

# ANavS Positioning and Map-Creation Systems – Reference Guide

Applicable to:

- Multi-Sensor RTK/PPP Module (MS-RTK)
- RTK/RTCM Reference Station
- ISP (Integrated Sensor Platform)

ANavS reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. Reproduction, use, modification or disclosure to third parties of this document or any part thereof without the express permission of ANavS is strictly prohibited.

The information contained herein is provided "as is" and ANavS assumes no liability for the use of the information. No warranty, either express or implied, is given with respect to, including but not limited to, the accuracy, correctness, reliability and fitness for a particular purpose of the information. This document may be revised by ANavS at any time. For most recent documents, please visit www.anavs.com.

© Copyright 2011-2022-10-11 ANavS GmbH. All rights reserved.

ANavS GmbH – Advanced Navigation Solutions Gotthardstrasse 40 80686 München, Germany Tel.: +49 - (0)89 - 89056721 Fax: +49 - (0)89 - 89056720 Internet: http://www.anavs.com/

**Reference Guide Document** 



Multi-Sensor RTK Module, RTK Reference Station and ISP 1. Getting Started with the GUI tools

### Abstract

The following guide provides a detailed explanation for the usage of the different ANavS<sup>®</sup> positioning Systems, the Multi-Sensor RTK/PPP module (MS-RTK), the RTK/RTCM Reference Station and the Integrated-Sensor-Platform (ISP).

The **ANavS® MS-RTK module** (chapter 2) provides a precise position, velocity, and attitude information. It is a turnkey system with a very attractive price/performance ratio and can be easily integrated into users' application. The module includes up to 3 Multi-frequency, Multi-GNSS (GPS, Galileo, Glonass, Beidou) receivers, a MEMS IMU, a barometer, a CAN interface for reception of vehicle data (wheel odometry and steering angle), an LTE module for reception of RTK/ PPP corrections (e.g. from ANavS® RTK reference station), and the powerful ANavS® Sensor Fusion on a single board. The latter one performs a tight coupling of all sensor data with an Extended Kalman Filter (EKF).

The **ANavS® RTK/RTCM Reference Station** (chapter 3) provides correction data in standard RTCM format to guarantee precise positioning in every situation without any integration effort. It only requires a power supply and connected GNSS antenna, thus it is ready to use after a short calibration phase of the fixed position.

The **Integrated Sensor Platform** (chapter 4) is a hardware-platform for easy integration of a large variety of sensors without any effort. It comes with a standard configuration of three GNSS receivers and integrated antennas, a high-grade MEMS IMU, a CAN interface for wheel odometry data and a barometer. On top of the standard sensors a fully integrated computer vision module is equipped, that can be flexibly configured with two cameras and/or a 3D-LiDAR with powerful processor for artificial intelligence (AI) applications.

Helpful tools for system configuration, for solution visualization, for postprocessing and for converters are explained also in this guide.



Multi-Sensor RTK Module, RTK Reference Station and ISP 1. Getting Started with the GUI tools

### **Typographical Conventions**

abc -param	Command-line instructions, e.g., in shell

abc -param MSRTKF command-line instructions

### List of Acronyms

AI Artificial Intelligence

CAN Controller Area Network

GNSS Global Navigation Satellite System GUI Graphical User Interface

IMU Inertial Measurement Unit ISP Integrated Sensor Platform

LTE Long Term Evolution

MEMS Micro-Electro-Mechanical Systems

PPP Precise-Point-Positioning

ROS Robot Operating System RTCM Radio Technical Commission for Maritime services RTK Real-Time-Kinematic

SLAM Simultaneous Localization and Mapping SSH Secure Shell

USB-PD USB-Power Delivery

VPU Vision Processing Unit



Multi-Sensor RTK Module, RTK Reference Station and ISP

1. Getting Started with the GUI tools

### Document Change Log

Issue	Revision	Sections Affected	Details of Change	
1	0	All	Initial version of document.	
1	1	9	Added overview of NTP functionality.	
1	2	2.7.8	Added hint for new settings with already running navigation-service.	
2	1	13	Added chapter for LTE-VPN configuration.	
2	2	6.1.1	Updated binary protocol with new parameters (inserted in "reserved" fields).	
		9.4	Added sub-chapter "Time-Synchronization with MS-RTK clock".	
2	3	Appendix 2/3/4/5	Added technical drawings for casing types including coordinates of IMU.	
		2.2	Changed power-consumption rating for newer hardware	
			versions (=>v9).	
2	4	12	Added Java-Version for using Record-Extractor tool	
2	5	8	Updated CAN-Interface description	
2	6	2.3, 3.2	Recommendation to use triple frequency variant of ANavS	
			positioning modules only with connected GNSS antennas.	
2	7	4.2, 4.3, 4.4	Updated chapter "Getting-Started with the Integrated-Sensor- Platform (ISP)"	
2	8	8.3.7	Added sub-chapter "Set up CAN hardware filter"	
2	9	4.2, 4.4, 10	Updated 4.2 and 4.4 to the current ISP setup with optional two	
			embedded GPU platforms. Added object detection as optional	
			algorithm and corresponding subsection.	
			Updated ROS-Ethernet Adapter description.	
2	10	8.2	Updated description with endianness of CAN-Output of ANavS	
			solution	
2	11	Appendix 1	Added example DBC file for ANavS solution output	
2	12	4.4	Updated section 4.4 with updated VPU setup with optional two	
			embedded GPU platforms.	
2	13	Appendix 3	Updated drawing with exact IMU position	
2	14	6	Velocity in MSKF filter is given in body frame, not in navigation	
			frame	



Multi-Sensor RTK Module, RTK Reference Station and ISP 1. Getting Started with the GUI tools

### Inhalt

1.	Get	ting S	tarted with the GUI tools1	0
	1.1.	Syst	em Requirements1	0
	1.2.	Dow	/nload1	0
	1.3.	Win	dows Installation1	0
	1.4.	Linu	x Installation1	0
	1.5.	The	ANavS <sup>®</sup> Wizard Tool1	1
	1.6.	The	ANavS <sup>®</sup> Visualizer Tool1	.3
2.	Get	ting S	tarted with the MS-RTK module1	8
	2.1.	Gen	eral1	.8
	2.2.	Pow	rering the MS-RTK Module1	8
	2.3.	Con	nections of the MS-RTK Module2	0
	2.4.	The	Setup for RTK- and Attitude-Determination2	.1
	2.5.	GNS	S Antenna Placement Guideline2	2
	2.6.	MS-	RTK module Placement Guideline2	.3
	2.7.	The	ANavS <sup>®</sup> -Wizard to configure the MSRTK Module2	4
	2.7.	1.	Wizard Step-12	.5
	2.7.	2.	Wizard Step-22	.5
	2.7.	3.	Wizard Step-3	1
	2.7.	4.	Wizard Step-43	2
	2.7.	5.	Wizard Step-53	3
	2.7.	6.	Wizard Step-63	5
	2.7.	7.	Wizard Step-73	6
	2.7.	8.	Wizard Step-83	7
	2.8.	The	ANavS <sup>®</sup> -Wizard to Update the MS-RTK Module3	9
3.	Get	ting S	tarted with the RTK/RTCM Reference Station4	1
	3.1.	Pow	vering the RTK/RTCM Reference Station4	1
	3.2.	The	Setup for the RTK/RTCM Reference Station4	1
	3.3.	The	ANavS <sup>®</sup> -Wizard to configure the RTK/RTCM Reference Station4	3
	3.3.	1.	Wizard Step-14	3
	3.3.	2.	Wizard Step-24	4



		3.3.3	8.	Wizard Step-3	46
		3.3.4	ŀ.	Wizard Step-4	47
		3.3.5	5.	Wizard Step-5	48
	3.4	4.	Rece	viving RTCM-Messages from the RTK/RTCM Reference Station	49
		3.4.1	L.	Broadcasting RTCM-Data via NTRIP-Caster hosted by ANavS cloud service	50
		3.4.2	2.	Broadcasting RTCM-Data via local NTRIP-Caster	51
	3.	5.	The	ANavS <sup>®</sup> -Wizard to Update the RTK/RTCM Reference Station	53
4.		Gett	ing St	tarted with the Integrated-Sensor-Platform (ISP)	54
	4.	1.	Gene	eral	54
	4.	2.	The	ISP Setup	55
	4.	3.	The	Basic-Configuration: GNSS, IMU and Odometry Sensor Fusion	56
		4.3.1	L.	The ANavS®-Wizard to Update the ISP Basic-Configuration	56
	4.4	4.	The	Computer-Vision Operation-Modes	57
		4.4.1	L.	Prerequisites	57
		4.4.2	2.	Setup	57
		4.4.3	8.	Data Acquisition Mode	58
		4.4.4	ŀ.	Object Detection	62
		4.4.5	5.	Troubleshooting	63
5.		The	Comr	mand Line API Reference Guide	65
	5.	1.	Navi	gation commands	65
	5.	2.	Syste	em commands	66
	5.	3.	Role	commands	68
	5.4	4.	CAN	commands	69
	5.	5.	Drive	er commands	71
	5.	6.	GNS	S commands	72
	5.	7.	LTE o	commands	73
	5.8	8.	Netv	vork commands	74
	5.9	9.	Reco	ord commands	75
	5.	10.	Se	rver commands	76
	5.	11.	Ti	me commands	77
6.		The	ANav	S Binary Solution Output Format	78



	6.1.	The	Standard Binary Solution Message	78
	6.1.	1.	The Pavload	
	6.1.	2.	The Result-Code	
	6.2.	The	Extended Integrity Information Message	
	6.2.	1.	The Pavload	
7.	The	NME	A Solution Output Format	
	7.1.	The	NMEA-Format	
	7.1.	1.	Sentence Structure	
	7.1.	2.	Address field	
	7.1.	3.	Data fields	90
	7.1.	4.	Checksum field	90
	7.1.	5.	Terminating field	90
	7.1.	6.	Satellite Numbering	90
	7.2.	Sent	ence specification	91
	7.2.	1.	GGA – Global positioning system (GPS) fix data	91
	7.2.	2.	VTG – Course over ground and ground speed	91
	7.2.	3.	GSA – GNSS DOP and active satellites	92
	7.2.	4.	GSV – GNSS satellites in view	92
	7.2.	5.	RMC – Recommended minimum specific GNSS data	93
	7.2.	6.	ZDA – Time and date	94
	7.2.	7.	PASHR – Attitude Data	94
8.	CAN	I-Inte	rface	96
	8.1.	CAN	Bus Settings	96
	8.2.	CAN	-Output: ANavS-Solution	97
	8.3.	CAN	-Input: Dynamic CAN Decoder with .dbc-file	99
	8.3.	1.	Overview	99
	8.3.	2.	Copy the DBC-file	100
	8.3.	3.	Load the file	100
	8.3.	4.	Generate code with DBCC	
	8.3.	5.	Select signals for sensors	
	8.3.	6.	Compile generated code	



	8.3.7	<b>'</b> .	Setup CAN hardware filter	102
	8.3.8	8.	Starting Sensor Fusion with ANavS Wizard	103
9.	The	Netw	vork-Time-Protocol (NTP)	105
ç	9.1.	Time	e Policy	105
ç	Э.2.	Time	e Server	106
ç	Э.З.	Stat	us Information	106
ç	9.4.	Time	e-Synchronization with MS-RTK clock	107
10.	A	VavS	ROS-Ethernet-Adapter (REA)	109
-	10.1.	Sy	ystem requirements and dependencies	
-	10.2.	RI	EA Client	109
	10.2	.1.	Prerequisites	109
	10.2	.2.	Setup your ROS environment	110
	10.2	.3.	Sensor fusion solution (mode: padsolution2ros)	110
11.	A	VavS	<sup>®</sup> Solution Decoder Tool	115
-	11.1.	D	ownload	115
	11.2.	Sc	ome Hints	116
	11.3.	Hi	ints especially for Linux users	116
	11.4.	D	ecode to .csv-format	116
	11.5.	D	ecode to .kml-format	117
12.	AN AN	VavS	® Record Extractor Tool	119
	12.1.	D	ownload	119
	12.2.	U	sage	119
	12.2	.1.	Arguments	119
	12.2	.2.	Output	119
13.	LT	E-VP	PN connection to the ANavS Positioning Systems	121
	13.1.	Se	etting up OpenVPN for Linux	121
	13.2.	Se	etting up the OpenVPN for Windows	121
Ар	pendix	- <b>1:</b> E	xample CAN DBC-File for the sensor data Input	123
Ар	pendix	-2: E	xample CAN DBC-File for the ANavS solution Output	125
Ар	pendix	-3: D	Prawing 3D-printed Casing Type	131
Ар	pendix	-4: D	Prawing Industrial Casing Type	132



Appendix-5: Drawing High-Class GNSS-Antenna	
Appendix-6: Drawing Survey-Grade GNSS-Antenna	



Multi-Sensor RTK Module, RTK Reference Station and ISP 1. Getting Started with the GUI tools

### 1. Getting Started with the GUI tools

The suite of GUI tools contains the so called **ANavS® Wizard** for configuring the hardware and the **ANavS®-Visualizer** for showing the real-time sensor fusion solution with all estimated parameters. How to use the programs is explained in the chapters for each ANavS Positioning System.

### 1.1. System Requirements

The following minimum requirements should be fulfilled:

Intel <sup>®</sup> Core <sup>™</sup> i5 with 1.60GHz or comparable processors
Minimum 4 GB
Windows 64-Bit architecture or Ubuntu 18.04
Minimum 500 MB

### 1.2. Download

Download the latest ANavS<sup>®</sup> Online Installer for your desired Operating System (Windows 10 or Ubuntu 18.04) from the following link:

https://anavs.com/knowledgebase/anavs-app/

### 1.3. Windows Installation

- Unzip and double click the installer executable file *ANavS\_Wizard\_Online\_Installer\_Win64Bit* and follow the installation-wizard step-bystep.
- Once it is finished, the installer displays an option to run the ANavS<sup>®</sup> Wizard after completion. If you choose this option, the application should start immediately. Otherwise, you must navigate to your previously defined installation-folder and run the Wizard-executable ANavS\_Wizard.exe. Besides, it could be important to start the software with admin-rights or to give the software the rights if asked for it.
- The ANavS<sup>®</sup> Wizard is always proving for new published versions of this tool in the online repository after starting the software.

### 1.4. Linux Installation

- Unzip the download file
- Launch the executable file *ANavS\_Wizard\_Online\_Installer\_Unix64Bit* via command line. If this does not work, please change the file permissions to be an executable file.



Multi-Sensor RTK Module, RTK Reference Station and ISP 1. Getting Started with the GUI tools

- After starting, follow the installation-wizard step-by-step.
- Once it is finished, the installer displays an option to run the ANavS<sup>®</sup>-Wizard after completion. If you choose this option, the application should start immediately. Otherwise, you must navigate to your installation-destination and run the Wizard-executable ANavS\_Wizard.exe via command line. Besides, it could be important to start the software with admin-rights or to give the software the rights if asked for it.
- The ANavS<sup>®</sup> Wizard is always proving for new published versions of this tool after starting the software.

### 1.5. The ANavS<sup>®</sup> Wizard Tool

The ANavS<sup>®</sup> Wizard tool connects to the ANavS<sup>®</sup> Positioning Systems using a TCP/IP data stream connection. This connection allows the ANavS<sup>®</sup>-Wizard to operate and control a positioning system remotely via Wi-Fi, Ethernet, or LTE.

Defining a TCP/IP connection is simply done by specifying the IP address of the ANavS Positioning System. This can be done by inserting the IP in the settings dialog (very left bottom button, see Figure 1). On default, the user should be connected via the established Wi-Fi Access-Point of the Positioning System with a SSID named with a substring "ANAVS". The default static IP of the Positioning System is

- 192.168.42.1 or
- 192.168.43.1

The default Ethernet configuration is DHCP. This brings the user the possibility to connect the ANavS Positioning System to a router with a running DHCP-server. Contact your network administrator for more information on how to map or get the IP address to/from a DNS server. A short introduction searching for IP address is also explained in the ANavS knowledge base (https://anavs.com/knowledgebase/using-the-ip-scanning-tool-nmap/)

The status field in the right bottom corner of the ANavS<sup>®</sup> Wizard shows the status of TCP/IPconnection. The message *"TCP-Conn OK"* says that the ANavS<sup>®</sup> Wizard can communicate with the MS-RTK module, RTK Reference Station or ISP. The message *"TCP-Conn N/A"* says the ANavS<sup>®</sup>-Wizard is NOT able to communicate with the ANavS Positioning Syst.

**HINT:** To get the best possible user-experience with the ANavS<sup>®</sup> Wizard, please change your global Windows/Linux Display settings of the Symbols to 100%. See Figure 2 for this.



#### Multi-Sensor RTK Module, RTK Reference Station and ISP

1. Getting Started with the GUI tools

ANavS RTK-Wizard			– 🗆 X
ANA	<sup>st</sup> STEP: s	Select your desired Mode	
Select this mode to perform se	ensor fusion in realtime o	n Multi-Sensor RTK-Module (MSRTK)	
Calibrate ANavS RTCM Select this mode to calibrate th	I Basestation	NavS RTCM Basestation	>
	Settings	×	
Update your ANavS-Mo Select this mode to update you with the latest stable-release of	IP-Address of MSRTK-Board: IP-Address of RTCM-Station: Voreinstellungen In WSRTR-Woddle of RTC or beta-release	192.168.42.1           192.168.43 1           Abbrechen         OK	>
Postprocess ANavS se Select this mode to postproce recorded with your MSRTK mo	ensor raw data ss your sensor raw data odule		>
Settings	out	Wizard-Version: MSRTK: TCP-Conn O RTCM-Station: TCP-Conn C	7.2.1   PAD-Version: 5.2.130 K (Nav-Mode: UNMANAGED) K (Nav-Mode: RTCM_NTRIP)

Figure 1: Defining the TCP/IP connection for controlling the positioning systems. The button is found in the left bottom corner. The different Modis of the ANavS<sup>®</sup> Wizard are explained in chapter 2 with the usage of the different positioning systems.

Settings	- σ x
Home Find a setting	Display Nyint light
aystern	rugitt agts settings.
🖵 Display	Windows HD Color
4章 Sound	Get a brighter and more vibrant picture for videos, games and apps that
Notifications & actions	Windows HD Color settings
J Focus assist	Scale and layout
O Power & sleep	Change the size of text, apps, and other items
Battery	100% · · ·
🖙 Storage	Advanced scaling settings
3 Tablet	utipay resolution 1920 × 1080 (Recommended)
H Multitasking	Display orientation
Projecting to this PC	Landscape 🗸
X Shared experiences	Multiple displays
Clipboard	Multiple displays
✓ Remote Desktop	Entend desitop to this display
O About	Make this my main display
	Connect to a wireless display
	Advanced display settings
	марика зекица

Figure 2: Changing display settings on Windows to 100%



Multi-Sensor RTK Module, RTK Reference Station and ISP 1. Getting Started with the GUI tools

### 1.6. The ANavS<sup>®</sup> Visualizer Tool

The ANavS<sup>®</sup> Visualizer is normally started by the ANavS<sup>®</sup> Wizard. After pushing the green start-button for triggering the ANavS<sup>®</sup> sensor fusion within the ANavS<sup>®</sup> Wizard at the end of a stepwise Positioning-System configuration, the ANavS<sup>®</sup> Visualizer (Figure 3) pops-up and the sensor fusion starts to run. The ANavS<sup>®</sup> GUI visualizes all sensor fusion estimates via text, graphs and on a map.

**HINT:** To get the best possible user-experience with the ANavS<sup>®</sup> Visualizer, please change your global Windows/Linux Display settings of the Symbols to 100%. See Figure 2 for this.

Besides, in case of already running sensor fusion on a positioning system, the user can directly start the ANavS<sup>®</sup> Visualizer tool. For this, please navigate to the subfolder **/bin** in your installation folder and start the visualizer via double click on the ANavS\_GUI.exe.



Figure 3: ANavS® Visualizer with graphs, constellation plot and map

At startup time of the application, the visualizer tries to connect via default or user-defined IPs with an ANavS<sup>®</sup> Positioning System. In addition to this Auto-Connect, the user can also manually insert the IP and Port within the Tab "Settings", shown in Figure 4. Please note, the Port is in the standard configuration always 6001, which is reserved for the proprietary binary protocol, used by the ANavS<sup>®</sup> Visualizer decoder to gather all the solution and system



Multi-Sensor RTK Module, RTK Reference Station and ISP 1. Getting Started with the GUI tools

information. Changing the port will prevent getting the solution stream into the ANavS<sup>®</sup> Visualizer in default settings without customer adjustments.



Multi-Sensor RTK Module, RTK Reference Station and ISP

1. Getting Started with the GUI tools



Figure 4: Defining the TCP/IP connection of the Positioning System for data streaming.



Figure 5: Positioning Accuracy in Centimeter-Level.



Multi-Sensor RTK Module, RTK Reference Station and ISP

1. Getting Started with the GUI tools



Figure 6: Phase-Residuals and many more information about the internal Kalman filter states.

#### Hints for ANavS<sup>®</sup> GUI handling:

- A Left-Mouse clicking in the Google-Earth plot zooms-in.
- A Right-Mouse clicking in the Google-Earth plot zooms-out.
- The map through the Google-Earth API is only visible with scale-level 5 meter or higher. Below only a withe map with scaling is visible.
- In the Tab "Settings", one can define the IP-address of an ANavS Positioning System to which the GUI should connect.
- The "Data rate" shows the amount of solution output data streamed to your Laptop/PC. With a successful connection, the data-rate should be always greater than zero.
- The "*Relative Position*" shows the baseline-vector from RTCM/RTK Reference Station to your Rover.
- The "Last corrections" in the left upper corner shows the time since the last RTK correction data was received. The counter should be under 10 seconds to get best RTK performance. If no counter appears but only "N/A", there is no valid connection between the ANavS Positioning System and the selected RTK correction source. Please prove again your settings in that case.



Multi-Sensor RTK Module, RTK Reference Station and ISP 1. Getting Started with the GUI tools

#### Important to get best performance:

- The gray or red light for the Attitude-LED signals that the attitude-solution is not fixed with GNSS phase measurements. That means, there is NO highly accurate attitude information available.
- The gray or red light for the RTK-LED signals that the position-solution is not fixed with GNSS phase measurements. That means, there is NO highly accurate position information available.
- The orange light for Attitude/RTK signals that the sensor fusion solution lost the fixed state and the Kalman filters performs in a float mode.
- The green light for Attitude/RTK signal that the position and/or attitude is fixed with GNSS phase measurements, and a highly accurate solution is available.
- To get best experience with the Positioning-Systems, please start movement only with float (orange signal) or fixed (green signal) mode.



Multi-Sensor RTK Module, RTK Reference Station and ISP 2. Getting Started with the MS-RTK module

### 2. Getting Started with the MS-RTK module

### 2.1. General

This guide is intended for first time Multi-Sensor RTK module (MS-RTK) users and provides an overview of how to handle with the required software, connect to and configure the MSRTK module, and acquire position and attitude solutions. By the end of this guide, you will be able to acquire a fixed RTK and Attitude solution using ANavS<sup>®</sup> MS-RTK modules. The steps in this guide should be performed outdoors.



Figure 7: MS-RTK module in industrial casing with touch panel (left) and 3D-printed casing (right)

### 2.2. Powering the MS-RTK Module

The MS-RTK module has three different options for power supply which are explained in the following.

### Important:

All options should deliver a minimum current supply of **2.1A@5V** (10.5 Watt) until hardware-version **msrtkv8**. From hardware-version **msrtkv9** onwards, all options should deliver minimum current supply of **3.5A@5V** (17.5 Watt).

The first option for power supply is via Powerbank (see **Figure 8**). For this option, please use a Powerbank with USB-C PD (power delivery mode)(Capacity: 10000mAh) and a USB cable with Typ-C connector to connect to the MS-RTK module.

**Important:** Don't use the USB-Type-A connector for powering the MS-RTK module.



Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module



Figure 8: Power supply via Powerbank

The second option for power supply is via standard 230V AC Power plug (see Figure 9). Please use the delivered Power adapter and the USB cable with Typ-C connector at one end.



Figure 9: Power-Supply with AC Power Plug

The third option for power supply is via wires (see Figure 10). Please take care of the polarity (+/-) and the allowed voltage-range of 9V - 24V.



Figure 10: DC Power-Supply per Wires



Multi-Sensor RTK Module, RTK Reference Station and ISP 2. Getting Started with the MS-RTK module

### 2.3. Connections of the MS-RTK Module

The following section describes the different standard connectors and interfaces of the MS-RTK module. Figure 11 shows the antenna-connections with up to 3 GNSS antennas/receivers. Please connect for a One-Antenna setup to GNSS 1, for Two-Antenna setup to GNSS 1+2 and for a Three-Antenna setup to GNSS 1+2+3.



Figure 11: GNSS Antenna connections

Figure 12 shows the standard connectors of the casing:

- SMA Connectors for GNSS: As already described in Figure 11, on the left side of the board are the connectors for the GNSS antennas. Please take care to connect in the appropriate order (GNSS 1, GNSS 2, GNSS 3).
- **SMA Connector for LTE/Mobile Network**: Please connect the delivered LTE Antenna in case of using the integrated mobile network chip for internet access (for example to receive correction data from your RTK Reference Station).
- **USB-Typ C for Power-Supply:** As already described, the USB-Typ-C connector is used for the Power-Plug or Powerbank for power supply.
- Camera Interface 1/2: The interfaces for ANavS<sup>®</sup> visual odometry sensor (VIS). Camera 1 can for example be used for the forward movement direction and Camera 2 for backward movement direction.<sup>1</sup>
- **CAN:** The CAN- 2.0A Interface is used for receiving vehicle data for example for wheelspeed information and to output the sensor-fusion solution. More information about adjusting DBC-files can be found in chapter 2.7.2 and chapter 8.

<sup>&</sup>lt;sup>1</sup> The Camera-Interfaces are only available until hardware version MSRTKv8.



Multi-Sensor RTK Module, RTK Reference Station and ISP 2. Getting Started with the MS-RTK module

- **USB-Interface:** The standard USB interface can be used for example for data-storage, Wi-Fi-dongle, LTE-dongle, data-transmission, etc.
- **Ethernet:** The ethernet-port can be used for internet/network-connections to stream for example the ANavS sensor fusion solution.
- **Power-Supply per Wires:** As already described in Figure 10, the module can be powered with DC-voltage (9V 24V) via wires.

Special interfaces and pins like UART, FPGA for incremental-decoder, PPS-Signal and GPIOs are not forwarded to the casing and need special customer adjustments.



Figure 12: Standard interfaces lead to the casing

### 2.4. The Setup for RTK- and Attitude-Determination

This chapter describes a typical setup of the MS-RTK module on a rover platform (car, robot, UAV, etc.). The heading and pitch of a vehicle can be derived from the orientation of the baseline between a base and a rover antenna when both antennas are attached to the vehicle. The base GNSS-antenna is connected to the first GNSS-receiver configured as RTK antenna. The second and third GNSS antenna is connected to the second and third receiver configured as Attitude antennas. This is illustrated in Figure 13.

With three GNSS-antennas on top of the car/rover the software can calculate the yaw, pitch, and roll angle of the rover in a very accurate way without the need of movement. The RTK correction data is typically streamed from an ANavS<sup>®</sup> RTK Reference Station or from an



Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module

external service-provider via Ethernet, LTE or Wi-Fi connection. The RTK-Baseline defines the centimeter-accurate position of your rover.



Figure 13: Typical setup on a car. The red coordinate frame indicates the rover's body-frame. The black coordinate-frame indicates the local navigation-frame (ANavS is using the NED-frame).

### 2.5. GNSS Antenna Placement Guideline

This is a very important step of the setup and has direct impact on the Position- and Attitude performance of the sensor fusion. The placement of the GNSS antennas defines the attitude-baseline, that means the yaw, pitch, and roll angle of your rover. Please mount the antennas in accordance with your use-case and carefully measure the distances between the GNSS antennas (measurement-error <= 1 cm). The configuration of the sensor fusion with these measured distances is done in the ANavS<sup>®</sup> Wizard and is described in the section 2.7.5.

### Please pay attention to the following:

• The minimum distance between two GNSS antennas is 30 cm.



Multi-Sensor RTK Module, RTK Reference Station and ISP 2. Getting Started with the MS-RTK module

- Please note that the attitude accuracy increases with the distance between the GNSS antennas (sigma=0.25° absolute attitude-accuracy per meter antenna spacing). That means at 2-meter baseline-length a sigma of 0.125° for the heading/pitch/roll.
- Please align your antennas in the same way to minimize the impact of antenna phase center offsets. The high-grade antennas have typically an arrow marked on the bottom or rear side of the antenna. The orientation of the low-cost patch antennas is simply defined by the orientation of the cable-connector.
- Please consider and measure also a height-offset between the mounted GNSS antennas. We recommend a placement at the same height level for the beginning as this prevents any sign errors of the differential height and typically enables the best performance.
- For setups with three GNSS antennas (3D-Setup for yaw, pitch, and roll angle determination), please make sure that distance measurements in perpendicular directions are having a 90° angular spacing as otherwise the distance measurements do not fit to the actual geometry. This would prevent any reliable solution.

### 2.6. MS-RTK module Placement Guideline

The following Figure 14 shows a placement example of the MS-RTK module and GNSS antennas in the body-frame of your rover (top-view).



Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module





### Please pay attention on the following:

- The movement direction of your rover is defining the orientation of the x-axis.
- The MS-RTK module includes an IMU, which needs to be oriented in a certain manner: The MS-RTK module must be oriented such that the SMA-connector of the LTE/mobile-network is pointing towards the movement direction.
- To get the best performance, it is good practice to mount the MS-RTK module in the center of rotation of your rover.

### 2.7. The ANavS<sup>®</sup>-Wizard to configure the MSRTK Module

In the previous section, the user became familiar with the hardware and the setup of the MS-RTK module. This section describes the use of the **ANavS® Wizard** software. To be able to configure and receive data of the module, please connect with the Wi-Fi Access-Point "ANAVS\_MSRTK\_AP" (Password: *anavsrtk*) of your switched-on MS-RTK module. Please note that the boot time of the Linux-OS is approximately 1-2 min. As described in chapter 1.5, the default static IP of the MS-RTK module is:

- 192.168.42.1 or
- 192.168.43.1 (on older hardware)



Multi-Sensor RTK Module, RTK Reference Station and ISP 2. Getting Started with the MS-RTK module

2.7.1. Wizard Step-1

Figure 15 shows Step-1 of the ANavS<sup>®</sup> Wizard application. Please select the first option "Starting ANavS Sensor Fusion on MSRTK module".



Figure 15: Step-1, Select your desired Modi

**Hint:** The Modi for Postprocessing ("Postprocess ANavS sensor raw data) is only available as part of a service contract or joint development-agreement.

### 2.7.2. Wizard Step-2

Figure 16 and Figure 17 shows Step-2 of the ANavS<sup>®</sup> Wizard application. In this step, the Wizard is proving the communication between the users Laptop/PC and the MS-RTK module. In case the error-dialog as shown in Figure 16 appears, please check again your Wi-Fi/Ethernet connection settings with the button in the bottom left corner ("Settings").

Figure 17 shows the typical window with correct Wi-Fi/Ethernet settings. One can adjust here the settings for the mobile network module, the Wi-Fi module, the Ethernet module and the CAN-transceiver module (described in chapter 8 in more detail).



Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module

Define APN: e.g: InternetLemobile   Define Dial-Up Number: e.g: 1799#   Define Username: e.g: 1m   Define Passwort: e.g: 1m   Define PiN (If activated): TCP-Connection to your MSRTK?   SEND CONFIG Please check your WLAN or Ethernet settings   WIFI Information: VIFI Configuration:   Profile: N/A   Connected SSID: N/A   Current Address: N/A   Current Netmask: N/A   Signal Quality: N/A	ANavS RTK-Wizard	•Settings:	TEP: Interface Setti	– D ×
WiFi Information:     WiFi Configuration:     Known WiFis:       Profile:     N/A     Profile:     O FF     CLI-STATIC       Connected SSID:     N/A     O P-static SSID:     Image: Cliphone Clip	Define APN: Define Dial-Up Number: Define Username: Define Passwort: Define PIN (If activated): SEND CONFIG WIFI-Settings:	e.g.: Internet.t-mobile e.g.: T*99# e.g.: t-mobile e.g.: tm	MSRTK-Feedback:	4G is Inactive     (RE-)START 4G     GET STATUS
	WiFi Information:         Profile:       N/A         Connected SSID:       N/A         Current Address:       N/A         Current Netmask:       N/A         Signal Quality:       N/A		WiFi Configuration:         Profile:       0 FF         CLI-DHCP         AP-static SSID:         AP-static PSK:         AP-static IP:         AP-static Netmask:	Known WiFis:

ANavS RTK-Wizard			- 🗆 X
<	energy 2 <sup>nd</sup> S	STEP: Interface Sett	ings of MSRTK-Module
Mobile-Netw	vork-Settings:		
Define APN:	em	MSRTK-Feedback:	4G is Active
Define Dial-Up Numbe	er: T*99#		(RE-)START 4G
Define Username:	e.g.: t-mobile		GET STATUS
Define Passwort:	e.g.: tm		
Define PIN (If activate	d):		Strength:
SEND CONFIG			
WiEi-Setting	.e.		
wiri-Setting	5.		
WiFi Information:		WiFi Configuration:	Known WiFis:
Profile:	AP_STATIC	Profile: OFF (	CLI-STATIC
Connected SSID:	ANAVS_MSRTK_AP_Andi	O CLI-DHCP @	AP-STATIC
Current Address:	192.168.42.1	AP-static SSID: ANAVS_MSRT	<u>&lt;_AP</u>
Current Netmask:	255.255.255.0	AP-static PSK: anavsrtk	
Signal Quality:	0%	AP-static IP: 192.168.42.1	
		AP-static Netmask: 255.255.255.0	
Settings	CÎ ⊂ Output		CAN-Status: Not receiving any messages   MSRTK-Temperature: 47.80 Wizard-Version: 7.2.1   PAD-Version: 5.2.13
			MSRTK: TCP-Conn OK (Nav-Mode: UNMANAGED

Figure 17: Step-2, Mobile-Network/Wi-Fi/CAN settings of MS-RTK module

Issue: 2.14

Reference Guide Document

Figure 16: Step-2, Wi-Fi/Ethernet connection error message



**Multi-Sensor RTK Module, RTK Reference Station and ISP** 2. Getting Started with the MS-RTK module

### Mobile Network Settings:

ANavS delivers all Positioning Systems with already equipped SIM-cards, which are providerindependent and dial-in into the best available mobile network at users' location. The region (Europe, North America, Asia, ...) is selectable by the customer in the ordering-process. The fee of the SIM-card is part of a service-contract or directly bookable by ANavS. The following settings are needed for the SIMs:

•	APN:	em

• Dial-Up Number: T\*99#

Own SIM-cards can also be used. With the 3D printed casing, the user can exchange the SIMcard without any help and extra cost. With the industrial casing, the user must send the SIM to ANavS before delivering the Positioning System. If this change has to be done afterwards, ANavS reserves the right to charge for the replacement.

In case of using an own SIM-card, please change the settings here accordingly and click afterwards to the button "SEND CONFIG" to transmit the new settings to the MS-RTK module. In the next step, click "(RE-)START 4G" button. If all provided information for the SIM-card are correct and LTE-reception is available at your position, the field "4G Is Inactive" becomes "4G is Active" and the color turns from red to green.

The configuration is saved to enable an automatic re-connection with the mobile network after each reboot.

### Wi-Fi Settings (obsolete):

The left section is showing the current Wi-Fi settings. The right section is for the Wi-Fi configuration. The Wi-Fi-module can be used in four different Modis.

### • Access-Point (AP-STATIC Profile):

The standard/default way is the Access-Point (AP) profile. This means that the MS-RTK module is creating its own Wi-Fi-network with the SSID "ANAVS\_MSRTK\_AP" with password "anavsrtk" and static IP 192.168.42.1. Please use this mode for your first steps to get familiar with the system.

• Client DHCP-Mode (CLI-DHCP Profile):

With this selected profile, the MS-RTK module tries to connect to an existing Wi-Fi network with a running DCHP-server running on it. To give the information to the MSRTK module, please use the "**SCAN**" Button and select the suitable SSID from the dropdown-list. After this, please define the Password in the dialog-window, activate the "**ADD**" radio button and click "**APPLY NEW CONFIGURATION**". It is possible to define a lot of known Wi-Fi-networks. But take care, you must know the assigned IP-



**Multi-Sensor RTK Module, RTK Reference Station and ISP** 2. Getting Started with the MS-RTK module

address to your MSRTK module in your network to be able to communicate with the ANavS<sup>®</sup> Wizard to the MSRTK module. The new IP must be signed in the message box by clicking on the "Settings"-button in the bottom left corner. A detailed description of how to find the IP-address of your MSRTK module is described in the ANavS knowledge base "Using the IP scanning-tool NMAP" <sup>2</sup>. Another knowledge base article is explaining how to broadcast RTK-Data from your ANavS RTK reference station directly via Wi-Fi to your MS-RTK module <sup>3</sup>.

- Client Static-Mode (CLI-STATIC Profile): With this selected profile, the MS-RTK module tries to connect to an existing Wi-Fi network without a running DCHP-server running on it. The procedure for configuration is the same as for the CLI-DHCP profile.
- Powered-Off Wi-Fi module (OFF Profile):
   Use this mode to save power consumption or to reduce traffic in the Wi-Fi frequency range. BUT NOT RECOMMENDED.

### Ethernet Settings:

The left section is showing the current Ethernet settings. The right section is for the Ethernet configuration. The Ethernet module can be used in three different Modis.

DHCP-Mode (DHCP Profile):

With this default setting, the Ethernet port is waiting to get an IP address of a DHCP server (e.g., from a router). After connecting the MS-RTK module via Ethernet cable with a router/DHCP-server, you can identify the MSRTK modules IP-address via the Ethernet information section in the Wizard window, the dashboard of your router or scanning the network as explained in the knowledge base article "Using the IP scanning-tool NMAP"<sup>2</sup>.

- Static-Mode (STATIC Profile): Another option is to set a static IP for the MSRTK module and directly connect it with another device or laptop with same static IP range address.
- Powered-Off Ethernet port (OFF Profile):
   Use this mode to save power consumption. BUT NOT RECOMMENDED.

### CAN Settings:

<sup>&</sup>lt;sup>2</sup> Using the IP scanning-tool NMAP: <u>https://anavs.com/knowledgebase/using-the-ip-scanning-tool-nmap/</u>

<sup>&</sup>lt;sup>3</sup> Broadcasting RTCM-Data for MSRTK Modules: <u>https://anavs.com/knowledgebase/publishing-rtcm-data-for-msrtk-modules/</u>



Multi-Sensor RTK Module, RTK Reference Station and ISP 2. Getting Started with the MS-RTK module

CAN is a robust and widely spread data bus standard which is among other applications also used in almost all modern vehicles for communication between the various controllers in it.

The MS-RTK Module comes with a CAN Interface that allows the user to input wheel odometry values and/or to access the solution data over that interface. The CAN- 2.0A Interface can be fully configured in the ANavS Wizard (Figure 18). The settings are hereby divided in two categories: the bus settings and the solution output (CAN-Output).

### CAN Bus Settings:

- **Bus-Speed:** Select the Bit rate of the CAN bus. By default, 500 Kbit/s are selected.
- **Termination enabled:** CAN requires a 120 Ohm hardware termination at the last transceiver. The MS-RTK System has a built in switchable 120 Ohm termination which can be enabled by using this slider.
- Bus mode: The normal mode is the default mode in which the CAN Interface is fully operating. In the listen-only mode, the CAN-Controller does not transmit any data and does not acknowledge the received CAN-frames. This mode can be used to monitor the data bus without participate or interfere with the traffic on the bus. In the listenonly mode it is not possible to output solution information.
- **Output enabled:** This function is intended as an extra security layer to avoid unintentional writing on the CAN bus. It must be enabled to use the solution output functionality of the CAN Interface. Otherwise, it is recommended to switch it off.

### Solution Output via CAN:

The CAN Interface can be used to receive the output of the position and attitude solution. The CAN Interface sends for each solution variable a unique message containing the value. The CAN address corresponds to the ID of the variable. The variables are bundled in groups which can be activated or deactivated by checking the corresponding boxes. As standard, each packet has a unique ID which is also shown in the table below. To change the IDs of the CAN messages (e.g., to avoid collisions with the information of other devices on the bus), there is the possibility to add an offset to all messages. To use the solution output via CAN, the bus must be configured in the normal mode and the output must be enabled (see also above section "CAN Bus settings").

ID	Format	Name	Unit	Description
1	uint16	resCode	-	Result code bitfield, which keeps the system status
				and information.
2	uint16	week	-	Week number of the current epoch.
3	double	tow	S	Time of Week of the current epoch.
4	uint16	weekInit	_	Week number of the epoch when the system was
				started.



Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module

5	double	towInit	S	Time of Week of the epoch when the system was	
				started.	
7	double	lat	deg	Latitude.	
8	double	lon	deg	Longitude.	
9	double	height	m	Height	
10	double	ECEF-X	m	X-position in ECEF-coordinate frame	
11	double	ECEF-Y	m	Y-position in ECEF-coordinate frame	
12	double	ECEF-Z	m	Z-position in ECEF-coordinate frame	
13 –	3*double	b	m	Baseline in NED frame spanned by the position	
15				given by lat, lon and height, and by the position of	
				the reference station.	
16 –	3*double	bStdDev	m	Standard deviation of the baseline.	
18					
19 –	3*double	vel	m/s	Velocity in NED frame.	
21					
22 –	3*double	velStdDev	m/s	Standard deviation of the velocity.	
24					
25 –	3*double	асс	m/s²	Acceleration in body frame.	
27					
28 –	3*double	accStdDev	m/s²	Standard deviation of the acceleration.	
30					
31 –	3*double	att	deg	Attitude/Euler angles (heading, pitch, roll).	
33					
34 –	3*double	attStdDev	deg	Standard deviation of the attitude.	
36					
39 –	5*double	timing-Info	s	CPU-Load of used sensors. The sum (green line in	
43				the GUI) of elapsed time should not over 1 second	
				(-> to slow processor).	
				First double: Elapsed time GNSS;	
				Second double: Elapsed time IMU;	
				Third double: Elapsed time Baro;	
				Fourth double: Elapsed time Odometry;	
				Fifth double: Reserved	
46	double	latency-info	s	Overall end-to-end positioning latency	
49	double	gnssReception	-	Scalar, which indicates the GNSS signal reception.	
				The value is between 0 and 20, where 20 is the	
				best, i.e. very good conditions.	
50	uint8	numSats		Number of satellites.	

Table 1: CAN-Bus output messages



#### Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module

ANavS RTK-Wizard – X					
< .	2 <sup>nd</sup> S	STEP: Interfa	ce Settings of M	ISRTK-Module	>
CAN-Settings:					
For detailed information to the CAN-Interface, please read the CAN configuration guide. (https://anavs.de/knowledge-base/can-interface-of-the-msrtk-module/)					
Bus Settings:					
Defines the basic hardwar	re properties of the CAN is	nterface.			
Bus-Speed:	500 kBit/s V				
Termination enabled:					
Output enabled:					
Bus-Mode:	Bus-Mode:   O Listen-Only				
Solution output via C	AN:				
Select the solution message	ges which should be trans	smitted via CAN:			
resCode	Position Lat/Lon/Height	Velocity NED-Frame	Attitude (Heading/Pitch/Roll)	Timing-Info	
Week + Tow	Position ECEF-Frame	Velocity StdDev NED-Frame	Attitude StdDev	Latency-Info	
WeekInit + TowInit	RTK-Baseline NED-Frame	Acceleration Body-Frame	Accuracy of RTK-Solution	GNSS-Reception	
	RTK-Baseline StdDev NED-Frame	Acceleration StdDev Body-Frame		Number of used Satellites	
Define offset of MSRTK-Module 0x Current Offset: 0x0					
Settings	Output		CAN-Status: N	lot receiving any messages   MSRTK-Temp Wizard-Version: 7.2.1   PAD-V MSRTK: TCP-Conn OK (Nav-Mode)	verature: 50.50° /ersion: 5.2.130

Figure 18: Step-2, CAN settings window of MS-RTK module

#### Odometry input via CAN:

The ANavS sensor fusion can handle different forms of vehicle odometry. Up to 5 variables can therefore be defined. These are either one, two or four independent wheel speeds, and the steering angle or another heading information of the vehicle in the vehicle frame. The algorithms inside of the sensor fusion software calculate from the different inputs the current velocity and heading information in the body frame of the vehicle for the positioning algorithm.

To adjust the CAN-Interface to user specific CAN messages, a dynamic CAN decoder is part of the MS-RTK module as command-line tool. The Dynamic CAN Decoder allows you to use the MS-RTK system with CAN signals from your .DBC file without sharing the file with third parties or ANavS. The DBC-generation on the MS-RTK module is described in detail in chapter 8.

### 2.7.3. Wizard Step-3

The Figure 19 shows Step 3 of the ANavS<sup>®</sup> Wizard application. The user needs to define the number of used GNSS antennas mounted on the rover respectively screwed on the MSRTK module.



**Multi-Sensor RTK Module, RTK Reference Station and ISP** 2. Getting Started with the MS-RTK module

The impact of user's selection:

**1-Dimensional:** The attitude is estimated with movement and coupled with the IMUgyroscope and accelerometer (one GNSS antenna connected). With this setup, you need some rover dynamic (curves, circles) to get an accurate attitude information of your rover.

**2-Dimensional:** The attitude (yaw and pitch angle) is already determined without movement using fixed carrier-phase GNSS measurements and coupled with the IMU-gyroscope (two GNSS antennas connected).

**3-Dimensional:** The attitude (yaw, pitch, and roll angles) is already determined without movement using carrier-phase GNSS measurements and coupled with the IMU-gyroscopes (three GNSS antennas connected).



Figure 19: Step-3, Select Attitude-Dimensionality

### 2.7.4. Wizard Step-4

The next step proves the GNSS antenna connection and if the count of founded GNSS antennas match with the previous selected Attitude dimensionality (Step-3). The user can only go forwards if it matches in a proper way.

Reference Guide Document



Multi-Sensor RTK Module, RTK Reference Station and ISP 2. Getting Started with the MS-RTK module

The following circumstances would prevent a successful GNSS-antenna connection:

- Failure in Antenna-Status: The positioning system need only some more boot-time for the OS and some time for gather satellite information (30 – 90sec).
- Failure in Antenna-Status: If the antenna-Status problem stays the same after some retries, to long antenna cables could lead to a missing recognition of the antenna from the GNSS-receiver side. The text field "Antenna-Status" shows ERROR or SHORT in that case.
- No Data received/ No Satellites visible: Please check this step with GNSS antennas outdoor.



Figure 20: Step-4, Proving Antenna-Connections of MS-RTK module

### 2.7.5. Wizard Step-5

The following Figure 21 shows the placement input of the users GNSS antennas in the bodyframe of your rover (top-view). Each Text field needs input, before proceeding with the next steps.

### Please pay attention on the following:



Multi-Sensor RTK Module, RTK Reference Station and ISP 2. Getting Started with the MS-RTK module

- The x-direction shown in graph/coordinate-frame defines the movement-direction of your rover
- Please measure the distances as accurate as possible. The measurement-error should be below 1 cm
- Defining the z-Axis corresponds to the right-hand-rule. The thumb shows in movement-direction
- ANavS RTK-Wizard × 5<sup>th</sup> STEP: GNSS-Antenna Dimensions in Rover's body-frame **GNSS-Antenna 1:** X-axis: 0 [cm] Y-axis: 0 [cm] Z-axis: 0 [cm] Mov Direction **GNSS-Antenna 2:** X-axis: 30 [cm] Y-axis: 30 [cm] Z-axis: 0 [cm] **GNSS-Antenna 3:** Y-axis: 30 [cm] Y [cm] Z-axis: 0 [cm] CAN-Status: Not rece Output Settings Lever arm MSRTK: TCI
- For setups with three GNSS Antennas, please use a right-angle measurement-tool

Figure 21: Step-5, GNSS-Antenna Dimension in rover body-frame

In addition, the lever arms of the other sensors can also be configured in this step. Please open the corresponding window "Lever arm" shown in the bottom of this step. Figure 22 shows the input-options.



Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module



Figure 22: Step-5, configuration of additional sensor lever arm

### 2.7.6. Wizard Step-6

Step 6 is used for defining the input-stream for RTK correction data. The source could be your own ANavS RTK Reference Station, third-party reference stations or external service provider like SAPOS or Axio-Net. The nomenclature for a suitable RTK input-format notation is given in the Wizard-Window. To facilitate the user input, the last three streams are cached in a selectable history.



Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module

ANavS RTK-Wizard	- 🗆 X				
< 6 <sup>th</sup> STEF	C: Define RTCM-Station Input-Stream				
NTRIP Server/Client Connection: Define your RTCM stream to receive RTK correction-data on your MSRTK-Module.					
RTCM_User:anavs123@18.189.7.57:30672/ANAVS <username>:<passwort>@<ip-adress>:<portnumber>/<mointpoint></mointpoint></portnumber></ip-adress></passwort></username>	Input History:				
Settings 1 Output	CAN-Status: Not receiving any messages   MSRTK-Temperature: 45.10* Wizard-Versior: 7.2.1   PAD-Version: 5.2.130 MSRTK: TCP-Cono K( Naw-Mode: UNMANAGED)				

Figure 23: Step-6, Define RTCM/RTK Reference Station Input-Stream

### 2.7.7. Wizard Step-7

The ANavS<sup>®</sup> Sensor Fusion Framework is customizable with some specific a priori information.

For using a priori information about the reference station, an input-option is given in this step. The user can fill the dimension in the NED (North-East-Down)-Frame format for using this mask. Additionally, the accuracy of the measurement can be set and needs to be activated with the appropriate button.
 This input is NOT mandatory: Use this input only if the information is exactly known and the user is introduced in the NED-frame and how one can set this parameter in a

and the user is introduced in the NED-frame and how one can set this parameter in correct manner.

- The additional setting "Up-Velocity" is for constraining the velocity mainly in the horizontal plane. It's recommended to activate this option for applications like automotive or robotics. Please deactivate this option for UAV-applications or something similar.
- The additional setting "Heading<->Velocity" is for constraining the velocity mainly to the heading direction. It's recommended to activate this option for applications like


Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module

automotive or robotics. Please deactivate this option for UAV-applications or something similar.

ANavS RTK-Wizard	- 🗆 X
<	7 <sup>th</sup> STEP: Settings for a priori information
Reference Station         (Define ONLY if exactly known!)         North: <ul> <li>Set Active</li> <li>Sigma:</li> <li>2 cm</li> <li>5 cm</li> <li>10 cm</li> </ul> East: <ul> <li>Set Active</li> <li>Sigma:</li> <li>2 cm</li> <li>5 cm</li> <li>10 cm</li> </ul> Down: <ul> <li>Set Active</li> <li>Sigma:</li> <li>2 cm</li> <li>5 cm</li> <li>10 cm</li> </ul> Length: <ul> <li>2 cm</li> <li>5 cm</li> <li>10 cm</li> </ul>	
Additional Settings Up-Velocity SetActive Constraining velocity mainly into the horizontal-plane. (e.g. for automotive applications) Heading<->Velocity SetActive Constraining velocity to the heading-direction. Helps especially in poor environments.	Reference-Station 50 50 50 50 50 50 50 50 50 50
Settings	CAN-Status: Not receiving any messages   MSRTK-Temperature: 48.30° Wizard-Version: 7.2.1   PAD-Version: 5.2.130 MSRTK: TCP-Conn OK (Nav-Mode: UNMANAGED)

Figure 24: Step-7, Settings for a priori Information

#### 2.7.8. Wizard Step-8

In the last step of the Wizard, the user can start the ANavS<sup>®</sup> sensor fusion with the green start-button. Before starting, please check further settings:

- The checkbox "Enable Save Solution File" activates recording the Realtime sensor fusion solution in a file. The format of the file depends on the selected type of solution output. Furthermore, the user gets a converted KML-file, which gives the user the opportunity to see the most interesting information (position, attitude, velocity, and acceleration) in a Google-Earth plot. The files are saved in 

   UserPath>/Documents/AnavsWizardAppData/output\_data. With the button "Output" on the bottom of the Wizard, the user can directly step to the generated output-folders. Each recorded dataset is saved in one own folder with the naming "YYYYMMDD\_HHMM\_UTC".
- The checkbox "Enable Save Raw Data Files" activates recording of all processed sensor data (GNSS, IMU, Barometer, Odometry, Visual-Odometry, ...) with highly



Multi-Sensor RTK Module, RTK Reference Station and ISP 2. Getting Started with the MS-RTK module

accurate timestamps to use the data for postprocessing. The files are saved in *<UserPath>/Documents/AnavsWizardAppData/output\_data*.

With the button "**Output**" on the bottom of the Wizard, the user can directly step to the generated output-folders. Each recorded dataset is saved in one own folder with the naming "**YYYYMMDD\_HHMM\_UTC**".

- The checkbox "Enable Odometry (via USB)" is used for enabling the Odometry-Input via USB-Typ-A. Only with activated checkbox, the tightly coupled sensor fusion is using this input sensor data.
- The checkbox "Enable Odometry (via CAN)" is used for enabling the Odometry-Input via CAN. Only with activated checkbox, the tightly coupled sensor fusion is using this input sensor data.
- The checkbox "Enable Autostart of Navigation-Service" effects an automated start of the sensor fusion after switching-on the MS-RTK module with the last userconfiguration. To see the solution in the ANavS® Visualizer, start the program ANavS\_GUI.exe in the folder <Installation-Path>/ANavS\_Wizard/bin.
- The checkbox "Enable Low-Latency-Mode" can be used for very time-critical applications. The software limits the used GNSS-signals and pushes the solution output in a strict manner.
- The checkbox "Enable Dynamic Attitude Fix" forces an Attitude-Fix with GNSS phase measurements not only in stand-still mode but also in movement. Applications with less stand-still phases should activate the checkbox.
- The option "Type of Solution-Output" is explained in chapters about ANavS<sup>®</sup> Binary Solution Output Format and NMEA Solution Output Format in XX and XX.
- The option "**Customer-Code**" is only for experts with appropriate support-level. The default-value is 0.
- The option "Output-Rate" is selectable with Low (5Hz), Medium(55-65Hz), and High(105-125Hz). The exact rate depends on the used sensors within the tightly coupled sensor fusion.

After pushing the green start-button for triggering the ANavS<sup>®</sup> sensor fusion on the MS-RTK module, the settings are stored on the module, the ANavS<sup>®</sup> Visualizer pops-up and the sensor fusion navigation service starts to run.

**HINT:** In case of an already running Navigation-Mode, the Wizard and Visualizer is only attaching to this process without restarting the Navigation-Service. Please stop and start again the Navigation-Service to perform with the newest settings.



Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module



Figure 25: Step-8, Starting ANavS Sensor fusion Navigation Service

### 2.8. The ANavS<sup>®</sup>-Wizard to Update the MS-RTK Module

The ANavS<sup>®</sup> Wizard can also be used for updating the MS-RTK module. Trying this, the user must provide internet access to the MS-RTK module. The default way would be through the mobile network or through Ethernet with a connection to a router. The first step in the Wizard is selecting the option "Update your ANavS-Module (...)" on the starting page.

The next window is showed in Figure 26. The user has two options with the **Online-Updater**. Selecting the button "Stable Update", the user updates the MS-RTK (and also the RTK Reference Station) with the latest stable version on the ANavS repository. It is well tested but is not including all recent minor updates and sensor fusion improvements. Selecting the button "Beta Update", the user updates the MS-RTK (and also the RTK Reference Station) with the latest stable version. It is less tested but is including all recent minor updates the MS-RTK (and also the RTK Reference Station) with the latest Beta version on the ANavS repository. It is less tested but is including all recent minor updates and sensor fusion improvements.

In case of problems with getting internet access to the MS-RTK module, ANavS is also providing an **Offline-Updater**. Using this option, please contact the support to get the recent



Multi-Sensor RTK Module, RTK Reference Station and ISP

2. Getting Started with the MS-RTK module

Update-Zip, load it in the Wizard (do NOT unzip this file) with the SEARCH button and click the update-button.

ANavS RTK-Wizard			-		×
<	enave 2"	nd STEP: Update your ANavS Devices			
Online-Updat	ter to the latest	STABLE or BETA Release:			
Please be connected deviationaly, the N	cted per WiFi/Ethern lodules need Interne vices (MSRTK and/o	net with your ANavS-Modules. et-Connection to reach the ANavS Update-Server. or RTCM Basestation) will be updated.			
STABLE Update:	Feedback of Update-Proce	ess:			
$\bigcirc$					
BETA Update:					
$\bigcirc$					
Offline-Upda	ter to the latest	STABLE or BETA Release:			
In case of proble please contact th and load in the fo	ms with the Online-L e ANavS-Support (s arm below	Jpdater, upport@anavs.de) for the offline zip-file			
Settings	Output	Wizard-Versi MSRTK: TCP-Con RTCM-Station: TCP-Con	on: 7.2.1   PAD-\ n OK (Nav-Mode: n OK (Nav-Mode:	/ersion: 5 UNMAN/ RTCM_N	.2.150 AGED) NTRIP)

Figure 26: Update of the MS-RTK module with the ANavS Wizard



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

### 3. Getting Started with the RTK/RTCM Reference Station

This guide is intended for first time RTK/RTCM Reference Station users and provides an overview of how to handle with the required software, connect to and configure the Reference Station.



Figure 27: RTK/RTCM Reference Station in industrial casing with touch panel

### 3.1. Powering the RTK/RTCM Reference Station

The RTK/RTCM Reference Station can be powered with standard 230V AC-Voltage plug or with standard USB Type-C (e.g., 5V USB Powerbank with PD (Power-Delivery)).

### 3.2. The Setup for the RTK/RTCM Reference Station

Figure 28 shows the standard connections for the typical RTK/RTCM Reference Station setup:

- Please connect the GNSS antenna with the marked SMA connector to the Reference Station. The GNSS antenna must stay outside with open-sky environment (see Figure 29).
- Please connect the Wi-Fi antenna with the marked SMA connector to the Reference Station.
- Provide internet-access to the Reference Station for transmitting RTCM 3.2 messages. For this, please connect the station to a router or screw on the mobile network antenna.



#### Multi-Sensor RTK Module, RTK Reference Station and ISP

3. Getting Started with the RTK/RTCM Reference Station



Figure 28: RTK/RTCM Reference Station connections

**Recommendation:** The GNSS antenna should be fixed mounted on position outside with best possible satellite visibility (see Figure 29). A recommended place would be the roof of a high building or similar places. The RTK correction data of the Reference Station are highly accurate for rovers within 15 km distance from rover (MS-RTK module) to Reference Station. A common way is to fix the Reference Station on a location where the user can calibrate the position once a time and don't change the position again.



Figure 29: Reference Station placement guideline



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

### 3.3. The ANavS<sup>®</sup>-Wizard to configure the RTK/RTCM Reference Station

In the previous section, you became familiar with the hardware and the setup. This section describes the use of the **ANavS® Wizard** software. To be able to configure and receive data of the module, please connect with the Wi-Fi Access-Point "ANAVS\_RTCM\_AP" (Password: *anavsrtk*) of your switched-on Reference Station. Please note that the boot time of the Linux-OS is approximately 1-2 min. As described in chapter 1.5, the default static IP of the Reference Station is:

- 192.168.42.1 or
- 192.168.43.1 (on older hardware)

#### 3.3.1. Wizard Step-1

For a precise absolute/relative position solution the Reference Station needs a one-time calibration before using it for the new position. Figure 30 shows Step-1 of the ANavS<sup>®</sup> Wizard application. Please select the second option "Calibrate ANavS RTCM Basestation".

ANavS RTK-Wizard	– 🗆 X
1 <sup>st</sup> STEP: Select your desired Mod	9
Starting ANavS Sensor Fusion on MSRTK-Module	
Select this mode to perform sensor fusion in realtime on Multi-Sensor RTK-Module (N	ISRTK)
Calibrate ANavS RTCM Basestation	
Select this mode to calibrate the static location of the ANavS RTCM Basestation	>
Update your ANavS-Module (MSRTK or RTCM Basestation)	
Select this mode to update your MSRTK-Module or RTCM Basestation with the latest stable-release or beta-release	>
Postprocess ANavS sensor raw data	
C settings and to postprocess your sensor raw data	ard-Version: 7.2.1   PAD-Version: 5.1.264
Settings Output MsRTk: T	CP-Conn OK (Nav-Mode: UNMANAGED) CP-Conn OK (Nav-Mode: RTCM_NTRIP)

Figure 30: Step-1, Select the desired modus "Calibrate ANavS RTCM Base Station"



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

3.3.2. Wizard Step-2

Figure 31 shows Step-2 of the ANavS<sup>®</sup> Wizard application. In this step, the Wizard is proving the communication between the users Laptop/PC and the MS-RTK module. If the error-dialog as shown in Figure 16 appears, please check again your Wi-Fi/Ethernet connection settings with the button in the bottom left corner ("Settings").

On this settings-window one can adjust the settings for the mobile network module, the Wi-Fi module, and the Ethernet module.

ANavS RTK-Wizard			– 🗆 X
< 🔬	2 <sup>nd</sup> STE	EP: Interface Setting	gs of ANavS RTCM-Station
Mobile-Netwo	rk-Settings:		
Define APN:	em	RTCM-Station Feedback:	4G is Active
Define Dial-Up Number:	T*99#		(RE-)START 4G
Define Username:	e.g.: t-mobile		GET STATUS
Define Passwort:	e.g.: tm		Signal.
Define PIN (If activated):			Strength:
SEND CONFIG			
WiFi-Settings:			
WiFi Information:		WiFi Configuration:	Known WiFis:
Profile: Al	P_STATIC	Profile: OFF	O CLI-STATIC
Connected SSID: AI	NAVS_MSRTK_AP_Andi	() CLI-DHCP (	• • AP-STATIC
Current Address: 19	92.168.42.1	AP-static PSK: anavetk	IK_AP
Current Netmask: 25	55.255.255.0	AP-static IP: 192 168 42 1	
Signal Quality: 05	%	AP-static Netmask: 255,255,255,0	
Settings	Output		RTCM-Temperature: 45.10° Wizard-Version: 7.2.1   PAD-Version: 5.1.264 RTCM-Station: TCP-Conn OK (Nav-Mode: UNMANAGED)

Figure 31: Step-2, Interface settings of ANavS RTCM Base Station

#### Mobile Network Settings:

ANavS delivers all Positioning Systems with already equipped SIM-cards, which are providerindependent and dial-in into the best available mobile network at users' location. The region (Europe, North America, Asia, ...) is selectable by the customer. The fee of the SIM-cards is part of a service-contract or directly bookable with ANavS. The following settings are needed for the SIMs:

- APN: em
- Dial-Up Number: T\*99#



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

Own SIM-cards can also be used. With the 3D printed casing, the user can exchange the SIMcard without any help and extra cost. With the industrial casing, the user must send the SIM card to ANavS before delivering the Positioning System. If it has to be done afterwards, ANavS reserves the right to charge for the replacement.

In case of using an own SIM-card, please change the settings here accordingly and click afterwards to the button "SEND CONFIG" to transmit the new settings to the MS-RTK module. In the next step, click "(RE-)START 4G" button. If all provided information for the SIM-card are correct and LTE-reception is available at your position, the field "4G Is Inactive" becomes "4G is Active" and the color turns from red to green.

The configuration is saved to enable an automatic re-connection with the mobile network after each reboot.

#### Wi-Fi Settings (obsolete):

The left section is showing the current Wi-Fi settings. The right section is for the Wi-Fi configuration. The Wi-Fi-module can be used in four different Modis.

#### • Access-Point (AP-STATIC Profile):

The standard/default way is the Access-Point (AP) profile. This means that the MS-RTK module is creating its own Wi-Fi-network with the SSID "ANAVS\_MSRTK\_AP" with password "anavsrtk" and static IP 192.168.42.1. Please use this mode for your first steps to get familiar with the system.

#### • Client DHCP-Mode (CLI-DHCP Profile):

With this selected profile, the MS-RTK module tries to connect to an existing Wi-Fi network with a running DCHP-server running on it. To give the information to the MSRTK module, please use the "**SCAN**" Button and select the suitable SSID from the dropdown-list. After this, please define the Password in the dialog-window, activate the "**ADD**" radio button and click "**APPLY NEW CONFIGURATION**". It is possible to define a lot of known Wi-Fi-networks. But take care, you must know the assigned IPaddress to your MSRTK module in your network to be able to communicate with the ANavS<sup>®</sup> Wizard to the MSRTK module. The new IP must be signed in the message box by clicking on the "Settings"-button in the bottom left corner. A detailed description of how to find the IP-address of your MSRTK module is described in the ANavS knowledge base "Using the IP scanning-tool NMAP" <sup>4</sup>. Another knowledge base

<sup>&</sup>lt;sup>4</sup> Using the IP scanning-tool NMAP: <u>https://anavs.com/knowledgebase/using-the-ip-scanning-tool-nmap/</u>



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

article is explaining how to broadcast RTK-Data from your ANavS RTK reference station directly via Wi-Fi to your MS-RTK module <sup>5</sup>.

- Client Static-Mode (CLI-STATIC Profile): With this selected profile, the MS-RTK module tries to connect to an existing Wi-Fi network without a running DCHP-server running on it. The procedure for configuration is the same as for the CLI-DHCP profile.
- Powered-Off Wi-Fi module (OFF Profile):
   Use this mode to save power consumption or to reduce traffic in the Wi-Fi frequency range. BUT NOT RECOMMENDED.

#### Ethernet Settings:

The left section is showing the current Ethernet settings. The right section is for the Ethernet configuration. The Ethernet module can be used in three different Modis.

• DHCP-Mode (DHCP Profile):

With this default setting, the Ethernet port is waiting to get an IP address of a DHCP server (e.g., from a router). After connecting the MS-RTK module via Ethernet cable with a router/DHCP-server, you can identify the MSRTK modules IP-address via the Ethernet information section in the Wizard window, the dashboard of your router or scanning the network as explained in the knowledge base article "Using the IP scanning-tool NMAP".

### Static-Mode (STATIC Profile): Another option is to set a static IP for the MSRTK module and directly connect it with another device or laptop with same static IP range address.

Powered-Off Ethernet port (OFF Profile):
 Use this mode to save power consumption. BUT NOT RECOMMENDED.

#### 3.3.3. Wizard Step-3

The next step proves the GNSS antenna connection. The user can only go forwards if it matches in a proper way.

The following circumstances would prevent a successful GNSS-antenna connection:

 Failure in Antenna-Status: The positioning system need only some more boot-time for the OS and some time for gather satellite information (30 – 90sec).

<sup>&</sup>lt;sup>5</sup> Broadcasting RTCM-Data for MSRTK Modules: <u>https://anavs.com/knowledgebase/publishing-rtcm-data-for-msrtk-modules/</u>



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

- Failure in Antenna-Status: If the antenna-Status problem stays the same after some retries, to long antenna cables could lead to a missing recognition of the antenna from the GNSS-receiver side. The text field "Antenna-Status" shows ERROR or SHORT in that case.
- No Data received/ No Satellites visible: Please check this step with GNSS antennas outdoor.

🔷 ANavS RTK-Wiza	ard					– 🗆 X
<	ANAV	<b>3</b> <sup>rd</sup> S	TEP: F	TCM Anten	na Connection	
Proving	Data-Transmis	sion				
Please be of for streaming	connected per WiFi/ ng sensor-data to ca	Ethernet with alibrate your o	your RTCI	M Basestation tion.		
						>
	Serial-Number:	Stream:	Input-Type:	Data-Received:	Satellites-Visible:	
	Designator: GNSS1	Input-Format:	PAD-ID: 1	Antenna-Status: OK	rue	
Setti	ngs 🗂 Outp	ut			RTCM Wizard-Version: 7.2.1   RTCM-Station: TCP-Conn OK (Nav-	-Temperature: 52.10° PAD-Version: 5.1.264 Mode: RTCM_NTRIP)

Figure 32: Step-3, Proving GNSS antenna connection

#### 3.3.4. Wizard Step-4

The user has two options for calibrating the stationary position of the RTK/RTCM Reference Station:

External RTK correction data: Use this option to calibrate your Reference Station with centimeter-accurate position. To do this, the user needs an external RTK correction input-stream from an appropriate correction-data service-provider with centimeter accuracy (e.g., SAPOS, Axio-Net). Depending on your service-level, ANavS<sup>®</sup> can do this also for you. The advantage of this mode is a precise relative and absolute position estimation of your rover equipped with MS-RTK module and its tightly coupled ANavS<sup>®</sup> sensor fusion framework.



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

**NOTE:** To stream the correction data from external service provider, your RTK Reference Station needs internet access (e.g., through the integrated mobile network module or ethernet connection to a router).

 Filtered Least-Squares Position-Solution: This is the standard way to calibrate a rough position estimation for the Reference Station. The user can do this without the need of additional services. It has no influence on the accuracy of the relative position-solution between rover (MS-RTK module) and Reference Station, but the absolute position includes a position-offset depending on the accuracy of the position of the RTCM base station.

◆ ANavS RTK-Wizard —		$\times$
4 <sup>th</sup> STEP: Select Mode for calibrating RTCM Base Station		
Getting external RTK correction data		
Select this mode for streaming external RTK correction data to reach highest absolute accuracy for your RTCM Basestation		
Please define external RTCM Input-Stream:		
<usemame>:<passwort>@<ip-adress>:<portnumber>/<mointpoint></mointpoint></portnumber></ip-adress></passwort></usemame>		
Filtered Least-Squares Position-Solution		
Select this mode if you have no external RTK correction data. Taking a long-time filtered Least-Squares position as rough RTCM Basestation position. Requirements: Open-Sky and long-time filtering.	,	>
RTCM-Ten	perature	: 51.50°
Settings Output Wizard-Version: 7.2.1   PAD RTCM-Station: TCP-Conn OK (Nav-Mode	Version: : RTCM_	5.1.264 NTRIP)

Figure 33: Step-4, select the mode for RTK/RTCM Reference Station position calibration

#### 3.3.5. Wizard Step-5

Figure 34 shows Step-5 of the ANavS<sup>®</sup> Wizard for Reference Station calibration. Hereby, the user can define the error-bound which must be reached and the time for averaging after being below this defined error-bound. After attaining the limits, the calibration stops, and the position is stored permanently on the Reference Station (also after reboot of the system).



#### Multi-Sensor RTK Module, RTK Reference Station and ISP

3. Getting Started with the RTK/RTCM Reference Station

ANavS RTK-Wizard	- D X
< 5 <sup>th</sup> STEP: Starting Calil	pration of ANavS RTCM-Station
Calibrate RTCM-Station Save raw-data Time of Averaging [sec]: 30 Error-Level-Bound [m]: 5 Customer-Code: 0	
Settings	RTCM-Temperature: 52.10 Wizard-Version: 7.2.1   PAD-Version: 5.1.26

Figure 34: Step-5, Starting calibration process of Reference Station

#### 3.4. Receiving RTCM-Messages from the RTK/RTCM Reference Station

The Reference Station provides an NTRIP-Server which converts the GNSS data into the standardized RTCM 3.2 Format and connects either to a local NTRIP-caster (on the Reference Station itself) or to a cloud-based NTRIP-caster, hosted by ANavS (without fee). To receive this RTK correction data from your Reference Station one could use the own local network or the ANavS cloud-based correction data service via internet-connection.

An example of a defined RTK correction data stream with the ANavS cloud-based correction data service is:

Username:	RTCM_User
Password:	anavs123
IP/URL:	customer-specific; info is included in the system delivery
Port:	customer-specific; info is included in the system delivery
Mountpoint:	ANAVS

This results in the following NTRIP input stream for your MS-RTK module or ISP: RTCM\_User:anavs123@<customer-specific-IP>:<customer-specific-Port>/ANAVS



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

The default setting of the Reference Station is using the cloud-based NTRIP-Caster, which ensures the usability independent of any company's network policy (e.g., port-forwarding). The local NTRIP-caster setup is activatable via the global settings file, described in the following subsections.

Message-Type	RTCM 3.2	Description
1005	10s	ARP-Station coordinates, ECEF XYZ
1008	10s	Antenna-Type of the RTK Reference Station
1033	10s	Receiver- und Antenna-Type
1077	1s	GPS Observation data (MSM7)
1085	1s	GLONASS Observation data (MSM7)
1095	1s	Galileo Observation data (MSM7)
1125	1s	BeiDou Observation data (MSM7)
1230	10s	GLONASS L1 and L2 Code-Phase Biases

The used RTCM 3.2<sup>6</sup> messages are the following:

Other RTCM messages or other time-intervals are adjustable via the global configuration file *<home/user>/device/settings* on the Reference Station.

The **Range** of the ANavS Reference Stations are only limited by (mobile) network connection and the useful distance of RTK corrections from Reference Station to the rover (MS-RTK module or ISP), which is ~20 km.

# 3.4.1. Broadcasting RTCM-Data via NTRIP-Caster hosted by ANavS cloud service

It's the most comfortable way to broadcast and reach correction data over the internet (Ethernet, Wi-Fi, or mobile network) and the recommendation to bring the users RTK setupup working. The RTK correction data is transmitted over internet-access to the ANavS cloud service with a running NTRIP-Caster and broadcasted on a specific IP-address and portnumber.

The individual information, IP-address and port-number, is included in the delivered package and defined in the global customer settings file **/home/pi/device/settings** as follows:

<sup>&</sup>lt;sup>6</sup> The Radio Technical Commission for Maritime Services (RTCM) is a US organization. Among other things, it pursues the goal of realizing internationally standardized data formats for the transmission of corrections for GNSS applications and making correction data available in real time.



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

RTCM.caster.host=<customer-specific-IP-Address>

RTCM.port=<customer-specific-Port>

To edit this file, please connect per SSH to the Reference Station. For the SSH-credentials, please ask the support.

#### 3.4.2. Broadcasting RTCM-Data via local NTRIP-Caster

The following description shows broadcasting RTK correction data in a local network or via internet-access via a local NTRIP caster, running on the Reference Station. For receiving the RTK correction data, which are mandatory for RTK-Positioning, the RTCM station must be reachable via TCP/IP for the MS-RTK module or ISP.

#### Step 1:

Comment out (#) the following line in the global settings file /home/pi/device/settings:#RTCM.caster.host=<customer-specific-IP-Address>#RTCM.port=<customer-specific-Port>

To edit this file, please connect per SSH to the Reference Station. For the SSH-credentials, please ask the support.

#### Step 2:

Connect the Reference Station with a router via ethernet cable or Wi-Fi. A DHCP-server running on the router is mandatory. To get correction data outside or inside of this network, the user must follow the next mandatory steps.

#### Step 3:

First of all, the user needs the IP address of the Reference Station in the local network of the router. The user has the following options: either discover the IP address by connecting to the router (usually by typing <a href="http://192.168.1.1">http://192.168.0.1</a> in the web browser), then look for a device named "ANavS XXX", or you use network discover software like Nmap. More details on this can be found in the article <a href="https://using.to.using

**Step 4:** In case of using the Reference Station from outside of the local network, the IPaddress of the router is needed. The easiest way to do this is to call the page <u>https://www.outsideopen.com/ip/</u> within user's local network. The shown numbers are your public IP address. This public IP address is managed from the users Internet Service Providers. Some providers do not provide with a static IP address, but rather change it usually in a 24h time window. If this is the case, the user will need to set up a <u>Dynamic DNS</u> <u>service</u> that keeps track of the external IP changes. Please refer to your network administrator to know the policy regarding the external IP address.



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

**Step 5:** Assuming to have an external IP address set up correctly, the user must configure the router to enable port forwarding. Port forwarding maps requests coming from outside the network at a specific port number to a local IP address from within the local network at a second port number. Therefore, in other words, it redirects the traffic from outside to a specific device inside the local network.

The following example shows the rerouting of correction-data of the Reference Station to an arbitrary Port of the router:

External IP address of the router	external port No.	Local IP address of the Pi	Internal port No.
82.135.2.37	2101	192.168.1.101	2101

In this example, the user configures the port forwarding to reroute the traffic coming from outside (landing so at the external IP of the router, namely 82.135.2.37) at port 2101 to the local IP of the Reference Station (192.168.1.101) at port 2101. Note that choosing external port 2101 is arbitrary (is always best practice not to choose a port that is a <u>well known port</u>). Having the router's port forwarding set up as in the above example, to connect to the Reference Station from outside the local network just configure the RTCM stream on the MS-RTK module or ISP with IP 82.135.2.37 and with port 2101. The traffic will be automatically rerouted to 192.168.1.101 at port 2101 in your local network.

#### IMPORTANT

The internal port number is not changeable and always **2101**.

In case of a local network without port-forwarding, this results in the following NTRIP input stream for the MS-RTK module or ISP:

RTCM\_User: anavs123@<Local-IP-of-RTCM-station>:2101/ANAVS

In case of port forwarding, the NTRIP input stream for the MS-RTK module or ISP needs the external port number as configured in the router-settings and the external IP-Address of the router. Following an example for this:

RTCM\_User: anavs123@<External-IP-address-of-the-router>:<External-Port-No>/ANAVS



Multi-Sensor RTK Module, RTK Reference Station and ISP 3. Getting Started with the RTK/RTCM Reference Station

### 3.5. The ANavS®-Wizard to Update the RTK/RTCM Reference Station

The ANavS<sup>®</sup> Wizard can also be used for updating the Reference Station. Trying this, the user must provide internet access to the station. The default way would be through the mobile network or through Ethernet with a connection to a router. The first step in the Wizard is selecting the option "Update your ANavS-Module (...)" on the starting page.

The next window is showed in Figure 35. The user has two options with the **Online-Updater**. Selecting the button "Stable Update", the user updates the Reference Station (and also the MS-RTK module) with the latest stable version on the ANavS repository. It is well tested but is not including all recent minor updates and sensor fusion improvements. Selecting the button "Beta Update", the user updates the Reference Station (and also the MS-RTK module) with the latest stable version. It is less tested but is including all recent minor updates the Reference Station (and also the MS-RTK module) with the latest Beta version on the ANavS repository. It is less tested but is including all recent minor updates and sensor fusion improvements.

In case of problems with getting internet access to the Reference Station, ANavS is also providing an **Offline-Updater**. Using this option, please contact the support to get the recent Update-Zip, load it in the Wizard (do NOT unzip this file) with the SEARCH button and click the update-button.

ANavS RTK-Wizard			– 🗆 X
<	2nd ST	EP: Update your ANavS Devices	
Online-Updat	er to the latest STAB	LE or BETA Release:	
Please be connected deviationaly, the N	ted per WiFi/Ethernet with lodules need Internet-Conn ices (MSRTK and/or RTCN	your ANavS-Modules. ection to reach the ANavS Update-Server. I Basestation) will be updated.	
STABLE Update:	Feedback of Update-Process:		
$\bigcirc$			
BETA Update:			
$\bigcirc$			
Offline-Upda	er to the latest STAB	LE or BETA Release:	
In case of proble please contact th and load in the fo	ns with the Online-Updater, e ANavS-Support (support@ rm below	⊉anavs.de) for the offline zip-file	
Settings	Output	Wizard-Vers MSRTK: TCP-Cor RTCM-Station: TCP-Co	ion: 7.2.1   PAD-Version: 5.2.150 in OK (Nav-Mode: UNMANAGED) in OK (Nav-Mode: RTCM_NTRIP)

Figure 35: Update of the RTK/RTCM Reference Station with the ANavS Wizard



**Multi-Sensor RTK Module, RTK Reference Station and ISP** 4. Getting Started with the Integrated-Sensor-Platform (ISP)

### 4. Getting Started with the Integrated-Sensor-Platform (ISP)

This guide is intended for first time ISP users and provides an overview of how to handle with the required software, connect to and configure the ISP.



Figure 36: The Integrated-Sensor-Platform (ISP)

### 4.1. General

The Integrated Sensor Platform (ISP) is a hardware basis for easy integration of a large variety of sensors without any effort. It comes with a standard configuration of three GNSS receivers and integrated antennas, an industrial-grade inertial measurement unit (IMU), a CAN interface for wheel odometry data and a barometer. On top of the standard sensors a fully integrated computer vision module is equipped, that can be flexibly configured with two cameras and/or a 3D-LiDAR.

The camera only configuration includes a high-quality, high frame-rate global shutter monocular HD camera and a global shutter stereo camera with either fisheye objective or depth sensing capabilities.

The LiDAR only configuration includes a high-quality 3D-LiDAR for 360° sensing. On the one hand, both the camera sensors and the LiDAR sensor provide an additional odometry or positioning information through visual-inertial odometry or Simultaneous Localization and Mapping (SLAM). On the other hand, 2D and 3D maps of the environment or road can be generated. Furthermore, semantic segmentation enabled by deep learning algorithms allows to add semantic information to the maps and further enhances the SLAM performance.

The additional positioning information obtained from the computer vision module is coupled with GNSS, IMU and wheel odometry information in the ANavS<sup>®</sup> Sensor Fusion. This leads to an improved positioning accuracy to overcome also the most challenging environments.



Multi-Sensor RTK Module, RTK Reference Station and ISP 4. Getting Started with the Integrated-Sensor-Platform (ISP)

### 4.2.The ISP Setup

The ISP consists of the following modules and components:

- Multi-Sensor Fusion System (MS-RTK System Inside):
  - 3x Multi-GNSS, Multi-Frequency Receivers
  - 3x High-Class, Survey-Grade, Triple-Frequency GNSS Antennas
  - High-grade MEMS IMU
  - Barometer
- Computer Vision Module
  - Camera sensors:
    - Industrial high-grade global shutter RGB camera (FLIR Grasshopper3)
    - Stereo camera with integrated IMU (<u>Intel Realsense D435i</u>)
  - Lidar sensor (<u>Velodyne Puck/ VLP16</u>)
  - \*Embedded platform for GPU accelerated sensor data processing (<u>NVIDIA</u> <u>Jetson Xavier NX Developer Kit</u>)

In the following referred to as Vision Processing Unit (VPU)

\*Data storage: Integrated 2TB M.2 NVMe SSD

\*) Optionally two embedded platforms can be integrated (each with integrated data storage).

#### • Interfaces

• Ethernet, WLAN, CAN, USB, LTE

The ISP is ready to use out-of-the-box. With its vacuum cups (suction cups, Figure 37) it can safely be mounted for any kind of automotive dynamics. Pump the plunger a few times until the suction cup is completely fixed with the surface of mounting. When the red line has faded out, the vacuum is sufficient for lifting. A firm push or pull on the tab on the edge of the cup can loosen the holder. A suction cup protector prevents damage.



#### Multi-Sensor RTK Module, RTK Reference Station and ISP

4. Getting Started with the Integrated-Sensor-Platform (ISP)



#### Figure 37: The ISP can be mounted with its three suction cups on all smooth, non-porous surfaces

### 4.3. The Basic-Configuration: GNSS, IMU and Odometry Sensor Fusion

The basic configuration with a tightly coupled sensor fusion of three GNSS receivers, an IMU and Odometry sensor data on the ISP corresponds to the description and handling of the MS-RTK module. Please follow the instructions in chapter 2.

A major advantage of the ISP is the fixed lever arms of the system and of each sensor. Corresponding to this, please use the following dimensions in Step-5 in the ANavS<sup>®</sup> Wizard Software (see section 2.7.5).

GNSS-Antenna-1 [m]:	X= 0.0	Y= 0.0	Z= 0.0
GNSS-Antenna-2 [m]:	X= 0.708	Y= -0.39	Z= 0.0
GNSS-Antenna-3 [m]:	X= 0.708	Y= 0.39	Z= 0.0
IMU [m]:	X=0.493	Y=0.017	Z= 0.106

All dimensions belong to the body frame. The movement-direction is assigned to the field-ofview of the cameras. The GNSS-Antenna-1 is the rear one, GNSS-Antenna-2 is the right one and GNSS-Antenna-3 the left one.

#### 4.3.1. The ANavS<sup>®</sup>-Wizard to Update the ISP Basic-Configuration

Please follow the instructions in section 2.8 for updating the ISP regarding the GNSS/IMU/Odometry sensor fusion.



**Multi-Sensor RTK Module, RTK Reference Station and ISP** 4. Getting Started with the Integrated-Sensor-Platform (ISP)

### 4.4. The Computer-Vision Operation-Modes

The Computer Vision module offers a data acquisition mode and can be extended by customer or application specific algorithms that run on the VPU, such as object detection or SLAM.

#### 4.4.1. Prerequisites

For basic operation any operating system with installed terminal application supporting SSH is suitable.

For live visualization of sensor data on a client an operating system that supports ROS is required, for example a Linux Operating System (tested with Ubuntu 18.04, Ubuntu 20.04) and a ROS environment that supports ROS1 or ROS2 (tested with ROS Melodic, ROS Noetic).

#### 4.4.2. Setup

Connecting to the ISP and login to the VPU:

You can connect via Ethernet, or WLAN. For transferring huge data or visualization of live camera or Lidar data on a client an Ethernet connection is recommended. Ethernet provides a direct Gigabit connection to the VPU. WLAN only provides indirect access to the VPU, but it is sufficient for executing commands.

The VPU may distribute processing onto two embedded GPU platforms/ Jetson Xavier NX devices, termed Master NX (IP address: 192.168.1.101) and Slave NX (IP address: 192.168.1.102). However, to operate the VPU, you only need to connect to the Master NX.

1. Ethernet

Connect your host to the ISP via Ethernet. You need to set a static IP in the domain 192.168.1.xxx, e.g.: 192.168.1.210. (Do not use these reserved IP addresses: 192.168.1.100, 192.168.1.101, 192.168.1.201, for setup with two embedded GPU platforms: 192.168.1.102)

Add the following line to /etc/hosts:

192.168.1.101 <Master-NX-host-name>

The Master NX host name is usually set to: ubuntu

Directly login to the VPU using SSH (Password: *anavsisp*):

ssh <u>anavs@192.168.1.101</u>



Multi-Sensor RTK Module, RTK Reference Station and ISP 4. Getting Started with the Integrated-Sensor-Platform (ISP)

#### 2. WLAN

Connect to the ISP WiFi Access Point *ANAVS\_ISP\_XXX* (Password: *anavsrtk*). Indirectly login to the VPU using SSH:

- 1. ssh pi@192.168.42.1 # login to the Multi-Sensor Fusion
   System

Before proceeding with the following operation modes make sure the ISP has good satellite view, LTE reception is available and the system is powered on already for some minutes, to ensure completion of MS-RTK system startup including services and internal time-synchronization. Furthermore, configure and start the sensor fusion (described in section 4.3). Starting the sensor fusion is optional if only camera and Lidar sensor data shall be acquired.

#### 4.4.3. Data Acquisition Mode

The Data Acquisition Mode is the basic operation mode that runs the sensor nodes for the cameras and the Lidar sensor and provides sensor data ROS messages. The sensor data consists of RGB imagery, grayscale stereo imagery, Lidar data and IMU data and can be recorded using the rosbag tool. Embedded GPU platform system time is synchronized to the MS-RTK system time. In addition, a ROS wrapper provides the Multi-Sensor Fusion System Solution in ROS. All ROS messages are provided in ROS1 and ROS2, a ROS bridge converts all ROS1 messages to ROS2

- 1. Login to the VPU using SSH (as described above under Setup)
- 2. Start the VPU components consisting of ROS master, sensor ROS nodes and the ROS recorder:

start\_vpu

To get an overview over optional command line arguments:

start\_vpu --help

Optionally disable verification of NTP time-synchronization

(to the Multi-Sensor Fusion System):

start\_vpu --no\_ntp\_sync

Enable recording of ROS topics to bag files:

start\_vpu --record



**Multi-Sensor RTK Module, RTK Reference Station and ISP** 4. Getting Started with the Integrated-Sensor-Platform (ISP)

To enable bridge communication between ROS1 and ROS2:

start\_vpu --enable\_ros\_bridge

To enable object detection container:

start\_vpu --object\_detection

To run only specific VPU sensor containers:

e.g.:

start\_vpu --sensors "d435i gh3"

Available VPU components are listed below:

ROS Node	Sensors/ Algorithm	Component Name
ROS Master		ros_master
Industrial RGB Camera ROS Wrapper	FLIR Grasshopper3 USB3	gh3
Stereo Camera ROS Wrapper	Intel Realsense D435i	<u>d435i</u>
Lidar Sensor ROS Wrapper	Velodyne Puck/ VLP16	vlp16
Multi-Sensor Fusion System Solution	Multi-GNSS, Inertial Sensor	pad2ros
ROS Wrapper <sup>7</sup>	based Sensor Fusion	
Rosbag Recorder		ros_recorder
Ros Bridge		ros_bridge
Optional Components:		
Object Detection	2D Object Detection	object_detection

By default, all standard components listed in the table above (except ros\_recorder) are launched when executing the start\_vpu script.

#### Available ROS topics are listed below:

ROS Topic	Description	ROS Message Type
/camera/image_raw	Raw camera image of the industrial RGB camera.	sensor_msgs/Image
/d435i/infra1/image_rect_raw	Raw camera image 1 of the stereo camera.	sensor_msgs/Image

<sup>&</sup>lt;sup>7</sup> The VPU provides a ROS Wrapper for the Multi-Sensor Fusion System Solution. Running the component pad2ros will publish an available solution in ROS.



Multi-Sensor RTK Module, RTK Reference Station and ISP

4. Getting Started with the Integrated-Sensor-Platform (ISP)

/d435i/infra2/image_rect_raw	Raw camera image 2 of	sensor_msgs/Image
	the stereo camera.	
/d435i/imu	IMU data from stereo	sensor_msgs/Imu
	camera.	
/velodyne_packets	Lidar raw data	velodyne_msgs/VelodyneScan
/anavs/solution/*	ROS messages provided by the ROS wrapper for the Multi- Sensor Fusion System Solution. More details including a list	
	Ethorpot Adaptor (REA)	In chapter 10, Anavs ROS-
	Ethemet-Adapter (REA).	
Optional Components:		
Object detection ROS topic specifications see separate section below.		

The topics listed above are recorded by the rosbag recorder by default, if recording is enabled. In addition to these, more topics are available that are advertise by the different nodes. Furthermore, additional components provide specific ROS topics. These are listed in the algorithm specific sections in the following.

3. There are two contexts, i.e., two docker nodes running on different hosts.

The command docker context ls lists all available contexts and marks the current context with an asterisk.

The context default corresponds to the Master NX, the context slave\_nx corresponds to the Slave NX.

To change the context, use the following command:

docker use <context\_name>

4. To show log messages coming from all containers running on the Master or Slave NX run

```
vpu_master_logs
```

or

```
vpu_slave_logs
```

respectively.

5. Visualizing sensor data locally on your host



**Multi-Sensor RTK Module, RTK Reference Station and ISP** 4. Getting Started with the Integrated-Sensor-Platform (ISP)

```
export ROS_MASTER_URI=http://192.168.1.101:11311
```

export ROS\_IP=<your-host-IP>

rosrun rviz rviz -f velodyne # for visualizing lidar data

Note: For accessing ROS messages on your host adjusting */etc/hosts* is required.

6. Data recording in ROS

Sensor data is recorded in rosbag files that are stored in the folder:

~/vpu/data

#### The file naming convention is:

isp\_recording\_<year>\_<month>\_<day>\_<h>\_<min>\_<sec>\_<split\_index>.bag

Rosbag files are automatically split after 30 minutes of recording time to prevent dealing with huge files. Further, LZ4 compression is used, to reduce file sizes.

#### Time stamping:

Recorded ROS messages are timestamped using the VPU system time which is timesynchronized to the Multi-Sensor Fusion System and is based on the UTC time. This requires on the one hand GNSS satellite view, or LTE reception, and on the other hand an adequate NTP-time synchronization offset toward the MS-RTK system. Enable verification of NTP-time synchronization to guarantee a specified time offset when starting data acquisition. Without GNSS satellite view or LTE reception only a local time can be provided.

ROS message timestamps can be converted from UTC time to GPS time of weeks in post-processing.

NTP time-synchronization offsets are logged automatically to *data/logs/ntp\_log.txt*. In a setup with two embedded GPU platforms the NTP offset of the second device is logged to *data/logs/ntp\_log\_slave.txt*.

7. Stop the VPU

stop\_vpu

8. Copying recorded data



Multi-Sensor RTK Module, RTK Reference Station and ISP 4. Getting Started with the Integrated-Sensor-Platform (ISP)

Recorded data can be copied to your host using an FTP client or using SCP. An Ethernet connection is recommended. Copying via SCP:

scp anavs@192.168.1.101:/home/anavs/vpu/data/ <destination-folder>

#### 4.4.4. Object Detection

The object detection component performs real-time 2D object detection using live camera data from the monocular RGB camera. The output is 2D bounding boxes with detection confidences. Object detection output is provided in the ANavS GUI and in ROS. **Note:** For visualizing object detections in the ANavS GUI an Ethernet connection to the ISP is required.

#### ANavS GUI

Object detections are visualized in the Sensors/Camera tab. Bounding boxes and detection confidences are visualized in the live camera image:



#### ROS

Object detections are provided as an object list using the type

derived\_object\_msgs/ObjectArray. The camera image with visualized bounding boxes is provided as CompressedImage:

ROS Topic	Description	ROS Message Type



Multi-Sensor RTK Module, RTK Reference Station and ISP

4. Getting Started with the Integrated-Sensor-Platform (ISP)

/bounding_boxes/array	Object detections list	derived_object_msgs/ObjectArray
/bounding_boxes/compressed	Camera image with object detection bounding boxes	sensor_msgs/CompressedImage

#### **Object Detection Model**

An initial pretrained model for the detection of cars, busses, trucks, motorbikes, bicycles, pedestrians, bicyclists and motorcyclists is available. Object detection can be tailored to fit customer specific needs.

#### 4.4.5. Troubleshooting

• No internet connection on the VPU system:

The VPU system is not connected to the internet by default. If you require an internet connection, you may switch from static to DHCP network setting to obtain connection via an external router. To do so modify the following line in /etc/network/interfaces

- from: source interfaces.d/eth0\_static
- to: source interfaces.d/eth0
- Issues with Intel Realsense camera device: The camera device resource may still be blocked by previous access. Reboot the VPU, or power off and power on the ISP to release the camera device resource.
- NTP offset not available (VPU error: *Command '['./scripts/get\_ntp\_offset.sh']'* returned non-zero exit status 1)

The NTP offset may not be retrieved if the NTP daemon on the MS-RTK module is not active, which will result in a failure of the start\_vpu script. To resolve this issue:

- make sure satellites are visible or LTE reception is available and wait some minutes after system power on before starting the VPU
- reboot the Jetson Xavier NX
- NTP offset does not decrease after waiting some time:
  - increase the NTP offset threshold when starting the vpu\_start script using the --max\_ntp\_offset parameter, to allow for a larger offset
  - restart the ntp service: sudo service ntp restart



Multi-Sensor RTK Module, RTK Reference Station and ISP

4. Getting Started with the Integrated-Sensor-Platform (ISP)



Multi-Sensor RTK Module, RTK Reference Station and ISP 5. The Command Line API Reference Guide

### 5. The Command Line API Reference Guide

All ANavS Positioning Systems provide an API used by command line. The API is directly used on the modules through the SSH-access or via an external client on your Laptop/PC using a TCP/IP connection. Please ask the support-team for access to this functionality. The following sections describes the most important commands for customers. An autocomplete is available.

A detailed description of each command is also available via command-line:

#### MSRTKF help -search <command>

### 5.1. Navigation commands

This section describes the commands regarding the navigation software. With these commands, the user can control the ANavS Systems without using the Wizard Software. Each API command needs the preamble *MSRTKF* (Example: *MSRTKF Navigation.attach*).

Command	Description	
Navigation.attach	Prints the sensor fusion software trace into the command line.	
Navigation.configNtripPolicy	Navigation.configNtripPolicy	
	Get the currently configured policy.	
	Navigation.configNtripPolicy -set SET	
	Set the policy.	
	SET In OFF mode, NTRIP is deactivated. In AUTO mode, NTRIP is	
	automatically enabled when the navigation software starts and disabled	
	when it stopsset SET is mandatory. Allowed values for SET are AUTO,	
	OFF.	
Navigation.getLatency	Prints the current solution latency	
Navigation.getMode	Prints the current Navigation mode	
Navigation.setMode	Navigation.setMode -mode MODE -temp TEMP	
	Set navigation mode.	
	MODE Navigation mode to setmode MODE is mandatory. Allowed	
	values for MODE are: UNMANAGED, PAD_1D_RICM, PAD_2D_RICM,	
	PAD_3D_RTCM, RTCM_NTRIP, RTCM_MOSAIC, PPP_RT.	
	The modes DAD 1D PTCM DAD 2D PTCM DAD 2D PTCM launches the	
	sensor fusion software with 1-Antenna/2-Antenna/2-Antenna PTCM	
	mode. Automatic start and restart are enabled	
	The mode <b>LINMANAGED</b> deactivates the sensor fusion again	
	The modes <b>RTCM_NTRIP_RTCM_MOSAIC</b> launches the RTCM_NTRIP-	
	server/caster software. Automatic start and restart enabled	
	<b>TEMP</b> Set mode only temporary. The change is not saved persistent	
	temp TEMP is optional. Allowed values for TEMP are: true, false.	



#### Multi-Sensor RTK Module, RTK Reference Station and ISP

5. The Command Line API Reference Guide

	Enables/Disables the navigation mode.
Navigation.getState	The navigation software is monitored by the firmware of the positioning
	systems. The user gets one of these responses:
	<b>UNMANAGED:</b> Binaries are not currently running and are not scheduled to start.
	DELAY: Selected binaries are scheduled to start soon (boot delay).
	<b>STARTUP_WAIT:</b> Selected binaries have been started but have not been verified to be functional (startup period).
	<b>RECOVER_WAIT:</b> The selected binaries are up and have already been verified to be functional, however currently there is a problem. We have started a timer for the problem to disappear before up opfered a module
	restart.
	<b>NOMINAL:</b> The selected binaries are up and have been verified to be
	functional, moreover there is currently no indication of a problem with
	the navigation binaries.
	UNKNOWN: I here is currently no information on the state of the
Navigation.restart	Restart the currently active navigation software.
Navigation.PAD.config.generate	Description follows in next version.
Navigation.PAD.config.get	Description follows in next version.
Navigation.PAD.config.reload	Description follows in next version.
Navigation.PAD.config.set	Navigation.PAD.config.set -rfile RFILE
	Upload a PAD configuration resource.
	<b>RFILE</b> Resource that will be used as config filerfile RFILE is mandatory.
Navigation.PAD.properties	Because of the large amount of text, please have a look for the
	description of this command via command line:
	MSRTKF help -search Navigation.PAD.properties
Navigation.RTCM.calibrate	Description follows in next version.
Navigation.RTCM.config	Navigation.RTCM.config -host HOST -port PORT
	Set parameters for NTRIP-caster in an RTCM station.
	HUST HOST OF THE NIRIP casterhost HUST is optional.
	PORT PORT OF THE NERIP CASTER PORT PORT IS OPTIONAL

### 5.2. System commands

This section describes the system commands. Each API command needs the preamble **MSRTKF** (Example: **MSRTKF SYS.ping**).

Command	Description
SYS.acmInfo	SYS.acmInfo -mode MODE
	Print information of connected usb ACM devices.
	MODE Select a mode to list datamode MODE is optional. Allowed
	values for MODE are: acm, devices.
SYS.assertDevice	SYS.assertDevice -name NAME -t T
	Wait for a given time until the specified device becomes available.
	NAME Name of the devicename NAME is mandatory.

Reference Guide Document



Multi-Sensor RTK Module, RTK Reference Station and ISP

5. The Command Line API Reference Guide

	<b>T</b> is the maximum number of milliseconds to wait before aborting.
	Defaults to 1000t T is optional.
SYS.assertInterface	SYS.assertInterface -name NAME -t T -syslog SYSLOG
	Wait for an interface to become ready.
	NAME Name of the interfacename NAME is mandatory.
	<b>T</b> is the maximum number of milliseconds to wait. <b>-t T</b> is mandatory.
	SYSLOG is to optionally search the syslog for a message that the
	chatscript has failedsyslog SYSLOG is optional. Allowed values for
	SYSLOG are: true, false.
SYS.assertIP	Description follows in next version.
SYS.assertUsbDevice	SYS.assertUsbDevice -vendor VENDOR -prodid PRODID -t T
	Wait for a given time until the specified device becomes available.
	VENDOR Hex encoded vendorId of the devicevendor VENDOR is
	mandatory.
	PRODID Hex encoded productId of the deviceprodid PRODID is
	mandatory.
	T is the maximum number of milliseconds to wait before abortingt T
	is mandatory.
SYS.checklist	SYS.checklist -index INDEX -verbose VERBOSE
	Retrieve the text form of the checklist.
	INDEX Index of the checklist item to be displayedindex INDEX is
	optional.
	VERBOSE Set true to print the resultverbose VERBOSE is optional.
	Allowed values for VERBOSE are: true, false.
SYS.initNtp	Description follows in next version.
SYS.Memory.block	Description follows in next version.
SYS.Memory.info	Description follows in next version.
SYS.ping	Proving the current connection state
SYS.productName	SYS.productName -verbose VERBOSE
	Get the product name of the system.
	VERBOSE Print product nameverbose VERBOSE is optional. Allowed
	values for VERBOSE are: true, false.
SYS.restart	SYS.restart -mode MODE
	Restart a component of the system.
	<b>MODE</b> Name of the restart-mode. <b>-mode MODE</b> is mandatory. Allowed
	values for MODE are: COMMAND_SERVER, DRIVER,
	POSITIONING_APPLICATION, MCU_REBOOT, MCU_RESET,
	SYSTEM_REBOOT.
	SYS.restart -mode MODE
	Restart a component of the system.
	MODE Number of the restart-modemode MODE is mandatory.
	Allowed values for MODE are: 0, 1, 2, 3, 4, 5.
SYS.serial	SYS.serial
	kead the system serial number.
	SVS sovial stream STDFAM
	STS.serial -stream STREAN
	Read the serial number of a stream.



Multi-Sensor RTK Module, RTK Reference Station and ISP

5. The Command Line API Reference Guide

	STREAM Index of the streamstream STREAM is mandatory. Allowed
	values for STREAM are: 1, 2, 3.
SYS.setting	Description follows in next version.
SYS.showInterfaces	Description follows in next version.
SYS.subscribe	SYS.subscribe -branch BRANCH
	Subscribe to an update channel.
	BRANCH Name of the update branchbranch BRANCH is mandatory.
	Allowed values for BRANCH are: mf-automotive-unstable, mf-
	automotive-stable.
	SYS.subscribe -branch BRANCH -unsafe UNSAFE
	Subscribe to an update channel.
	BRANCH Name of the update branchbranch BRANCH is mandatory.
	Allowed values for BRANCH are: mf-automotive-unstable, mf-
	automotive-stable, ms-ppp-debug, master, debug.
	UNSAFE Allow system to subscribe to unsafe update channels. Unsafe
	channels contain the latest code that currently undergoes internal
	testing. These channels make no guarantee to be functionalunsafe
	<b>UNSAFE</b> is mandatory. Allowed values for <b>UNSAFE</b> are: true.
SYS.temperature	To prove the current temperature of the MSRTK module
SYS.Thread.error	Description follows in next version.
SYS.throttled	To prove if the system is throttled due to under-voltage or over-
	temperature
SYS.update	SYS.update
	Install the latest update available through the currently selected branch
	(defined in the file /home/pi/device/settings)
SYS.updateDNS	Description follows in next version.

### 5.3. Role commands

This section describes the role commands. A role defines a specific customer or internal setup of the MS-RTK-System on a system level. Each API command needs the preamble **MSRTKF** (Example: **MSRTKF Role.get**).

Command	Description
Role.get	Role.get -silent SILENT Gets the currently fulfilled role of the system. SILENT Suppress readable outputsilent SILENT is optional. Allowed values for SILENT are: true, false.
	To get the current role of your MS-RTK module. The default role is MSRTK_WIZARD
Role.install	<b>Role.install -name NAME</b> Sets the currently fulfilled role of the system and stores role-specific information to /home/pi/device/settings.



Multi-Sensor RTK Module, RTK Reference Station and ISP

5. The Command Line API Reference Guide

NAME Name of the new rolename NAME is mandatory. Allowed values for NAME are: MSRTK_WIZARD, PAD_1D, PAD_2D, PAD_3D, RTCM, RTCM_MOSAIC, M_STAR, M_POINT, M_REFERENCE, LEGACY_REFERENCE, STIHL_IMOW, PPP_RT, PREAPARE_SHIPS.
To install a customer specific role, which was assigned to the user by the support. Don't use this command without any support!

### 5.4. CAN commands

This section describes the commands regarding the CAN-interface. The commands are described in more detail in chapter 8. Each API command needs the preamble *MSRTKF* (Example: *MSRTKF CAN.dbcc*).

Command	Description
CAN.config.reset	Description follows in next version.
CAN.config.solution	Because of the large amount of text, please have a look for the
	description of this command via command line:
	MSRTKF help -search CAN.config.solution
CAN.config.solution.list	CAN.config.solution.list -format FORMAT -onlyenabled ONLYENABLED -
	file FILE
	Display list of currently enabled and disabled CAN output signals with
	their current CAN-Ids.
	FORMAT Allows to select a plain list or dbcformat FORMAT is
	mandatory. Allowed values for FORMAT are: LIST, DBC.
	ONLYENABLED If set to true, only enabled messages are shown
	onlyenabled ONLYENABLED is optional. Allowed values for
	ONLYENABLED are: true, false.
	FILE Allows to select a plain list or dbcfile FILE is mandatory.
CAN.dbcc	CAN.dbcc -source SOURCE
	Analyze the loaded .dbc file with dbcc
	<b>SOURCE</b> Path of the .dbc file. Defaults to the currently loaded file.
	-source SOURCE is optional.
CAN.generateDecoder	CAN.generateDecoder
	Generate a dynamic decoder binary
CAN.getStatus	CAN.getStatus
	Get a description of the CAN status
	CAN.getStatus -item ITEM
	Show CAN odometry rates.
	ITEM Item to be displayeditem ITEM is mandatory. Allowed values for
	ITEM are: CAN_MESSAGE_RATE, DRIVER_SIGNAL_RATE,
	DRIVER_MEASUREMENT_RATE, PAD_PROCESSING_RATE, ALL.
CAN.hardwareFilter.config	CAN.hardwareFilter.config
	Automatically generate optimal CAN reception hardware filter settings.
	CAN.hardwareFilter.config -clear CLEAR



#### Multi-Sensor RTK Module, RTK Reference Station and ISP

5. The Command Line API Reference Guide

	Disable CAN reception hardware filter.
	CLEAR Instructs the command to disable the filterclear CLEAR is
	mandatory. Allowed values for CLEAR are: true.
CAN.loadDbc	CAN.loadDbc -rsource RSOURCE -encoding ENCODING
	Loads a .dbc file and tries to detect in a best-effort way if it really is a
	.dbc file.
	<b>RSOURCE</b> SOURCE is a resource name used to provide the file.
	-rsource RSOURCE is mandatory.
	<b>ENCODING</b> Name of the encoding. If the encoding is UTF-8 or ISO-8859-
	1 this can be omittedencoding ENCODING is optional.
	CAN.loadDbc -source SOURCE -encoding ENCODING
	Loads a .dbc file and tries to detect in a best-effort way if it really is a
	.dbc file.
	SOURCE SOURCE absolute path of the source filesource SOURCE is
	mandatory.
	ENCODING Name of the encoding. If the encoding is UTF-8 or ISO-8859-
	1 this can be omittedencoding ENCODING is optional.
CAN.signal	CAN.signal
	lists all available CAN signals.
	CAN.signal -find FIND
	Lists all available CAN signals that match the search pattern.
	FIND Search pattern. Accepts hex values for CAN-idfind FIND is
	mandatory.
	CAN.signal -map MAP -magn MAGN -sign SIGN
	Maps a CAN signal to the magnitude and signum channel of a sensor.
	MAP Sensor to be mappedmap MAP is mandatory. Allowed values for
	MAP are: FL, FR, RL, RR, STEER.
	MAGN Magnitude of the sensor value. Can be any character sequence
	that is part of the signal description. If your signal name is exactly
	contained in another signal name, use the fully qualified name as
	displayed by CAN.signalmagn MAGN is mandatory. Allowed values for
	MAGN are: .
	<b>SIGN</b> Signum of the sensor value. Can be any character sequence that is
	part of the signal description. Has to contain specifiers for enum values of
	positive and negative.
	Example: wheeldirFL,+=1,-=2 where wheeldirFL is the CAN signal search
	termsign SIGN is optional.
	CAN.signal -get GET -sup SUP
	Returns the mapping for given sensor.
	GET Sensor to be retrievedget GET is mandatory. Allowed values for
	GET are: FL, FR, RL, RR, STEER, ALL.
	SUP Suppress warning that signal cache will be rebuiltsup SUP is
	mandatory. Allowed values for <b>SUP</b> are: <b>true</b> , <b>false</b> .
	CAN.signal -clear CLEAR



Multi-Sensor RTK Module, RTK Reference Station and ISP

5. The Command Line API Reference Guide

Clears the mapping for given sensor.
CLEAR Sensor to be clearedclear CLEAR is mandatory. Allowed values
for CLEAR are: FL, FR, RL, RR, STEER, ALL.

#### 5.5. Driver commands

This section describes the driver commands. Each API command needs the preamble *MSRTKF* (Example: *MSRTKF Driver.config*).

Command	Description
Driver.checkInstallation	Driver.checkInstallation -source SOURCE
	Compare driver installation to an archive file.
	SOURCE Path of the installation archivesource SOURCE is optional.
Driver.config	Description follows in next version.
Driver.createArchive	Description follows in next version.
Driver.deployArchive	Driver.deployArchive -source SOURCE
	Deploy driver files from archive
	<b>SOURCE</b> Path to a local update archivesource SOURCE is optional.
Driver.installUpdate	Driver.installUpdate
	Install the last downloaded update archive. Most users will prefer
	SYS.update instead.
Driver.listInterfaces	Description follows in next version.
Driver.listMappings	Description follows in next version.
Driver.listPlugins	Description follows in next version.
Driver.reinit	Driver.reinit -reason REASON -dump DUMP
	Request to send a SIGINT to the driver
	<b>REASON</b> Log messagereason REASON is optional.
	DUMP Request to dump a stack trace. In some situations, a stack trace
	will be generated anywaydump DUMP is optional. Allowed values for
	DUMP are: true, false.
Driver.setNtripEnabled	Driver.setNtripEnabled -enabled ENABLED -pushconfig PUSHCONFIG
	Connect to driver to set state of NTIP plugin.
	ENABLED True to enable NTRIPenabled ENABLED is mandatory.
	Allowed values for ENABLED are: true, false.
	PUSHCONFIG True to also push NTRIP configurationpushconfig
	PUSHCONFIG is mandatory. Allowed values for PUSHCONFIG are: true,
	false.
Driver.start	Driver.start
	Start driver.
Driver.stop	Driver.stop
	Stop driver and guard.
Driver.version	Driver.version -silent SILENT -cached CACHED
	Show version of driver.
	SILENT Don't print the resultsilent SILENT is optional. Allowed values
	for SILENT are: true, false.
	CACHED Don't query the driver, use last responsecached CACHED is
	optional. Allowed values for <b>CACHED</b> are: <b>true</b> , <b>false</b> .



Multi-Sensor RTK Module, RTK Reference Station and ISP 5. The Command Line API Reference Guide

### 5.6. GNSS commands

This section describes the commands related to the GNSS receivers. Each API command needs the preamble *MSRTKF* (Example: *MSRTKF GNSS.config*).

Command	Description
GNSS.chat	GNSS.chat -path PATH -message MESSAGE
	Exchange data with a serial device. The command expects some answer
	data and prints it.
	PATH Path of the device. For example /dev/ttyACM0path PATH is
	mandatory.
	Allowed values for PATH are: /dev/ttyACM5, /dev/ttyACM4,
	/dev/ttyACM3, /dev/ttyACM2, /dev/ttyACM1, /dev/ttyACM0,
	/dev/ttyAMA0, /dev/ttyprintk, /dev/tty63, /dev/tty62, /dev/tty61,
	/dev/tty60, /dev/tty59, /dev/tty58, /dev/tty57, /dev/tty56, /dev/tty55,
	/dev/tty54, /dev/tty53, /dev/tty52, /dev/tty51, /dev/tty50, /dev/tty49,
	/dev/tty48, /dev/tty47, /dev/tty46, /dev/tty45, /dev/tty44, /dev/tty43,
	/dev/tty42, /dev/tty41, /dev/tty40, /dev/tty39, /dev/tty38, /dev/tty37,
	/dev/tty36, /dev/tty35, /dev/tty34, /dev/tty33, /dev/tty32, /dev/tty31,
	/dev/tty30, /dev/tty29, /dev/tty28, /dev/tty27, /dev/tty26, /dev/tty25,
	/dev/tty24, /dev/tty23, /dev/tty22, /dev/tty21, /dev/tty20, /dev/tty19,
	/dev/tty18, /dev/tty17, /dev/tty16, /dev/tty15, /dev/tty14, /dev/tty13,
	/dev/tty12, /dev/tty11, /dev/tty10, /dev/tty9, /dev/tty8, /dev/tty7,
	/dev/tty6, /dev/tty5, /dev/tty4, /dev/tty3, /dev/tty2, /dev/tty1, /dev/tty0,
	/dev/tty.
	MESSAGE Message to send. \r and \n will be changed to newline and
	carriage returnmessage MESSAGE is mandatory.
GNSS.config	GNSS.config
	Detect GNSS receiver presence and device. Send correct configuration to
	all detected devices.
GNSS.config.Mosaic	GNSS.config.Mosaic -nighrate HIGHRATE
	Detect Mosaic receivers and write the configuration
	HIGHRATE Set all messages to 100Hz if true, 5Hz otherwisenighrate
	HIGHRATE is optional. Allowed values for HIGHRATE are: true, taise.
GNSS.leapSeconds	Description follows in next version.
GNSS.listiviessageTypes	
GNSS.reset	GNSS.reset -num NUM -mode MODE
	Reset a Gives module on one of the three KF ports.
	for NUM are: 1, 2, 2
	MODE Chooses what to do with the reset ning mode MODE is entional
	Allowed values for MODE area CYCLE LOW LUCH DELEASE
	Allowed values for <b>MODE</b> are: <b>CYCLE, LOW, HIGH, RELEASE</b> .


Multi-Sensor RTK Module, RTK Reference Station and ISP 5. The Command Line API Reference Guide

## 5.7. LTE commands

This section describes the commands related to the mobile network module and the SIM-card settings. Each API command needs the preamble *MSRTKF* (Example: *MSRTKF LTE.config*).

Command	Description				
LTE.block	LTE.block				
	Retrieves the current blocking date.				
	LTE.block -set SET				
	Set a blocking date (or null to disable blocking)				
	SET Time period in the form 10s or 22m or 1h to set the new blocking				
	date. null to clear the blocking dateset SET is mandatory.				
LTE.chat	LTE.chat -message MESSAGE				
	Send a command to the AT interface of the LTE modem.				
	MESSAGE The AT commandmessage MESSAGE is mandatory.				
LTE.config	LTE.config -apn APN -dial DIAL -user USER -isppw ISPPW -pin PIN				
	Set the configuration for the LTE modem.				
	APN APN that is required to use your SIM card. Contact your internet				
	service provider for that informationapn APN is mandatory.				
	DIAL Dial up number that is required to use your SIM card. Contact your				
	internet service provider for that informationdial DIAL is mandatory.				
	USER Username that is required to use your SIM card. Contact your				
	internet service provider for that informationuser USER is optional.				
	ISPPW Password that is required to use your SIM card. Contact your				
	internet service provider for that informationisppw ISPPW is optional.				
	<b>PIN</b> Pin that is required to use your SIM card. Contact your internet				
	service provider for that informationpin PIN is optional.				
LTE.config.read	LTE.config.read -get GET				
	Retrieve a single configuration item of your LTE configuration.				
	GET Name of the item to getget GET is mandatory. Allowed values for				
	GET are: apn, dial, user, isppw, pin.				
LTE.deviceName	Description follows in next version.				
LTE.getIccid	Description follows in next version.				
LTE.mobileEquipmentStatus	LTE.mobileEquipmentStatus				
	Query the modem for the mobile equipment status.				
LTE.receivedSignal	LTE.receivedSignal -dev DEV				
	Show the received signal quality.				
	<b>DEV</b> tty device of the modem control interface. Defaults to the correct				
	valuedev DEV is optional.				
LTE.reception	LTE.reception				
	Show the received signal quality in unit of 'bars'.				
LTE.restart	LTE.restart				
	Restart LTE modem.				
LTE.service.reception	Description follows in next version.				
LTE.service.state	LTE.service.state -verbose VERBOSE				
	Return the state of the LTE modem without blocking.				



Multi-Sensor RTK Module, RTK Reference Station and ISP

5. The Command Line API Reference Guide

	VERBOSE Print the LTE stateverbose VERBOSE is optional. Allowed values for VERBOSE are: true, false.
LTE.status	LTE.status
	Do an extensive diagnosis of the LTE modem status.

### 5.8. Network commands

This section describes the commands related to the network settings. Each API command needs the preamble *MSRTKF* (Example: *MSRTKF Network.config*).

Command	Description
Network.config	Network.config -interface INTERFACE -get GET
	Get a config item.
	INTERFACE Name of the interface to configure (= ETH)interface
	<b>INTERFACE</b> is mandatory. Allowed values for <b>INTERFACE</b> are: ETH.
	GET Name of the item to retrieveget GET is mandatory. Allowed
	values for GET are: profile, static.address, static.netmask,
	linkLocalAddress, current.address, current.netmask, current.profile.
	Network.config -interface INTERFACE -set SET -value VALUE Set a config item.
	<b>INTERFACE</b> Name of the interface to configure (= <b>ETH</b> )interface
	INTERFACE is mandatory. Allowed values for INTERFACE are: ETH.
	SET Name of the item to changeset SET is mandatory. Allowed values
	for SET are: profile, static.address, static.netmask.
	<b>VALUE</b> New value of the changed item. <b>-value value</b> is mandatory.
	Network.config -interface INTERFACE -get GET Get a config item.
	<b>INTERFACE</b> Name of the interface to configure (= WIFI)interface
	INTERFACE is mandatory. Allowed values for INTERFACE are: WIFI.
	GET Name of the item to retrieveget GET is mandatory. Allowed
	values for GET are: profile, static.address, static.netmask,
	linkLocalAddress, current.address, current.netmask, current.ssid, current.quality, current.profile, ap.ssid, ap.psk, client.ssid, client.psk.
	Network.config -interface INTERFACE -set SET -value VALUE
	Set a config item.
	INTERFACE Name of the interface to configure (= WIFI)interface
	INTERFACE IS mandatory. Allowed values for INTERFACE are: WIFI.
	for SET are: profile, static address, static natmask, an ssid, an nsk
	client scid client nsk
	VALUE New value of the changed item _value VALUE is mandatory
	VALUE NEW Value of the changed itemvalue value is manuatory.
Network.config.apply	Network.config.apply
	Apply pending network configuration.
Network.config.reset	Description follows in next version.



#### Multi-Sensor RTK Module, RTK Reference Station and ISP

5. The Command Line API Reference Guide

Network.profile.config	Network.profile.config -get GET				
	Retrieve configured network profile of a single interface.				
	GET Interface to be queriedget GET is mandatory. Allowed values for				
	GET are: eth0, wlan0.				
	Network.profile.config -set SET -p P				
	Set configured network profile of a single interface.				
	SET Interface to be queriedset SET is mandatory. Allowed values for				
	SET are: eth0, wlan0.				
	P Profile to set. DHCP, STATIC apply only to eth0. CLI_ and AP_ modes				
	apply only to wlan0p P is mandatory. Allowed values for P are: OFF,				
	DHCP, STATIC, CLI_DHCP, CLI_STATIC, AP_STATIC.				
Network.profile.initialize	Description follows in next version.				
Network.renew	Network.renew				
	Change operating system network settings to match device/settings.				
	Network.renew -revert REVERT				
	Change device/settings to match operating system settings.				
	REVERT Set to true to revert device/settings to operating system				
	settingsrevert REVERT is mandatory. Allowed values for REVERT are:				
	true.				
Network.test	Description follows in next version.				
Network.testConnectionNumber	Description follows in next version.				
Network.wifi.info	Description follows in next version.				
Network.wifi.NAT	Network.wifi.NAT -mode MODE				
	Enable NAT for your Wi-Fi access point (allows clients to use your				
	internet connection).				
	MODE Operation mode for NATmode MODE is mandatory. Allowed				
	values for MODE are: OFF, LTE.				
Network.wifi.scan	Description follows in next version.				

## 5.9. Record commands

This section describes the commands related to recording sensor raw data, the sensor fusion solution and the corresponding logs. Each API command needs the preamble **MSRTKF** (Example: **MSRTKF Record.setMode**).

Command	Description					
Record.deleteDataset	Record.deleteDataset -name NAME					
	Delete a recordered dataset.					
	NAME Name of the datasetname NAME is mandatory. Allowed values for					
	NAME are: 20210409_1149_UTC, 20210803_1222_UTC (examples)					
Record.extractStream	Record.extractStream -name NAME -stream STREAM					
	Extract a stream from a dataset.					
	NAME Name of the datasetname NAME is mandatory. Allowed values for					
	NAME are: 20210409_1149_UTC, 20210803_1222_UTC (examples)					



Multi-Sensor RTK Module, RTK Reference Station and ISP

5. The Command Line API Reference Guide

	STREAM Stream to extractstream STREAM is mandatory. Allowed values for STREAM are: recorder.log, LOGvrs.osr, LOGrover0.ubx, driver.log, maintenance.log, ARCHIVE, LOGrover2.ubx, LOGcan.ubx, LOGrover1.ubx, navigation.log, PAD_solution.bin.
Record.getMode	Record.getMode
	Get currently active recorder mode.
Record.listDatasets	Record.listDatasets
	Print a list of all datasets.
Record.setMode	Record.setMode -mode MODE
	Select operation mode of the recorder.
	MODE Selected modemode MODE is mandatory. Allowed values for
	MODE are: UNKNOWN, OFF, SOLUTION, RAW, ALL.

## 5.10. Server commands

This section describes the server commands. Each API command needs the preamble **MSRTKF** (Example: **MSRTKF Server.installUpdate**).

Command	Description					
Server.installUpdate	Description follows in next version.					
Server.mirrorStream	Description follows in next version.					
Server.performanceLog	Server.performanceLog -sort SORT					
	Print performance log.					
	SORT Sort bysort SORT is optional. Allowed values for SORT are:					
	SELF_TIME, TOTAL_DURATION, INVOCATIONS, AVG_DURATION.					
Server.printTrace	Server.printTrace					
	Prints the complete trace log of this command server.					
Server.remotePerformanceLog	Server.remotePerformanceLog -sort SORT -summed SUMMED					
	Print performance log.					
	SORT Sort bysort SORT is optional. Allowed values for SORT are:					
	TERMINATION_TIME, ISSUE_TIME, SERVING_LATENCY,					
	EXECUTION_LATENCY, DURATION, WASTED_TIME, WAITED_TIME,					
	BLOCKED_TIME, CPU_TIME.					
	<b>SUMMED</b> Accumulate over all entries of the same operation.					
	-summed SUMMED is optional. Allowed values for SUMMED are: true,					
	false.					
Server.traceRetention	Server.traceRetention					
	Get current trace retention mode.					
	Server trace retention -set SET					
	Set current trace retention mode. For safety-reasons, this setting can					
	not be made persistent and will go back to SUFT after a restart.					
	SET New modeset SET is mandatory. Allowed values for SET are:					
	SULID, SUFT, WEAK.					
Server.updateiviaintenance1001	Server.updateiviaintenanceiooi -rbin KBIN					
	write binary to temporary location and use atomic file system					
	operation to replace the old binary with the new binary.					



Multi-Sensor RTK Module, RTK Reference Station and ISP

5. The Command Line API Reference Guide

	<b>RBIN</b> Resource that will provide the new binaryrbin RBIN is
	mandatory.
Server.version	Description follows in next version.

### 5.11. Time commands

This section describes the time commands related to NTP. The commands are described in more detail in chapter 9. Each API command needs the preamble *MSRTKF* (Example: *MSRTKF Time.config*).

Command	Description
Time.adjust	Description follows in next version.
Time.config	Time.config -set SET -value VALUE
	Set a time configuration parameter.
	SET Item to be configuredset SET is mandatory. Allowed values for
	SET are: timePolicy, timeServer.
	VALUE Time sync policyvalue VALUE is mandatory. Allowed values
	for VALUE are: SYNC_OFF, SYNC_GNSS, SYNC_NETWORK, AUTO,
	time.nist.gov.
	Time.config -get GET
	Get a time configuration parameter.
	GET Item to be retrievedget GET is mandatory. Allowed values for
	GET are: timePolicy, timeServer.
Time.error	Description follows in next version.
Time.NTP.sync	Description follows in next version.
Time.service.status	Description follows in next version.



Multi-Sensor RTK Module, RTK Reference Station and ISP 6. The ANavS Binary Solution Output Format

## 6. The ANavS Binary Solution Output Format

The ANavS<sup>®</sup> sensor fusion solution provides two different output-streams for the position, attitude, velocity and many more states of solution and quality of solution, the standardized NMEA-Format and the proprietary binary protocol. In the following, the proprietary ANavS<sup>®</sup> binary protocol is described.

By default, it is possible to configure the system simultaneously to write the solution into a file and broadcast the solution via TCP/IP on port **6001**. To stream the solution via Wi-Fi, Ethernet or mobile network, the user needs additionally to the defined port-number the IP-address of the module, which is by default **192.168.42.1** in case you are connected with Wi-Fi Access-Point **"ANavS\_MSRTK\_XXX"**.

## 6.1. The Standard Binary Solution Message

The Binary Protocol is defined as follows:

Structure:	Sync Char 1	Sync Char 2	Class	ID	Length	Payload	ChecksumA	ChecksumB
Bytes:	1 Byte	1 Byte	1 Byte	1 Byte	2 Byte	<i>Length-</i> Byte	1 Byte	1 Byte

The endianness of *Length* and the following *Payload* is little endian. The payload is of *Length*. The checksum is calculated with the 16-Bit Fletcher algorithm over Class, ID, Length and Payload with modulo 256. The ANavS<sup>®</sup> binary protocol message can be identified by Sync Char 1 = 0xB5 (dec 181), Sync Char 2 = 0x62 (dec 98), Class = 0x02 (dec 2) and Id = 0xE0 (dec 224).

In the following, the type of double has 8 bytes. If a variable in the Payload is given in the NED frame, the variable has three components (hence 3 times the data type, e.g. 3\*double), where the components are north, east and down. This also holds for the body frame, which is the fixed frame of the rover, and where the components are given in x, y and z.

### 6.1.1. The Payload

The Payload is given as:

	Size	Scaling	Name	Unit	Description
	uint8	T	id	_	Identifier of the system/the ANavS Position and Attitude Determination (PAD) solution.

Issue: 2.14



Multi-Sensor RTK Module, RTK Reference Station and ISP

	uint16	-	resCode	-	Result code bitfield, which keeps the system status and information.
	uint16	-	week	-	Week number of the current epoch (epoch means Kalman filter state- update with GNSS, IMU or another sensor data).
	double	-	tow	S	Time of Week of the current epoch.
	uint16	-	weekInit	-	Week number of the epoch when the system was started.
	double	-	towInit	S	Time of Week of the epoch when the system was started.
	int16	-	_	-	Reserved
	double	-	lat	deg	Latitude in WGS84.
	double	-	lon	deg	Longitude in WGS84.
	double	-	height	m	Height in WGS84 with geoid EGM96
	double	-	ECEF-X	m	X-position in ECEF- coordinate frame (WGS84).
	double	-	ECEF-Y	m	Y-position in ECEF- coordinate frame (WGS84).
	double		ECEF-Z	m	Z-position in ECEF- coordinate frame (WGS84).
	3*double	-	b	m	Baseline in NED frame spanned by the position given by lat, lon and height, and by the position of the reference station.
	3*double	-	bStdDev	m	Standard deviation of the baseline.
	3*double	-	vel	m/s	Velocity in NED frame.



Multi-Sensor RTK Module, RTK Reference Station and ISP

	3*double	-	velStdDev	m/s	Standard deviation of the velocity.
	3*double	-	асс	m/s²	Acceleration in body frame.
	3*double	-	accStdDev	m/s²	Standard deviation of the acceleration.
	3*double	-	att	deg	Attitude/Euler angles (heading, pitch, roll).
	3*double	-	attStdDev	deg	Standard deviation of the attitude.
	double	-	accuracy	m	Estimated accuracy of the baseline.
	double	-	systemTimeSolOut	S	System time of solution data output packet
	5*double	_	timingInfo	S	CPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Overall elapsed time
	double	_	systemTimePrevPAD	S	System time before executing sensor data
	double	-	systemTimePostPAD	S	System time after executing sensor data
	3*double	-	accNed	m/s²	Acceleration in NED frame.
	1*double	-	-	-	Reserved
	uint8	-	numSats	-	Number of satellites.



Multi-Sensor RTK Module, RTK Reference Station and ISP

	Loop	uint8	-	gnssld	_	Identifier of the GNSS (GPS = 1, SBAS = 2, GLONASS = 4, Galileo = 8).
		uint8	-	svld	-	Identifier of the satellite ("PRN")
		double	-	elev	deg	Elevation angle of the satellite.
		double	-	azim	deg	Azimuth angle of the satellite.
		uint8	_	numRcv	-	Number of GNSS receivers.
Loop		uint8	-	rcvld	-	Identifier of the receiver (unique within this system).
		char[11]	_	serial	-	Serial number of the receiver (unique).
		bool	-	isRefStation	_	Is true if this receiver is a reference station (stationary).
		uint16	_	week	-	Week number of the current epoch for this receiver. If the following tow is NaN, the week number is not valid!
		double	-	tow	S	Time of week of the current epoch for this receiver. Can be NaN, if there are no measurements at this epoch (e.g. commonly for reference station).
		double	_	lat	deg	Latitude of this receiver. Only given if the receiver is a reference station, otherwise it is NaN.
		double	-	lon	deg	Longitude of this receiver. Only given if the receiver is a reference station, otherwise it is NaN.



Multi-Sensor RTK Module, RTK Reference Station and ISP

		double	-	height	m	Height of this receiver. Only given if the receiver is a reference station, otherwise it is NaN.
		3*double	-	bodyPos	m	Receiver position in x, y and z (body frame).
		3*double	-	body Misalign	m	Misalignment of the receiver in x, y and z (body frame).
		uint8	-	-	-	Reserved.
		5*double	_	sensorBufFillLvl	%	Sensor buffer filling level: First double: GNSS Second: IMU Third: BARO Fourth: ODO Fifth: Raw
		uint8	-	numSatsMeas	-	Number of satellites for which measurements are available for this receiver.
	Loop	uint8	_	gnssld	-	Identifier of the GNSS.
		uint8	_	svld	-	Identifier of the satellite.
		uint8	_	freq	-	Frequency band (currently that is 1 L1)).
		uint16	-	locktime	ms	Carrier phase locktime counter (maximum 64500ms).
		uint8	-	cno	dBHz	Carrier-to-noise density ratio (signal strength) [dB-Hz].
		uint8	0.01*2^n	prStdDev	m	Standard deviation of the pseudorange measurement.
		uint8	0.004	cpStdDev	cycles	Standard deviation of the carrier phase measurement.



Multi-Sensor RTK Module, RTK Reference Station and ISP

		uint8	0.002*2^n	doStdDev	Hz	Standard deviation of the Doppler frequency.
		uint8	-	trkStat	-	Status bitfield of the tracking (see graphic below).
		uint8	_	numBl	-	Number of baselines spanned by a receiver pair.
	Loop	uint8	_	rcvid1	_	Identifier of the receiver the baseline is pointing to.
		uint8	-	rcvld2	-	Identifier of the receiver the baseline is pointing from.
		bool	-	isFixed	_	Is true if the ambiguities of the phase measurements are fixed for this baseline.
		uint8	_	gnssldJointRefSat	_	GNSS identifier of the joint reference satellite for the single and double differenced measurements.
		uint8	-	svldJointRefSat	-	Identifier of the reference satellite.
		uint8	-	svIdGloRefSat	-	Identifier of the GLONASS reference satellite.
		uint8	-	svidUnlSat	-	Identifier of the GLONASS ultra- narrow lane satellite.
		3*double	-	aprioriBl	m	A priori baseline.
		3*double	-	stdDevAprioriBl	m	Standard deviation of the a priori baseline.
		double	-	aprioriLen	m	A priori baseline length.
		double	-	stdDevAprioriLen	m	Standard deviation of the a priori baseline length.



Multi-Sensor RTK Module, RTK Reference Station and ISP

		uint8	-	numFilter	-	Number of filters.
Loop		uint8	_	nameLen	Bytes	Length of the filter name.
		char[nameLen]	-	name	-	Filter name.
		uint32	-	params	-	Bitfield of parameters (states, residuals), which are transmitted by the filter.
		bool	-	isActive	-	Is true if the filter is active.
	Conditioned on Bit 0, i.e. if Bit 0 is not set, this shall not be considered (no pointer increment, just leave out!).	6*double	_	absPos	deg and m	Absolute position in latitude, longitude (both in deg) and height (in m) (first 3 doubles) and its standard deviation (latter 3 doubles).
	Bit 1	2*double	-	clkErr	S	Receiver clock error (first double) and its standard deviation (latter double).
	Bit 2	uint8	-	rcvld1	_	Identifier of the receiver the baseline is pointing to.
		uint8	-	rcvld2	_	Identifier of the receiver the baseline is pointing from.
		6*double	-	baseline	m	Baseline in NED frame (first 3 doubles) and its standard deviation (latter 3 doubles).
	Bit 3	6*double	_	vel	m/s	Velocity in body frame (first 3 doubles) and its standard deviation (latter 3 doubles).



Multi-Sensor RTK Module, RTK Reference Station and ISP

Bit 4		6*double	_	acc	m/s²	Acceleration in body frame (first 3 doubles) and its standard deviation (latter 3 doubles).
Bit 5		6*double	-	accBias	m/s²	Accelerometer bias in body frame (first 3 doubles) and its standard deviation (latter 3 doubles).
Bit 6		6*double	-	eulerAng	deg	Euler angles in heading, pitch and roll (first 3 doubles) and its standard deviation (latter 3 doubles).
Bit 7		6*double	-	angRate	deg/s	Angular rate in heading, pitch and roll (first 3 doubles) and its standard deviation (latter 3 doubles).
Bit S		6*double	-	gyroBias	deg/s	Gyroscope bias (first 3 doubles) and its standard deviation (latter 3 doubles).
Bit 9		2*double	-	tropoZenDel	m	Tropospheric zenith delay (first double) and its standard deviation (latter double). Currently not in use (Bit 9 is always 0).
BH 10		2*double	-	Accuracy	m	Accuracy of the baseline (first double) and its standard deviation (latter double). Currently not in use (Bit 10 is always 0).
Bit 11-17		7*double	-	Reserved	-	-
		uint8	-	numPhase	-	Number of phase measurements.
	Loop	uint8	-	gnssld	-	Identifier of the GNSS.



Multi-Sensor RTK Module, RTK Reference Station and ISP

6. The ANavS Binary Solution Output Format

		uint8	-	svld	-	Identifier of the satellite.
		uint8	-	freq	_	Frequency band (currently that is 1 (L1)).
Bit 18		2*double	-	ambiguities	cycles	Double difference ambiguities and std. dev.
Bit 19		2*double	_	phaseMp	m	Phase multipath and std. dev.
Bit 20		2*double	-	phaseRes	m	Phase residuals and std. dev.
		uint8	-	numCode	-	Number of code measurements.
	Loop	uint8	_	gnssld	-	Identifier of the GNSS.
		uint8	-	svld	-	Identifier of the satellite.
		uint8	-	freq	-	Frequency band (currently that is 1 (L1)).
Bit 21		2*double	-	codeMp	m	First double is code multipath, second its standard deviation.
Bit 22		2*double	-	codeRes	m	First double is code residual, second its standard deviation.
		uint8	-	numDoppler	-	Number of Doppler measurements.
	Loop	uint8	-	gnssld	-	Identifier of the GNSS.
		uint8	-	svld	-	Identifier of the satellite.
		uint8	-	freq	-	Frequency band (currently that is 1 (L1)).
Bit 23		2*double	-	doRes	Hz	First double is Doppler residual, second is its standard deviation.

The payload contains loops and conditions. The number of loop iterations and the conditions depends on other payload data. For example, the number of satellites determines, how often the following color-coded data is repeated. For *numSats* = 2 and *p* being a pointer to *numSats*, the following data is given as:



Multi-Sensor RTK Module, RTK Reference Station and ISP

6. The ANavS Binary Solution Output Format

Address	Туре	Name
p+1	uint8	gnssld1
p+2	uint8	svld1
p+3	double	elev1
p+11	double	azim1
p+19	uint8	gnssld2
p+20	uint8	svld2
p+21	double	elev2
p+29	double	azim2
p+37	uint8	numRcv

For *numSats* = 0, no satellite position data is transmitted, and the next variable would be *numRcv*. If a condition is fulfilled, the following color-coded data is transmitted. For example, if *isActive* is true, then at least the variables *numPhase*, *numCode* and *numDoppler* are transmitted. If *isActive* is false, then the end of the binary message is reached. The bitfield *params* is also a condition, whose bits determine, whether the following data is transmitted. **Example:** Let *p* being a pointer to *isActive* with *isActive* = *true*, Bit 0 of *params* is false and Bit 1 is true. Then, p+1 points to the receiver clock error *clkErr* and not to the absolute position *absPos* since Bit 0 is false.

### 6.1.2. The Result-Code

The resCode bitfield in the solution message is defined as:

Bit	Definition
0	Is set for GNSS update-epochs processed in the PAD-Software
1	Is set for IMU update-epochs processed in the PAD-Software
2	Is set for Barometer update-epochs processed in the PAD-Software
3	Is set for Odometry update-epochs processed in the PAD-Software
4	Is set for Camera update-epochs processed in the PAD-Software
5	Is set for Steering update-epochs processed in the PAD-Software
6	Is set if the IMU is initialized/calibrated
7	Is set if the Multi-Sensor RTK-Filter is reset in the current epoch
8	Is set if RTK correction were received initially
9 to 10	State-definition for the Attitude Kalman-Filter:
	00 -> No solution
	01 -> Least-Squares solution
	10 -> Float solution
	11 -> Fixed solution
11 to 12	State-definition for the RTK-Position Kalman-Filter:
	00 -> No solution
	01 -> Least-Squares solution
	10 -> Float solution
	11 -> Fixed solution



Multi-Sensor RTK Module, RTK Reference Station and ISP

6. The ANavS Binary Solution Output Format

13	Is set if the RTK-Position Kalman-Filter has only a float-solution
	accuracy but enough satellites in view to try a RTK-refix (the vehicle
	must be stationary for this try!)
14	Is set if state update is only a prediction step (without sensor data) in our sensor
	fusion filter. In this case, Bit 0-5 is set to zero.
15	Reserved

## 6.2. The Extended Integrity Information Message

To extend the existing binary solution message format with more integrity information, ANavS provides since version 5.1.72 an additional message with the following header:

Sync Char 1 = 0xB5 (dec 181), Sync Char 2 = 0x62 (dec 98), Class = 0x02 (dec 2) and **Id = 0xE5** (dec 229).

The Message is activated via customer-code 10.

#### 6.2.1. The Payload

The Payload is given as:

Size	Scaling	Name	Unit	Description
uint16	-	week	-	Week number of the current epoch
double	-	tow	S	Time of Week of the current epoch
double	-	cov_b_xx		Covariance matrix of RTK solution (value xx)
double	-	cov_b_xy		Covariance matrix of RTK solution (value xy)
double	-	cov_b_xz		Covariance matrix of RTK solution (value xz)
double	-	cov_b_yx		Covariance matrix of RTK solution (value yx)
double	-	cov_b_yy		Covariance matrix of RTK solution (value yy)
double	-	cov_b_yz		Covariance matrix of RTK solution (value yz)
double	-	cov_b_zx		Covariance matrix of RTK solution (value zx)
double	-	cov_b_zy		Covariance matrix of RTK solution (value zy)
double	-	cov_b_zz		Covariance matrix of RTK solution (value zz)
double	-	GDOP		Dilution of Precision: GDOP
double	-	PDOP		Dilution of Precision: PDOP
double	-	HDOP		Dilution of Precision: HDOP
double	-	VDOP		Dilution of Precision: VDOP
double	-	TDOP		Dilution of Precision: TDOP
bool	-	Flag: No		True: Rover stand still, no movement detected with IMU -> RTK- and
		Movement		Attitude Fix is triggered, bias estimation of IMU also.
				False: Rover is moving -> NO RTK- and Attitude Fix is triggered, NO bias
				estimation of IMU
double	-	RTK-Fix		Difference of successfully fixed RTK-baseline to the next best
		Validation		candidate. Only if "Flag No Movement" is true, this value is relevant for
				integrity information of RTK baseline.
double	-	Correction-		Time since last RTK correction-data arrived.
		Outage		



Multi-Sensor RTK Module, RTK Reference Station and ISP 7. The NMEA Solution Output Format

## 7. The NMEA Solution Output Format

The ANavS<sup>®</sup> sensor fusion solution provides two different output-streams for the position, attitude, velocity and many more states of solution and quality of solution, the standardized NMEA-Format and the proprietary binary protocol. In the following, the NMEA-format is described.

By default, it is possible to configure the system simultaneously to write the solution into a file and broadcast the NMEA solution via TCP/IP on port **6002**. To stream the solution via Wi-Fi, Ethernet or mobile network, the user needs additionally to the defined port-number the IP-address of the module, which is by default **192.168.42.1** in case you are connected with Wi-Fi Access-Point **"ANavS\_MSRTK\_XXX"**.

## 7.1. The NMEA-Format

This protocol is based on the international standard for maritime navigation and radio communication, equipment and systems and digital interfaces (IEC 61161-1)<sup>8</sup>. This standard adopted the de-facto standards for interfacing marine electronic devices, known as NMEA 0183. The data is transmitted in sentences of variable length with a specified sentence structure.

### 7.1.1. Sentence Structure

- Address field
- Data fields
- Checksum field
- Terminating field
- All sentences contain only ASCII characters
- The maximum length of a sentence is 82 characters
- All fields are separated by delimiters

### 7.1.2. Address field

The address field starts with "\$" followed by the talker ID and a sentence identifier. The used talker IDs are:

- GP for GPS only solutions
- GL for GLONASS only solutions

Issue: 2.14

<sup>&</sup>lt;sup>8</sup> IEC 61162-1 ed.2: <u>http://read.pudn.com/downloads151/ebook/657722/IEC%2061162-</u> 1%20ed.2%20(2000).pdf



Multi-Sensor RTK Module, RTK Reference Station and ISP

7. The NMEA Solution Output Format

- GA for GALILEO only solutions
- GN for multi GNSS solutions

The used sentence identifiers are:

- GGA Global Positioning System Fix Data
- VTG Course over Ground and Ground Speed
- GSA GNSS DOP and Active Satellites
- GSV GNSS Satellites in View
- RMC Recommended Minimum Specific GNSS Data
- ZDA Time and Date
- PASHR Attitude Data
- ROT Rate of Turn Data
- THS True Heading State Data

#### 7.1.3. Data fields

Data fields must always be separated by ",". They can contain alpha, numeric, and alphanumeric values all coded in ASCII characters. The length of a data field can be constant, variable or can contain a fixed and variable portion. This differs for each sentence.

### 7.1.4. Checksum field

The Checksum field starts with "\*" followed by the checksum of the sentence. The Checksum is generated with a bitwise exclusive OR of all fields including the "," delimiters, between but not including the "\$" and the "\*" characters. The hexadecimal value of the checksum is then converted to two ASCII characters.

### 7.1.5. Terminating field

The terminating sequence contains the two ASCII characters <CR> and <LF> without any delimiter.

### 7.1.6. Satellite Numbering

- GPS: 1-32
- GLONASS: 33-96
- GALILEO: 301-336 <sup>9</sup>

<sup>&</sup>lt;sup>9</sup> Currently no standard way to number Galileo satellites.



Multi-Sensor RTK Module, RTK Reference Station and ISP

7. The NMEA Solution Output Format

## 7.2. Sentence specification

### 7.2.1. GGA – Global positioning system (GPS) fix data

TALKER ID	XX	All talker IDs usable
SENTECE ID	GGA	
UTC of position	hhmmss.ss	Fixed length
		2 digits after dot
Latitude	101.000	Fixed length
		4 digits before and 7 after dot
Hemisphere of latitude	N/S	N if value of latitude is positive
Longitude	1111.11111	Fixed length
		5 digits before and 7 after dot
Hemisphere of longitude	E/W	E if value of longitude is positive
GPS quality indicator	x	0: GNSS fix not available
		1: GNSS fix valid
		4: RTK fixed ambiguities
		5: RTK float ambiguities
Number of satellites used for	XX	Fixed length
positioning		01 for single digits
HDOP	XX.X	Variable/fixed length
		1 digit after dot, variable before
Altitude geoid height	(-)X.XX	Variable/fixed length
		2 digits after dot, variable before
Unit of altitude	Μ	
Geoidal separation	(-)X.XX	Variable/fixed length
		2 digits after dot, variable before
Unit of geoidal separation	Μ	
Age of differential data	XX.X	Age of RTK corrections. Empty if RTK corrections
		never received.
		Variable/fixed length:
		1 digit after dot, variable before
Differential reference station ID		Empty field

#### Example:

\$GNGGA,185833.80,4808.7402397,N,01133.9325039,E,5,15,1.1,470.50,M,45.65,M,,\*75

722	VTG – Course over ground and ground speed
1.2.2.	vid – course over ground and ground speed

TALKER ID	XX	All talker IDs usable
SENTENCE ID	VTG	
Course over ground	X.XX	Variable/fixed length
		2 digits after dot, variable before
		Values from 0 to 359.99
Degrees	Т	True course
Course over ground	X.XX	Variable/fixes length
		2 digits after dot, variable before
		Values from 0 to 359.99
Degrees	М	Magnetic course
Speed over ground	X.XX	Variable/fixed length
		2 digits after dot, variable before
Unit	Ν	knots



Multi-Sensor RTK Module, RTK Reference Station and ISP

7. The NMEA Solution Output Format

Speed over ground	X.XX	Variable/fixed length	
		2 digits after dot, variable before	
Unit	К	Km/h	
Mode indicator	Х	A: Autonomous mode	

The VTG sentence is empty ( \$GNVTG,,T,,M,,N,,K,A\*3D ) until attitude baseline is valid. Course over ground equals heading.

#### Example:

\$GNVTG,112.99,T,109.99,M,0.15,N,0.08,K,A\*3B

		All talker IDs usable*
	~~	All talker IDs usable
SENTENCE ID	GSA	
MODE	X	1: GNSS fix not available
		3: 3D
MODE	XX	M: forced to operate in 3D
ID number	XX	Fixed length: 01 for single digit
	XX	Up to 12 satellites per constellation
	XX	Empty field if not used for positioning
	XX	GPS: ID is PRN (1-32)
	XX	GLONASS: ID is slot number + 64
	XX	GALILEO: PRN + 300
	XX	
PDOP	XX.XX	Fixed length
HDOP		2 digits before and after dot
VDOP		

#### 7.2.3. GSA – GNSS DOP and active satellites

\*if GN is used for Talker ID a separate sentence must to created for each GNSS constellation all starting with the Talker ID for multi GNSS.

Example: \$GNGSA,2,M,06,12,15,17,19,24,25,32,1.34,0.96,0.93\*1D \$GNGSA,2,M,70,71,79,80,81,82,88,1.34,0.96,0.93\*3A

#### 7.2.4. GSV – GNSS satellites in view

TALKER ID	XX	GN must not be used*
SENTENCE ID	GSV	
Total number of messages	Х	1-9
Message number	Х	1-9
Total number of satellites in view	XX	Fixed length: 01 for single digit



Multi-Sensor RTK Module, RTK Reference Station and ISP

7. The NMEA Solution Output Format

Satellite ID number	XX	Fixed length: 01 for single digit
		Empty field if not used for positioning
		GPS: ID is PRN (1-32)
		GLONASS: ID is slot number + 64
		GALILEO: PRN + 300
Elevation	XX	Fixed length: 00 for 0° elevation
		Values from 0 to 90
		Empty if not used
Azimuth	XXX	Fixed length: 000 for 0° azimuth
		Values from 000 to 360
		Empty if not used
SNR	XX	Fixed length: 05 for 5 db/Hz
		Values from 0-99
		Empty if not used

\*if multi GNSS is used a separate GSV sentence must be created for each constellation starting with the constellation specific talker ID.

This block is repeated 4 times per sentence in total. For more than multiples of 4 a new sentence is started each time. Blocks are left empty if the number of satellites in view is lower than a multiple of 4.

Example:

\$GPGSV,6,1,10,02,3.6,133.2,26,10,06,11.7,100.7,39,10,10,9.6,281.5,35,10,12,63.1,256.5,46\* 58

\$GPGSV,6,2,10,15,26.5,186.0,43,10,17,30.5,48.7,42,10,19,43.9,65.3,46,10,24,86.5,103.6,46\* 5E

\$GPGSV,6,3,10,25,21.6,250.8,43,10,32,21.7,316.0,41,,,,,,\*5E

\$GLGSV,6,4,09,69,7.0,215.9,30,09,70,30.8,267.4,44,09,71,23.0,324.4,46,09,73,13.0,286.8,33 \*72

\$GLGSV,6,5,09,79,47.8,70.6,43,09,80,54.9,314.5,38,09,81,48.6,86.8,43,09,82,28.4,150.8,46\* 49

\$GLGSV,6,6,09,88,21.3,28.0,40,,,,,,,\*4E

7.2.5.	RMC – Recommended	minimum	specific GNSS data
--------	-------------------	---------	--------------------

TALKER ID	XX	All talker IDs usable
SENTENCE ID	RMC	
UTC time	hhmmss.ss	Fixed length
Status	x	A: data valid
Latitude	.    11	Fixed length 4 digits before and 7 after dot
Hemisphere of latitude	N/S	N if value of latitude is positive



Multi-Sensor RTK Module, RTK Reference Station and ISP

7. The NMEA Solution Output Format

Longitude	1111.11111	Fixed length
		5 digits before and 7 after dot
Hemisphere of longitude	E/W	E if value of longitude is positive
Speed over ground	X.XX	Variable/fixed length
		2 digits after dot, variable before
Course over ground	X.XX	Variable/fixed length
		2 digits after dot variable before
		Values from 0 to 350 00
Date	ddmmyy	
Magnetic variation	X.XX	Variable/fixed length:
		2 digits after dot, variable before
		E formation an atting
	E/ W	E IT Variation positive
Mode indicator		A: Autonomous
		D: Differential

#### Example:

\$GNRMC,185823.40,A,4808.7402374,N,01133.9324760,E,0.00,112.64,130117,3.00,E,A\*14

#### 7.2.6. ZDA – Time and date

TALKER ID	XX	All talker Ids usable
SENTECE ID	ZDA	
UTC time	hhmmss.ss	Fixed length
Day	XX	Fixed length
		01 to 31
Month	XX	Fixed length
		01 to 12
Year	XXXX	
Local zone hours		Empty field
Local zone minutes		Empty field

Example: \$GNZDA,185823.40,13,01,2017,,\*7E

#### 7.2.7. PASHR – Attitude Data

TALKER ID		No talker ID
SENTENCE ID	PASHR	
UTC time	hhmmss.ss	Fixed length



Multi-Sensor RTK Module, RTK Reference Station and ISP

7. The NMEA Solution Output Format

Heading*	XXX.XX	Fixed value: 000.00 for 0°	
		3 digits before dot, 2 after	
	Т	True heading	
Roll angle*	(-)XXX.XX	Fixed value: 000.00 for 0°	
Pitch angle*	(-)XXX.XX	3 digits before dot, 2 after	
Heave		Empty field	
Roll standard deviation*	XX.XXX	Fixed value	
Pitch standard deviation*	XX.XXX	2 digits before dot 3 after	
Heading standard deviation*	XX.XXX		
Quality flag	X	0: No position	
		1: RTK float position	
		2: RTK fixed position	

\* attitude angles and corresponding deviation values are only filled for defined setup (3D, 2D)

Example:

\$PASHR,190558.56,107.09,T,,-0.16,,,0.067,0.056,2\*34

#### 7.2.8. ROT – Rate of Turn Data

TALKER ID	XX	
SENTENCE ID	ROT	
Rate of turn	(-)X.X	In degrees. Variable/fixed length: 2 digits after dot, variable before
Valid/Invalid	x	A: Valid data V: Invalid data

Example: \$GNROT,35.6,A\*4E

#### 7.2.9. THS – True Heading State Data

TALKER ID	XX	
SENTENCE ID	ROT	
True Heading	XXX.XX	Fixed value: 000.00 for 0°
		3 digits before dot, 2 after
Valid/Invalid	х	A: Valid data
		V: Invalid data

Example: \$GNTHS,35.6,A\*4E



Multi-Sensor RTK Module, RTK Reference Station and ISP 8. CAN-Interface

## 8. CAN-Interface

CAN is a robust and widely spread data bus standard which is among other applications also used in almost all modern vehicles for communication between the various controllers in it.

The ANavS Positioning Systems come with a CAN Interface that allows the user to input wheel odometry values and/or to access the solution data over that interface. When equipped, the Interface can be accessed by the DE-9 connector on the module. The pin assignment is in accordance with CiA<sup>®</sup> 303-1 and given below:



Figure 38: pin assignment is in accordance with CiA® 303-1

Pin	Pin assignment
1	Not connected
2	CAN-L
3	GND
4	Not connected
5	GND
6	Not connected
7	CAN-H
8	Not connected
9	Not connected

The CAN Interface can be fully configured in the ANavS Wizard, where the whole configuration is done in the second step of the initialization process. The CAN-settings are divided in three categories: the **bus settings**, the **solution output (CAN-Output)** and the **odometry input (CAN-Input)**. Every section has three buttons to get, set and restore the configurations of the corresponding section.

## 8.1.CAN Bus Settings

In this section, all physical settings of the CAN Interface are configured. These are:

- **Bus-Speed:** Select the Bit rate of the CAN bus. By default, 500 kBit/s are selected.
- **Termination:** CAN requires a 120 Ohm hardware termination at the last transceiver. The MSRTK System has a built in switchable 120 Ohm termination which can be enabled by using this slider.



Multi-Sensor RTK Module, RTK Reference Station and ISP 8. CAN-Interface

- **Bus-Mode:** The *normal mode* is the default mode in which the CAN Interface is fully operating. In the *listen-only mode*, the CAN-Controller does not transmit any data and does not acknowledge the received CAN-frames. This mode can be used to monitor the data bus without participate or interfere with the traffic on the bus. In the *listen-only mode* it is not possible to output solution information.
- **Output-Enabled:** This function is intended as an extra security layer to avoid unintentional writing on the CAN bus. It has to be enabled in order to use the solution output functionality of the CAN Interface. Otherwise, it is recommended to switch it off.

## 8.2.CAN-Output: ANavS-Solution

The CAN Interface can be used to output the ANavS solution from the sensor fusion software. The CAN Interface sends for each solution variable a unique message containing the value. The endianness of the values is **big-endian** The CAN address corresponds to the ID of the variable. The variables are bundled in groups which can be activated or deactivated by checking the corresponding boxes in the ANavS Wizard. As standard, each packet has a unique ID which is also shown in the table below. To change the IDs of the CAN messages (e.g. to avoid collisions with the information of other devices on the bus), there is the possibility to add an offset to all messages. To use the solution output via CAN, the bus must be configured in the normal mode and the output must be enabled (see section **CAN Bus Settings** above).

ID	Format	Name	Unit	Description
1	uint16	resCode	-	Result code bitfield, which keeps the system status and information.
2	uint16	week	_	Week number of the current epoch.
3	double	tow	S	Time of Week of the current epoch.
4	uint16	weekInit	-	Week number of the epoch when the system was started.
5	double	towInit	S	Time of Week of the epoch when the system was started.
7	double	lat	deg	Latitude.
8	double	lon	deg	Longitude.

The corresponding DBC file can be found in Appendix 1.

Issue: 2.14

**Reference Guide Document** 



### Multi-Sensor RTK Module, RTK Reference Station and ISP 8. CAN-Interface

10doubleECEF-XmX-position in ECEF- coordinate frame11doubleECEF-YmZ-position in ECEF- coordinate frame12doubleECEF-ZmZ-position in ECEF- coordinate frame13-153*doubleECEF-ZmBaseline in NED position in ECEF- coordinate frame13-153*doublebmbaseline in NED position given position of the position of the position of the position of the baseline.16-183*doublebStdDevmStandard deviation of the baseline.19-213*doublevelm/sStandard deviation of the baseline.22-243*doublevelStdDevm/sStandard deviation of the velocity.25-273*doubleaccm/s²Standard deviation of the velocity.31-333*doubleattdegStandard deviation of the velocity.34-363*doubleattStdDevm/s²Standard deviation of the velocity.39-43S*doubleattStdDevsStandard deviation of the acceleration. In indicate the GUI of sed sensors. The sum (green line in the GUI of lagsed time should not over 1 second (>>39-43S*doubletiminginfosStandard devision of the double: Elapsed time GUS; Second double: Elapsed time GUS; Firt double: Elapsed time GUS Second double: Elapsed time GUS Firt double: Elapsed time GUS Fir	9	double	height	m	Height
10100000100000100000100000100000100000011doubleECEF-YmY-position in ECEF- coordinate frame12doubleECEF-ZmZ-position in ECEF- coordinate frame13-153*doublebmBaseline in NED frame spanned by position of the reference station.16-183*doublebStdDevmStandard deviation of the baseline.19-213*doublevelm/sStandard deviation of the velocity in NED frame.22-243*doublevelStdDevm/sStandard deviation of the velocity.25-273*doubleaccm/s²Standard deviation of the velocity.28-303*doubleaccm/s²Standard deviation of the velocity.31-333*doubleattdegStandard deviation of the acceleration.34-363*doubleattdegStandard deviation of the acceleration.39-435*doubletiminginfosStandard deviation of the acceleration.39-43doublegnssReception-Standard deviation of the acceleration.49doublegnssReception-Scalar, which indicates the GNS;	10	double	FCFF-X	m	X-position in ECEF-
11doubleECEF-YmProposition in ECEF- coordinate frame12doubleECEF-ZmZ-position in ECEF- coordinate frame13-153*doublebmBaseline in NED frame spanned by the position of the position of the reference station.16-183*doublebstdDevmStandard deviation of the baseline.19-213*doublevelm/sStandard deviation of the baseline.22-243*doublevelStdDevm/sStandard deviation of the velocity.25-273*doubleaccm/s²Acceleration in body frame.28-303*doubleaccm/s²Acceleration in of the eaceleration.31-333*doubleattdegagles (heading, pitch, roll).34-363*doubleattStdDevdegStandard deviation of the acceleration.39-435*doubletimingInfosStandard deviation of the attitude.49doublegnssReception-Scalar, which indicates the GNSS	10	uousie			coordinate frame
12JoanJoanJoanConstraintImage: Constraint frame12doubleECEF-ZmZ-position in ECEF-coordinate frame13-153*doublebmBaseline in NED13-153*doublebmBaseline in NED16-183*doublebStdDevmStandard deviation19-213*doublevelm/sVelocity in NED19-213*doublevelstdDevm/sStandard deviation of the baseline.22-243*doublevelstdDevm/sStandard deviation of the velocity.28-303*doubleaccm/s²Standard deviation of the velocity.31-333*doubleattdegStandard deviation of the accleration.34-363*doubleattStdDevm/s²Standard deviation of the accleration.39-435*doubletimingInfosCPU-toal of used second double: Elapsed time for MSS Second double: Elapsed time Baro; Fourth double: Reserved49doublegnssReception	11	double	FCFF-Y	m	Y-position in ECEF-
12doubleECEF-ZmZ-position in ECEF-Z coordinate frame Baseline in NED frame spanned by the position given by lat, lon and hegight, and by the position of the reference station.13 - 153*doublebmStandard deviation of the baseline.16 - 183*doublebStdDevmStandard deviation of the baseline.19 - 213*doublevelm/sStandard deviation of the baseline.22 - 243*doublevelStdDevm/sStandard deviation of the eaceleration in body frame.28 - 303*doubleaccm/s²Acceleration in body frame.31 - 333*doubleattdegStandard deviation of the acceleration in hody frame.34 - 363*doubleattStdDevdegStandard deviation of the acceleration.39 - 435*doubletiminginfosSensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time Baro; First double: Elapsed time		uousie			coordinate frame
13131313131313131313141514151618 <td>12</td> <td>double</td> <td>FCFF-7</td> <td>m</td> <td>Z-position in ECEF-</td>	12	double	FCFF-7	m	Z-position in ECEF-
13 - 153*doublebmBaseline in NED frame spanned by the position given height, and by the position of the reference station.16 - 183*doublebStdDevmStandard deviation of the baseline.19 - 213*doublevelm/sVelocity in NED frame.22 - 243*doublevelStdDevm/sStandard deviation of the baseline.25 - 273*doubleaccm/s²Standard deviation of the velocity.28 - 303*doubleaccm/s²Standard deviation of the velocity.31 - 333*doubleattdegStandard deviation of the aseline.34 - 363*doubleattStdDevm/s²Standard deviation of the aseline.39 - 435*doubletiminginfosStandard deviation of the attitude.39 - 430ublegpssReception-Scalar, which indicates the GNSS; Second double: Elapsed time GNSS; Second double: Elapsed time MU; Third double: Hight double: Elapsed time MU; Third dou	12	uousie			coordinate frame
13 - 153*doublebmframe spanned by the position given by lat, lon and negistion of the reference station.16 - 183*doublebStdDevmStandard deviation of the baseline.19 - 213*doublevelm/sStandard deviation of the baseline.22 - 243*doublevelStdDevm/sStandard deviation of the velocity.25 - 273*doubleaccm/s²Acceleration in body frame.28 - 303*doubleaccm/s²Standard deviation of the velocity.31 - 333*doubleattdegStandard deviation of the acceleration.34 - 363*doubleattdegStandard deviation of the acceleration.39 - 435*doubletimingInfosStandard deviation of the acceleration.39 - 43doublegnsReception49doublegnsReception					Baseline in NED
13 - 153*doublebmthe position given by lat, lon and height, and by the position of the reference station.16 - 183*doublebStdDevmStandard deviation of the baseline.19 - 213*doublevelm/sVelocity in NED frame.22 - 243*doublevelStdDevm/sStandard deviation of the velocity.25 - 273*doubleaccm/s <sup>2</sup> Standard deviation of the velocity.28 - 303*doubleaccm/s <sup>2</sup> Standard deviation of the acceleration in body frame.31 - 333*doubleattdegStandard deviation of the acceleration.34 - 363*doubleattStdDevdegStandard deviation of the atceleration.39 - 435*doubletiminginfosStandard deviation of the atceleration.39 - 430doubletiminginfosStandard deviation of the atceleration.49doublegnsReception-Scalar, which indicates the GNSS					frame spanned by
13 - 153*doublebmby lat, lon and height, and by the position of the reference station.16 - 183*doublebStdDevmStandard deviation of the baseline.19 - 213*doublevelm/sVelocity in NED frame.22 - 243*doublevelStdDevm/sStandard deviation of the velocity.25 - 273*doubleaccm/s²Acceleration in body frame.28 - 303*doubleaccStdDevm/s²Standard deviation of the acceleration.31 - 333*doubleattdegangles (heading, pitch, roll).34 - 363*doubleattdegStandard deviation of the attitude.39 - 435*doubletiminginfosCPU-load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time BMU; Third double: Elapsed time GMUS; Second double: Elapsed time GMUS; Fourth double: Elapsed time GMUS; Fo					the position given
height, and by the position of the position of the reference station.16 - 183*doublebStdDevmStandard deviation of the baseline.19 - 213*doublevelm/sVelocity in NED frame.22 - 243*doublevelStdDevm/sStandard deviation of the velocity.25 - 273*doubleaccm/s²Acceleration in body frame.28 - 303*doubleaccStdDevm/s²Standard deviation of the acceleration.31 - 333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34 - 363*doubleattStdDevdegStandard deviation of the acceleration.39 - 435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time Baro; Fourth double: Elapsed time MU; Third double: Elapsed time MU; Third double: Elapsed time MIU; Third double: Elapsed time MIU; Third double: Elapsed time MIU; Third double: Elapsed time MIU; Third double: Elapsed time GNS; Second double: Elapsed time GNS; Fourth double: Elapsed time GNS; Fou	13 – 15	3*double	b	m	by lat, lon and
16 - 183*doublebStdDevmStandard deviation of the baseline.19 - 213*doublevelm/sVelocity in NED frame.22 - 243*doublevelStdDevm/sStandard deviation of the velocity.25 - 273*doubleaccm/s²Standard deviation of the velocity.28 - 303*doubleaccm/s²Standard deviation of the velocity.31 - 333*doubleattdegAttidue/Euler angles (heading, pitch, roll).34 - 363*doubleattStdDevdegStandard deviation of the attitude.39 - 435*doubletiminginfosStandard deviation of the attitude.39 - 43doubletiminginfosS49doublegnssReception-indicates the GMSS					height, and by the
16-183*doublebStdDevmStandard deviation of the baseline.19-213*doublevelm/sStandard deviation of the baseline.22-243*doublevelStdDevm/sStandard deviation of the velocity.25-273*doubleaccm/s²Acceleration in body frame.28-303*doubleaccStdDevm/s²Standard deviation of the acceleration.31-333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34-363*doubleattStdDevdegStandard deviation of the active.39-435*doubleitminginfosStandard deviation of the aspect time Baro; Fourth double: Elapsed time BARO; First double: Elapsed time BARO; First double: Elapsed time BARO; Fourth double: Elapsed time CMO; Firth double: Elapsed time CMO; Firth double: Elapsed time CMO; Fourth double: Elapsed time CMO; Fourth double: Elapsed time CMO; Firth double: Elapsed time CMO; Fourth double: Elapsed time CMO; Fourth double: Elapsed time CMO; Firth double: Elapsed time CM					position of the
16 - 183*doublebStdDevmStandard deviation of the baseline.19 - 213*doublevelm/sVelocity in NED frame.22 - 243*doublevelStdDevm/sStandard deviation of the velocity.25 - 273*doubleaccm/s²Acceleration in body frame.28 - 303*doubleaccStdDevm/s²Standard deviation of the velocity.31 - 333*doubleattdegStandard deviation of the acceleration.31 - 333*doubleattdegStandard deviation of the acceleration.34 - 363*doubleattStdDevdegStandard deviation of the attitude.39 - 435*doubletiminginfosStandard deviation of the attitude.39 - 435*doubletiminginfosSStandard deviation of the attitude.49doublegnssReception-Scalar, which indicates the GNSS					reference station.
19-213*doublevelm/sof the baseline. of the baseline.22-243*doublevelStdDevm/sStandard deviation of the velocity.25-273*doubleaccm/s²Acceleration in body frame.28-303*doubleaccStdDevm/s²Standard deviation of the acceleration.31-333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34-363*doubleattdegStandard deviation of the acceleration.39-435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time Baro; Fourth double: Elapsed time Baro; Fourth double: Elapsed time Baro; Fourth double: Elapsed time GNSS; Second double: Elapsed time GNSS; Second double: Elapsed time GNSS; Second double: Elapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time GNSS; Second double: Elapsed tim	16 – 18	3*double	bStdDev	m	Standard deviation
19-213*doublevelm/sVelocity in NED frame.22-243*doublevelStdDevm/sStandard deviation of the velocity.25-273*doubleaccm/s²Acceleration in body frame.28-303*doubleaccStdDevm/s²Standard deviation of the acceleration.31-333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34-363*doubleattStdDevdegStandard deviation of the acceleration.39-435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time Baro; Fourth double: Elapsed time GOdometry; Fifth double: Reserved49doublegnssReception-Scalar, which indicates the GNS					of the baseline.
22 - 243*doublevelStdDevm/sStandard deviation of the velocity.25 - 273*doubleaccm/s²Acceleration in body frame.28 - 303*doubleaccStdDevm/s²Standard deviation of the acceleration.31 - 333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34 - 363*doubleattStdDevdegStandard deviation of the acceleration.39 - 435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Code: Elapsed time Baro; Fourth double: Elapsed time Code: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Scalar, which indicates the GNSC	19 – 21	3*double	vel	m/s	Velocity in NED
22 - 243*doublevelStdDevm/sStandard deviation of the velocity.25 - 273*doubleaccm/s2Acceleration in body frame.28 - 303*doubleaccStdDevm/s2Standard deviation of the acceleration.31 - 333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34 - 363*doubleattStdDevdegStandard deviation of the acceleration.34 - 363*doubleattStdDevdegStandard deviation of the acceleration.39 - 435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time GNU; Third double: Elapsed time Baro; Fourth double: Elapsed time GNSS49doublegnssReception-Scalar, which indicates the GNSS				, -	frame.
25 - 273*doubleaccm/s²Acceleration in body frame.28 - 303*doubleaccStdDevm/s²Standard deviation of the acceleration.31 - 333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34 - 363*doubleattStdDevdegStandard deviation of the acceleration.34 - 363*doubleattStdDevdegStandard deviation of the attitude.39 - 435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time BNS5; Second double: Elapsed time Bro; Fourth double: Elapsed time Bro; Fourth double: Reserved49doublegnssReception-Scalar, which indicates the GNSS	22 – 24	3*double	velStdDev	m/s	Standard deviation
25 - 273*doubleaccm/s2Acceleration in body frame.28 - 303*doubleaccStdDevm/s2Standard deviation of the acceleration.31 - 333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34 - 363*doubleattStdDevdegStandard deviation of the attitude.39 - 435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time IMU; Third double: Elapsed time IMU; Third double: Elapsed time IMU; Fifth double: Reserved49doublegnssReception				, -	of the velocity.
28 - 303*doubleaccStdDevm/s2body frame. standard deviation of the acceleration.31 - 333*doubleattdegStandard deviation of the acceleration.34 - 363*doubleattStdDevdegStandard deviation of the attitude.34 - 363*doubleattStdDevdegStandard deviation of the attitude.39 - 435*doubletimingInfosElapsed time GNS; Second double: Elapsed time GNS; Second double: Elapsed time GNS; First double: Elapsed time GNS; Fourth double: Elapsed time GNS; Second double: Elapsed time GNS; Second double: Elapsed time GNS; Fourth double: Elapsed time GNS; Fourth double: Elapsed time GNS; Second double: Elapsed time GNS; Fourth double: Fourth double: Fourth double: <b< td=""><td>25 – 27</td><td>3*double</td><td>асс</td><td>m/s²</td><td>Acceleration in</td></b<>	25 – 27	3*double	асс	m/s²	Acceleration in
28 - 303*doubleaccStdDevm/s²Standard deviation of the acceleration.31 - 333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34 - 363*doubleattStdDevdegStandard deviation of the attitude.39 - 435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Elapsed time Odometry; Fifth double: Elapsed time GNIS49doublegnssReception-Scalar, which indirates the GNIS				,	body frame.
31 - 333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34 - 363*doubleattStdDevdegStandard deviation of the attitude.34 - 363*doubleattStdDevdegCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Stalar, which indicates the GNSS	28 – 30	3*double	accStdDev	m/s²	Standard deviation
31 - 333*doubleattdegAttitude/Euler angles (heading, pitch, roll).34 - 363*doubleattStdDevdegStandard deviation of the attitude.34 - 363*doubleattStdDevdegCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor).39 - 435*doubletimingInfosElapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time Baro; Fourth double: Elapsed time Baro; Fourth double: Elapsed time GNCS49doublegnssReception-Scalar, which indicates the GNSS				,	of the acceleration.
31-333*doubleattdegangles pitch, roll).34-363*doubleattStdDevdegStandard deviation of the attitude.39-435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor).39-435*doubletimingInfosElapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Baro; Fourth double: Elapsed time GNSE; Second double: Elapsed time GNSS; Second double: Elapsed time GNS Second double: Elapsed time GNS Second double: Elapsed time GNS49doublegnssReception-	24 22	<b>A</b> *1 11			Attitude/Euler
34 - 363*doubleattStdDevdegStandard deviation of the attitude.39 - 435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time GNSS; Second double: Elapsed time GNS; Second double: Elapsed time GNS; Second double: E	31 - 33	3*double	att	deg	angles (heading,
34 - 363*doubleattStdDevdegStandard deviation of the attitude.39 - 435*doubleCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time Baro; Fourth double: Elapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time GNSS; Second double: Elapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time GNSS; Second Scalar, which indicates the GNSS49doublegnssReception-Scalar, which indicates the GNSS					pitch, roll).
39 - 435*doubletimingInfosCPU-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Software Scalar, which indicates the GNSS	34 – 36	3*double	attStdDev	deg	Standard deviation
39-435*doubletimingInfosCPO-Load of used sensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Scalar, which indicates the GNSS					of the attitude.
39-435*doubletimingInfossensors. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Scalar, which indicates the GNSS					CPU-Load of used
39-435*doubletimingInfos(green line in the GUI) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Scalar, which indicates the GNSS;					sensors. The sum
39-435*doubletimingInfosGoi) of elapsed time should not over 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Scolar, which indicates the GNSS					(green line in the
39-435*doubletimingInfosover 1 second (-> to slow processor). First double: Elapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Scalar, which indicates the GNSS					time should not
39-435*doubletimingInfosover 1 second (->39-435*doubletimingInfosElapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Scalar, which indicates the GNSS					time should not
39 - 435*doubletimingInfosFirst double: Elapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Scalar, which indicates the GNSS					to clow processor)
39 - 435*doubletimingInfosElapsed time GNSS; Second double: Elapsed time IMU; Third double: Elapsed time Baro; Fourth double: Elapsed time Elapsed time Baro; Fourth double: Elapsed time Odometry; Fifth double: Reserved49doublegnssReception-Scalar, which indicates the GNSS					Eirst doublo:
39 - 43       5*double       timingInfo       s       Second double:         Elapsed time GNSS,       Second double:       Elapsed time IMU;         Third double:       Elapsed time Baro;       Fourth double:         Elapsed time       Odometry;       Fifth double:         49       double       gnssReception       -					Flist double.
49       double       gnssReception       -       Second double.         Barsed time IMU;       Third double:       Elapsed time Baro;         Fourth double:       Elapsed time         Barsed time       Odometry;         Fifth double:       Reserved         Scalar,       which         indicates the GNSS       Scalar,	39 – 43	5*double	timingInfo	S	Elapsed tille GNSS,
49       double       gnssReception       -       Scalar, which indicates the GNSS					Elanced time MUL
49       double       gnssReception       -       Scalar, which indicates the GNSS					Third double:
49       double       gnssReception       -       Scalar, which indicates the GNSS					Flansod time Pare:
49     double     gnssReception     -     Scalar, which indicates the GNSS					Fourth doubles
49     double     gnssReception     -     Scalar, which indicates the GNSS					Flansed time
49 double gnssReception – Scalar, which indicates the GNSS					Odometry:
49     double     gnssReception     -     Scalar, which indicates the GNSS					Fifth double
49 double gnssReception – Scalar, which indicates the GNSS					Reserved
49 double gnssReception – indicates the GNSS					Scalar which
	49	double	gnssReception	-	indicates the GNSS



Multi-Sensor RTK Module, RTK Reference Station and ISP 8. CAN-Interface

				signal reception. The value is between 0 and 20, where 20 is the best, i.e. very good conditions.
50	uint8	numSats	_	Number of satellites.

### 8.3.CAN-Input: Dynamic CAN Decoder with .dbc-file

The ANavS sensor fusion can handle different forms of vehicle odometry. Up to 5 variables can therefore be defined. These are either one, two or four independent wheel speeds, and the steering angle or another heading information of the vehicle in the vehicle frame. The algorithms inside of the sensor fusion software calculate from the different inputs the current velocity information in the body frame of the vehicle for the positioning algorithm.

The wheel speed is processed as a signed value. A negative speed means thereby that the wheel is turning backward. It is possible to define the sign on a different CAN message. This could be used if the turning direction of a wheel is encoded in another message or position than the speed. This can also be done with the steering angle if needed.

The implemented Dynamic CAN Decoder allows you to use the ANavS Positioning Systems with CAN signals from your .DBC file without sharing the file with third parties or ANavS. The .dbc file used in this HOW TO is appended to the appendix.

### Minimal required software versions:

MAINTENANCE\_TOOL=4.1.3059 DRIVER=4.1.1807 (Both released on 23.01.2020 via beta channel)

### 8.3.1. Overview

The following Figure 39 shows the overall approach for the preparing of the ANavS Positioning System for the DBC-file, already provided e.g. by the car-manufacturer for an easy decoding of the CAN messages.



Multi-Sensor RTK Module, RTK Reference Station and ISP 8. CAN-Interface



Figure 39: Overview showing the overall approach for preparing the ANavS-System for the DBC-file

### 8.3.2. Copy the DBC-file

Use an FTP/SCP client of your choice to copy your .DBC file to the ANavS Positioning System. To speed up all steps, the user may want to remove unnecessary signals if the DBC-file is very long. Let's assume the user puts the DBC-file to */home/pi/golf.dbc* The example file used here is included in the appendix.

### 8.3.3. Load the file

For every remaining step, the user needs to have access to the ANavS Positioning System via SSH. On the MSRTK-System's shell, load the file with:

### MSRTKF CAN.loadDbc -source /home/pi/golf.dbc

### 8.3.4. Generate code with DBCC

Now, the user must run **dbcc** to generate the source code required to understand signals from your DBC-file. Though there is no hard limit on the number of signals in your DBC file, the resulting code may get very inefficient, if the DBC-file consists of millions of signals. A few thousand signals should be fine. On the shell, run **dbcc** with:

### MSRTKF CAN.dbcc

### 8.3.5. Select signals for sensors

Now the user needs to map CAN signals to sensors supported by the ANavS Positioning System. Supported sensors are:

- Wheel odometry
  - o Front Left (FL)
  - Front Right (FR)
  - Rear Left (RL)
  - Rear Right (RR)
- Steering angle

As of January 2020, the positioning accuracy only benefits from RL and RR. Some cars use unsigned odometry signals and provide turning direction as a separate signal.



Multi-Sensor RTK Module, RTK Reference Station and ISP 8. CAN-Interface

To view the current signal map, run on the MSRTK-System's shell:

#### MSRTKF CAN.signal -get ALL

To view all imported signals, run on the MSRTK-System's shell:

#### MSRTKF CAN.signal

In this example, we see these:

>> MSRTKF CAN.signal can\_0x216\_WheelDirection.WheelDirRearLeft can\_0x216\_WheelDirection.WheelDirRearRight can\_0x217\_WheelSpeed.WheelSpeedRearLeft can\_0x217\_WheelSpeed.WheelSpeedRearRight

To find out a specific signal, run on the shell:

#### MSRTKF CAN.signal -find SEARCHTERM

For example:

>> MSRTKF CAN.signal -find rearleft can\_0x216\_WheelDirection.WheelDirRearLeft can\_0x217\_WheelSpeed.WheelSpeedRearLeft

To map a signal to a sensor, we use the '-map' parameter. It accepts a signal for the magnitude (this may be signed or unsigned) and an optional 'sign' parameter for the turning direction. We run on the shell:

### MSRTKF CAN.signal -map RL -magn speedrearleft -sign dirrearleft,+=0,-=1

The '-magn' parameter accepts a search term for the magnitude of the signal. It does not need to be the precise identifier, as long as the search turns up only on result. The (optional) '-sign' parameter requires a search term and the Enum values for forward and backward, separated by comma without space. Here, +=1 means that a signal with value '1' announces positive wheel speed. Likewise, -=2 means that a signal with value '2' announces negative wheel speed.

We do the same thing for the rear right (RR) sensor:

### MSRTKF CAN.signal -map RR -magn speedrearright -sign dirrearright,+=0,-=1

If we made a mistake, we could delete a configuration:

#### MSRTKF CAN.signal -clear FL

Finally, we review our complete setup:



Multi-Sensor RTK Module, RTK Reference Station and ISP 8. CAN-Interface

#### MSRTKF CAN.signal -get ALL

FL magnitude: null FL signum: null FR magnitude: null FR signum: null RL magnitude: can\_0x217\_WheelSpeed.WheelSpeedRearLeft RL signum: can\_0x216\_WheelDirection.WheelDirRearLeft,+=0,-=1 RR magnitude: can\_0x217\_WheelSpeed.WheelSpeedRearRight RR signum: can\_0x216\_WheelDirection.WheelDirRearRight,+=0,-=1 STEER magnitude: null STEER signum: null Signals are valid (null counts as disabled)

Note that you should only map signals that are present on your CAN bus, as the system waits for all mapped signals to arrive for a complete measurement.

#### 8.3.6. Compile generated code

In this step, all generated code gets compiled and installed on the system. Once it is installed, it will remain fully configured on the system through reboots and software updates. It will take effect as soon as the process completes.

To have the configuration cross-checked again, build, and install the decoder, run:

#### MSRTKF CAN.generateDecoder

You may get some warnings depending on your .dbc file and signal map. If everything worked, it would say: "Decoder built [...]" in the end. The driver will restart immediately and load the new decoder.

#### 8.3.7. Setup CAN hardware filter

To reduce the load on the MSRTK System when there is a high CAN load, unrelated messages can be discarded by a hardware filter. The filter is configured with a **mask** and a **tag** value. Each incoming CAN id is only received if this condition holds:

#### (mask & id) == tag

To generate suitable values for mask and id, run: MSRTKF CAN.hardwareFilter.config

To obtain tag, all used ids (id0, id1, ..., idn) are combined with the bitwise and operator &:



Multi-Sensor RTK Module, RTK Reference Station and ISP 8. CAN-Interface

#### tag = id0 & id1 & ... & idn

This finds all bit positions that have value 1 in every single used id. To obtain **mask**, all bit positions that are equal for all ids have to be searched:

mask = tag | ~(id0 | id1 | ... | idn)

We find all bit positions that have value zero by negating the result of applying the bitwise or opera-tor | on all ids. This combined with the tag, which holds all bit positions which have value 1, is a valid filter-mask.

**Note: tag** can also be used as **mask**. In this case, all selected ids pass the filter, but it is not as specific as possible. This simplification is used in some earlier software versions.

To disable the filter, use:

### MSRTKF CAN.hardwareFilter.config -clear true

#### 8.3.8. Starting Sensor Fusion with ANavS Wizard

The last step is enabling the CAN-Interface and saving raw data for post-processing. Please see the figure below which checkboxes (signed in red) must be activated in the Wizard.



Multi-Sensor RTK Module, RTK Reference Station and ISP 8. CAN-Interface

		1000 - 1000 - 1000
ANavS RTK-Wizard		- 🗆 X
	8 <sup>th</sup> STEP: Starting ANavS Sensor Fusion	LTE Signal- Strength:
ANavS Sensor Fusion		
Enable Save Solution File	the second s	
🗹 Enable Save Raw Data Files		
Enable Odometry (via USB)		
Enable Odometry (via CAN)		
Enable Autostart of Navigation-Service	the second s	
Enable Low-Latency Mode	the second se	
Enable Dynamic Attitude-Fix	And the local sector sector is the sector of the	
Type of Solution-Output:		
Binary-Stream (Port 6001)	And the second	
O Binary-Stream (Port 6001) NMEA-Stream (Port 6002)		
Customer-Code: 0		
Output-Rate:		
	and the second	
	the state of the state of the second state of the	
	the second se	
	and the second state of the second state of the	
	and the second	
	the second s	
	the second s	
Settings	CAN-Status: Not receiving any messages Wizard-Version MSRTK: TCP-Conn	MSRTK-Temperature: 47.80° h: 7.2.1   PAD-Version: 5.1.264 OK (Nav-Mode: UNMANAGED)

Figure 40: Start ANavS Sensor Fusion with activated CAN-Odometry input



Multi-Sensor RTK Module, RTK Reference Station and ISP 9. The Network-Time-Protocol (NTP)

## 9. The Network-Time-Protocol (NTP)

The ANavS<sup>®</sup> Positioning Systems are an accurate GNSS and multi sensor positioning system with Ethernet, WIFI, and LTE networking capabilities. These capabilities make it an ideal accurate network time source. This functionality is implemented using the GNU application "ntpd". As of September 2020, the Positioning Systems ships with the NTP functions installed through the Debian package "ntp" in the version "1:4.2.8p10+dfsg-3+deb9u2".



Figure 41: Overview of NTP functionality in the ANavS Positioning Systems

As shown in Figure 40, the Positioning System provides NTP time via ethernet and WIFI, while receiving time data through GNSS and a backup NTP server. The behavior of the NTP system can be configured on the command line of the ANavS Positioning Systems. The configuration is persisted in the file */home/pi/device/settings*. The ntpd-configuration file will be updated accordingly by the system itself.

## 9.1. Time Policy

Change the time policy on the terminal to select the source of the time provided to the user:

## MSRTKF Time.config -set timePolicy -value <PARAMS>

With time policy parameter **SYNC\_GNSS**>, only GNSS is selected as input to ntpd on the ANavS Positioning System. If satellites are visible for the system, the provided time accuracy reaches millisecond accuracy quickly after the satellites become visible. After this initialization phase, a delicate clock calibration process begins and ntpd will achieve accuracy better than 10 microseconds usually in less than 15 minutes.



Multi-Sensor RTK Module, RTK Reference Station and ISP 9. The Network-Time-Protocol (NTP)

With time policy **SYNC\_NETWORK**>, only the remote NTP server is selected as input to ntpd on the ANavS Positioning System. If it is reachable, the provided time accuracy reaches millisecond accuracy quickly. Due to noise of time measurements over the network, the clock calibration process is limited to an accuracy of 100 microseconds even in ideal conditions. This synchronization is available through Ethernet, Wi-Fi, and mobile network.

With time policy **AUTO**>, both NTP and GNSS are selected as input to ntpd on the ANavS Positioning System. Ntpd uses its own algorithm to select which of the two it selects as reference. The selection strategy is not obvious and won't always select GNSS when available. It even may fail to select GNSS, if the remote NTP server is not reachable.

## 9.2. Time Server

Change the time server that is used as ntpd reference in the Time-Policy **AUTO**> and **SYNC\_NETWORK**> modes. The value will default to "time.nist.gov" if not configured. This server is also queried during booting the ANavS Positioning System to initialize the local clock before GNSS has acquired any satellites.

### MSRTKF Time.config -set timeServer -value time.nist.gov

## 9.3. Status Information

The following command will print information on the time policy as well as the last successful clock synchronizations to NTP and GNSS. The "last successful …" fields are queried from ntpd only every few seconds, so an update may have happened in this short window and is not reported when calling

### MSRTKF Time.service.status

The following command will print information on the time sources used by ntpd. See <a href="http://manpages.ub-untu.com/manpages/bionic/man1/ntpq.1.html">http://manpages.ub-untu.com/manpages/bionic/man1/ntpq.1.html</a> for details.

### ntpq -p

Perform a precision measurement of the local clock error using the best available time source. This may require restarting ntpd and can thus affect clock accuracy:

### MSRTKF Time.error

Set local time immediately from best available time source, while bypassing ntpd. This requires restarting ntpd. This method is accurate to 0.5 milliseconds, so it may actually decrease accuracy if ntpd is already optimally calibrated.



Multi-Sensor RTK Module, RTK Reference Station and ISP 9. The Network-Time-Protocol (NTP)

### MSRTKF Time.adjust

### 9.4. Time-Synchronization with MS-RTK clock

Prerequisites:

- Network connection to the MS-RTK module. Ethernet connection in a local network with static IPs configured is recommended. A static Ethernet IP for the MS-RKT can be configured via the ANavS Wizard in the Ethernet-Settings section.
- Ubuntu Linux system (tested with Ubuntu 18.04) to apply the steps described below.

Install *ntp* from the Ubuntu sources:

#### >> sudo apt-get install ntp

Adapt the NTP configuration file */etc/ntp.conf* to set the MS-RTK as the only time server. Replace <MSRTK-IP> by the configured MS-RTK IP address:

#### pool <MSRTK-IP> iburst

# Provide current local time as a default time source if temporarily internet connectivity is lost.
# Uncomment lines below, to enable current local time as a time source. Disabled to prevent observed
# delays when synchronizing time with the MSRTK.
#server 127.127.1.0
#fudge 127.127.1.0 stratum 10

# Logging # Uncomment lines below, to enable logging of ntp statistics. #statistics loopstats #statsdir /var/log/ntp #filegen peerstats file peers type day link enable #filegen loopstats file loops type day link enable

Restart NTP Service: >> sudo service ntp restart

Check NTP status to see if service is active and running, and the specified time server is used: >> service ntp status



Multi-Sensor RTK Module, RTK Reference Station and ISP 9. The Network-Time-Protocol (NTP)

Monitor the time-synchronization offset (ms) between the clocks of the local client and the time server.

>> ntpq -p

Wait until the offset falls below the desired accuracy, e.g. 1 ms. If the offset is not decreasing, stopping and starting the ntp service may help: >> sudo service ntp stop >> sudo service ntp start

#### Notes:

- Within a small local area network and Ethernet connection time-synchronization offset < 1 ms is achievable.
- In case there are transitions from non-GNSS to GNSS reception areas the provided time may jump from local time to global GPS-based time of weeks. Furthermore, provided time accuracy depends to the availability and reception quality of GNSS signals.
- Monitoring and continuously logging the ntp offset and statistics is recommended to assess the quality of time-synchronization.
- Please set the poll interval in a range of some seconds (not days or even weeks).

#### References:

ntpd wiki Ubuntu-Users: <u>https://wiki.ubuntuusers.de/ntpd/</u> ntpd wiki Windows-Users: <u>https://www.rz.uni-osnabrueck.de/Dienste/NTP/win10.htm</u>


Multi-Sensor RTK Module, RTK Reference Station and ISP 10. ANavS ROS-Ethernet-Adapter (REA)

### 10. ANavS ROS-Ethernet-Adapter (REA)

The ROS-Ethernet Adapter is a command line tool for Linux that provides an adapter between ANavS TCP/IP data streams and ROS. The REA client allows to publish the ANavS sensor fusion solution in ROS (mode 'padsolution2ros').

Please contact the support-team to receive this software package.

### 10.1. System requirements and dependencies

- OS: Linux/ Ubuntu (tested with Ubuntu 18.04, and Ubuntu 20.04)
- ROS base version installed (tested with ROS Melodic/ Ubuntu 18.04, and ROS Noetic/ Ubuntu 20.04)
  - Follow <u>http://wiki.ros.org/ROS/Installation</u> and install "ROS-Base: (Bare Bones)" version
- Additional Ubuntu packages: ROS\_VERSION=melodic

sudo apt install ros-\${ROS\_VERSION}-tf2 ros-\${ROS\_VERSION}-tf2-ros ros-tf2-msgs libtf2msgs-devros-\${ROS\_VERSION}-tf2-geometry-msgs libtf2-dev ros-\${ROS\_VERSION}-tf libxmlrpcpp-devlibrosconsole-dev libactionlib-dev

### 10.2. REA Client

### 10.2.1. Prerequisites

- Linux host with installed REA package.
- ANavS MS-RTK module or Integrated Sensor Platform (ISP)
  - o GNSS antennas connected (with sufficient GNSS reception)
  - Device powered on
- Ethernet or WLAN connection between Linux host and ANavS system (Ethernet recommended)
  - Ethernet and WLAN settings can be configured in the ANavS Wizard
- Start ANavS Wizard and configure the ANavS system
- Start sensor fusion
  - A positioning solution should be provided (see 'Solution' tab in the ANavS GUI)

For mode 'padsolution2ros' if a specific customer code is used:

Copy the ANAVS.conf file into the REA subfolder /configs. The file is usually stored on the MS-RTK module at: /share/PAD/configs/ANAVS.conf.



Multi-Sensor RTK Module, RTK Reference Station and ISP 10. ANavS ROS-Ethernet-Adapter (REA)

To publish the ANavS sensor data only steps 1-3 are required.

#### 10.2.2. Setup your ROS environment

Use the following commands in the command-line:

```
ROS_VERSION=melodic
source /opt/ros/${ROS_VERISON}/setup.bash
roscore&
```

### 10.2.3. Sensor fusion solution (mode: padsolution2ros)

Publishes ANavS sensor fusion solution in ROS. Assumes ANavS sensor fusion is running (eg. on either the ANavS MS-RTK or ISP (remote host)) and TCP/IP data streams are available, eg. via Ethernet connection (default settings IP: 127.0.0.1, port: 6001). Specify the remote host's IP for your setup (--ip <host-ip>), and ANavS sensor fusion solution port if deviating from the default (--port <port>).

#### Usage

```
./client/bin/Release/anavs_ros_ethernet_client padsolution2ros
[--ip <host-ip>] [--port <port>] [options] # specify the MSRTK
host IP
```

#### Use help to print all options

./client/bin/Release/anavs\_ros\_ethernet\_client --help

#### Options

Option	Description
-hhelp	Show help.
ip <host-ip></host-ip>	IP address of remote host [default: 127.0.0.1].
port <host-port></host-port>	TCP/IP data streams port. ANavS sensor fusion solution [default: 6001], sensor data [default: 4001].
padsolution2ros:	
topic_prefix <topic-prefix></topic-prefix>	Prefix for all ROS topics published [default: /anavs/solution].
use_original_timestamps	Use original ANavS solution data timestamps (GPS tow) as ROS message timestamp [default: local host ROS time].



Multi-Sensor RTK Module, RTK Reference Station and ISP

10. ANavS ROS-Ethernet-Adapter (REA)

enable_odom	Enables publishing odometry (topic: /odom; type: nav_msgs::Odometry) and angular rate (topic: /ang_rate; type: geometry_msgs/Vector3Stamped).
enable_pose	Enables publishing pose (topic: /pose_enu; type:
	geometry_msgs::PoseWithCovarianceStamped).
odom_only	Publish only the odometry message '/odom'.
pose_only	Publish only the pose message '/pose_enu'.
publisher_queue_size <queue-size></queue-size>	Sets ROS publisher queue sizes for all messages published. [default: 1]
pose_enu_frame <frame-id></frame-id>	Specifies frame_id of published pose (topic: /pose_enu)' [default: map].
remove_pos_offset	Enables removing initial position offset for publishing pose 'pose_enu', and odometry 'odom'.
publish_to_tf [published_frame <child-frame-id>]</child-frame-id>	Enables publishing transformation to ROS tf. Optional: Specify child_frame_id [default: base_link].
publish_path	Enables publishing path (topic: /path; type: nav_msgs::Path) created from poses (topic: /pose_enu).
publish_ref_station	Enables publishing of reference station coordinates (topic:
	/pos_reference_station; type: geometry_msgs/PointStamped).

#### Remarks

publisher\_queue\_size

- Default: 1. Recommended for real-time settings. Old messages are dropped if they cannot be published fast enough. Prevents messages queueing and delaying the publishing of current messages.
- Increase publisher\_queue\_size (> 1) to avoid message drop.
   Recommended for post-processing settings, where potential delays are not critical but all messages shall be published by priority.
- For more details refer to <u>Choosing a good queue size</u>.

#### Advertised ROS topics

The standard ROS topics provided correspond to the fields of the "Standard Binary Solution Message" documented in Section 6.1. However angular measurements are provided in radians rather than in degrees in the ROS messages.

ROS Topic	Description	ROS Message Type
-----------	-------------	------------------



Multi-Sensor RTK Module, RTK Reference Station and ISP 10. ANavS ROS-Ethernet-Adapter (REA)

/anavs/solution/id	ID	std_msgs/Uint8	
/anavs/solution/week	Week of current epoch	std_msgs/Uint16	
/anavs/solution/tow	Time of Week (sec)	sensor_msgs/TimeReference	
/anavs/solution/pos	Position (NED* in meters)	geometry_msgs/PointStamped	
/anavs/solution/pos_llh	Position (lat,lon,height in deg,deg,meters)	geometry_msgs/PointStamped	
/anavs/solution/pos_xyz	Position (ECEF in meters)	geometry_msgs/PointStamped	
/anavs/solution/att_euler	Attitude/ Euler angles (heading, pitch, roll in rad)	geometry_msgs/PointStamped	
/anavs/solution/att_state	Attitude filter state	std_msgs/UInt8	
/anavs/solution/rtk_state	RTK filter state	std_msgs/UInt8	
/anavs/solution/num_sats	Number of satellites	std_msgs/UInt8	
/anavs/solution/imu_calibrate d	IMU initialized/calib rated	std_msgs/Bool	
/anavs/solution/vel	Velocity (NED* in m/s)	geometry_msgs/Vector3Stamped	
/anavs/solution/acc	Acceleration (body frame in m/s^2)	geometry_msgs/Vector3Stamped	
/anavs/solution/pos_stddev	Std Dev of position (NED* in meters)	geometry_msgs/PointStamped	
/anavs/solution/vel_stddev	Std Dev of velocity (NED* in m/s)	geometry_msgs/PointStamped	
/anavs/solution/att_euler_std dev	Std Dev of attitude/ Euler angles (in rad)	geometry_msgs/PointStamped	



Multi-Sensor RTK Module, RTK Reference Station and ISP

10. ANavS ROS-Ethernet-Adapter (REA)

/anavs/solution/accuracy	Estimated accuracy (m) (stored in: point.x)	geometry_msgs/PointStamped
Optional:		
/anavs/solution/pose_enu	Pose (ENU in meters)	geometry_msgs/PoseWithCovarian ceStamped
/anavs/solution/odom	Odometry (Pose: ENU in meters/ Twist: body frame, velocity in m/s, angular rate in rad/s)	nav_msgs/Odometry
/anavs/solution/ang_rate	Angular rate (NED* in rad/s)	geometry_msgs/Vector3Stamped
/anavs/solution/pos_reference _station	Position of reference station in geographic coordinates (llh)	geometry_msgs/PointStamped
/path	Path for visualization	nav_msgs/Path

\*): The default frame for topics *pos, vel* and *ang\_rate* is NED, but it may vary if a specific customer code is used (see ANAVS Wizard: Customer-Code, and ANAVS.conf: customer\_code). Also the body frame definition may vary if a specific customer code is used.

#### **Topics description**

ROS Topic	Description
id	Identifier of the ANavS Position and Attitude Determination (PAD) solution.
week	Week number of the current epoch.
tow	Time reference message containing the ROS time and the GNSS Time of Week (TOW) in seconds.
pos	The position in local coordinate frame (NED*) in meters. Baseline in local coordinate frame spanned by the position given by pos_llh in lat, lon and height, and by the position of the reference station.
pos_11h	The position in geographic coordinates (lat, lon, height) in degree, degree, meters.
pos_xyz	The position in ECEF coordinates (X, Y, Z) in meters.



#### Multi-Sensor RTK Module, RTK Reference Station and ISP

10. ANavS ROS-Ethernet-Adapter (REA)

att_euler	The attitude in Euler angles (heading, pitch, roll) in rad.		
att_state	The State-definition for the Attitude Kalman-filter: {0,1,2,3} - 0: No solution, 1: Least-Squares solution, 2: Float solution (orange light in ANavS GUI), 3: Fixed solution (green light in ANavS GUI)		
rtk_state	The State-definition for the RTK-Position Kalman-filter {0,1,2,3} - 0: No solution, 1: Least-Squares solution, 2: Float solution (orange light in ANavS GUI), 3: Fixed solution (green light in ANavS GUI)		
num_sats	Number of satellites (May be larger than the number of USED satellites, indicated in the ANavS GUI).		
imu_calibrated	Is set if the IMU is initialized/ calibrated.		
vel	The velocity in local coordinate frame (NED*) in m/s.		
acc	The acceleration in body frame in m/s^2.		
pos_stddev	The standard deviation of the position (NED*) in meters.		
vel_stddev	The standard deviation of the velocity (NED*) in m/s.		
att_euler_stddev	The standard deviation of the attitude in Euler angles in rad.		
accuracy	Estimated accuracy of the position in local coordinate frame in meters. The scalar accuracy value is stored in the component point.x. Components point.y and point.z are set to NaN.)		
Optional:			
pose_enu	The pose in ENU frame in meters. The geographic north direction is aligned with ROS frame y-axis. Heading anlge 0° corresponds to north direction and results in ROS in an orientation where body-frame x-axis (red-axis in rviz) points into ROS frame y-direction. The 6x6 covariance matrix contains the variances of position X, Y, Z and rotation around X, Y, and Z on the diagonal. The covariances are set to zero currently. In case position variances contain NaN/Inf values, the covariance matrix left-upper 3x3 part is set to zeros. In case rotation variances contain NaN/Inf values, the covariance matrix right- lower 3x3 part is set zeros.		
odom	Pose (ENU) in meters, and twist (body frame), velocity in m/s and angular rate in rad/s. Pose covariance matrix, as described for pose_enu. Twist covariance matrix is set zero (not available).		
ang_rate	Angular rate (NED*) in rad/s.		
pos_reference_station	Position of the reference station in geographic coordinates (IIh). Applicable for RTK positioning, not available for PPP positioning.		
path	Path for visualization in RViz.		



Multi-Sensor RTK Module, RTK Reference Station and ISP 11. ANavS<sup>®</sup> Solution Decoder Tool

\*): Note, see table above.

#### Remarks

Please note that the positioning estimates (position, attitude, velocity and acceleration) potentially may jump, ie. they are not guaranteed to be continuous all the time. The nav\_msgs/Odometry pose frame is thus set to "map" rather than "odom", to express that measurements are not guaranteed to be continuous.

#### Visualization in RViz

Run the REA client with enabled options to publish pose and odom topics to publish to tf and to publish a path of the position trajectory. To start at zero position, use the flag -remove\_pos\_offset to remove the initial position offset from the published positions in pose\_enu:

./client/bin/Release/anavs\_ros\_ethernet\_client padsolution2ros [--ip <host-ip>] [--port <port>] --enable\_pose --enable\_odom --remove\_pos\_offset --publish\_to\_tf --publish\_path [options]

Run RViz using the provided config file:

rviz -d configs/anavs.rviz

Following items are displayed:

- Pose with covariance: /anavs/solution/pose\_enu
- Odometry: /anavs/solution/odom
- Path: /path

### 11. ANavS<sup>®</sup> Solution Decoder Tool

The ANavS<sup>®</sup> Solution-Decoder Tool brings the binary solution output file into manageable file formats. The purpose of this tool is mainly for postprocessing. It can transform the .bin/.txt-file into .csv-format (Comma-Separated Values) for quick value visualization and .kml-format for coordinate visualization in Google-Earth.

### 11.1. Download

Download the latest ANavS<sup>®</sup> Solution Decoder Tool for your desired Operating System (Windows 10 or Ubuntu 18.04) from the ANavS Knowledgebase with the following link:



Multi-Sensor RTK Module, RTK Reference Station and ISP 11. ANavS<sup>®</sup> Solution Decoder Tool

### https://anavs.com/knowledgebase/anavs-solution-decoder-tool/

### 11.2. Some Hints

- The Source code has been compiled for Windows systems (MinGW-Windows) and Linux systems (GNU-Linux).
- The path to the datasets shall not contain any space characters or blank spaces.
- If the path is detected to be incorrect, it is safer to close the console and restart because problems tend to arise when trying to correct the path.
- The column header contains the same names as the first 49 variables of the proprietary binary protocol. The protocol is described in chapter 6.
- The decoder tool decodes the ANavS-Solution file commonly known as "PAD\_solution.bin" or "PAD\_solution.txt". However, the solution file can have another name, as long as it does not contain any blank spaces.
- The delimiter of the .csv files is a semicolon ";"
  - The decoder file can be put in the same folder as the file which is desired to be decoded. If that is done, the path to the file can be the file name itself. However, it is always safer to use a complete path than a relative path, e.g., "C:\Users\ANavS\Documents\Test\PAD\_solution.bin" instead of "PAD\_solution.bin"

### 11.3. Hints especially for Linux users

- To use the decoder, please open the bash and change your directory to the path where you saved the decoder file.
- Then enter: "./ubxproject"
  - If the program says that you don't have any access permissions, it probably means that you must change the permission flags/bits of the decoder file
    - Simply enter in the bash: "chmod +x ubxproject"
    - This will give your user the right to access the file which can be seen by the changed flags from "-rw-rw-r-" to à "-rwxrwxr-x"
    - Try it again.

### 11.4. Decode to .csv-format

The .csv-format is a way to visualize the ANavS solution in an editor or any spreadsheetprogram such as Excel and LibreOffice.

- 1. Please open the "ubxprojext.exe" executable.
- 2. A console window will open, which asks for the path to the desired document. Please introduce the correct path to the ANavS solution-file.



Multi-Sensor RTK Module, RTK Reference Station and ISP 11. ANavS<sup>®</sup> Solution Decoder Tool

- 3. If a correct path was introduced, the console will ask which format you wish to receive. You shall enter 0 for a .csv-format.
- 4. The console will ask a second time for a format. However, this time it is referring to the format of the .csv-file. There are two formats to choose from basic and complete.
  - 1. The basic format decodes all the important measurements such as time, position, velocity, and acceleration, in a very compact form.
  - 2. The complete format includes a few more values than the basic one. However, these extra values are mostly valuable for development purposes and do not represent any added value for the customer. In addition, it requires more space. Until now the complete format includes the satellite information of each satellite recorded. Therefore, the console will first ask you which satellite systems you want to consider in the decoding process.
- 5. For practicality it is advised to use the basic format. Therefore enter 0.
- 6. If all values were entered correctly, the tool should begin the decoding process immediately. Thereupon the console visualizes the progress of the decoding process.
- 7. The resulting .csv-file "PADSolution.csv" will appear in the same folder as the "ubxprojext.exe".
- 8. After the decoding process you can open the .csv-file in any spreadsheet-program to see the ANavS<sup>®</sup> Solution-output.

### 11.5. Decode to .kml-format

The .kml-format helps to visualize the recorded trajectory with services such as Google Earth or Google Maps. Since the regular data output-rate is quite high, it would make the .kml-file too memory-intensive. As a result, .kml-file only includes the most significant portion of the original data points, that means only GNSS-epochs are visualized.

- 1. Please open the "ubxprojext.exe" executable.
- 2. A console window will open, which asks for the path to the desired document. Please introduce the correct path to the ANavS solution file.
- 3. If a correct path was introduced, the console will ask which format you wish to receive. You shall enter 1 for a .kml-format.
- 4. If all values were entered correctly, the tool should begin the decoding process immediately. Thereupon the console visualizes the progress of the decoding process.
- The resulting .kml-file "PADSolution.kml" will appear in the same folder as the "ubxprojext.exe".
- 6. After decoding you can use that kml-file to visualize your recorded trajectory, e.g., by incorporating it to Google Earth.



Multi-Sensor RTK Module, RTK Reference Station and ISP

11. ANavS<sup>®</sup> Solution Decoder Tool



Figure 42: Example kml-file where each purple dot is showing the most interesting states like position, velocity, acceleration, and attitude.



Multi-Sensor RTK Module, RTK Reference Station and ISP 12. ANavS<sup>®</sup> Record Extractor Tool

### 12. ANavS<sup>®</sup> Record Extractor Tool

When using the ANavS Positioning Systems, it records a variety of data from different sources/sensors and stores it all in a single file within a zip-archive. The Record-Extractor command line tool can be used to extract this data into several files, one for each channel of data recorded. This tool is especially needed for using recorded data is further analysis in post-processing.

**NOTE:** The target-platform using the Record Extractor Tool is Java 8.

### 12.1. Download

Download the latest ANavS<sup>®</sup> Record Extractor Tool from the ANavS Knowledgebase with the following link:

https://anavs.com/knowledgebase/anavs-record-extractor-tool/

### 12.2. Usage

From command line:

```
java -jar RecordExtractor.jar -i <inputfilepath< [-o
<outputfilepath>]
```

in the directory of the RecordExtractor.jar file

#### 12.2.1. Arguments

inputfilepath: Required. The path of the zip archive containing the data to extract.

outputfilepath: Optional. The path of the directory where the extracted data should be stored. If the directory doesn't exist, it will be created. If this argument is omitted, the tool will store the extracted data in the same directory as the source zip-file.

12.2.2. Output

Currently the tool will be able to name the output files correctly if the port number of the fragment in the input file is one of the following:

Port number	Corresponding filename	
4007	"LOGcan.ubx"	
4001	"LOGrover0.ubx"	
4002	"LOGrover1.ubx"	
4003	"LOGrover2.ubx"	
2102	"LOGvrs.osr"	
6001	"PAD_solution.bin"	



Multi-Sensor RTK Module, RTK Reference Station and ISP

12. ANavS<sup>®</sup> Record Extractor Tool

5003	"maintenance.log"	
5004	"navigation.log"	
5005	"recorder.log"	
4000	"driver.log"	

If the tool comes across any other port number during extraction it will name the file according to the port number and store the contents as a .bin file.



Multi-Sensor RTK Module, RTK Reference Station and ISP 13. LTE-VPN connection to the ANavS Positioning Systems

### 13. LTE-VPN connection to the ANavS Positioning Systems

All ANavS Positioning Systems are delivered with already equipped SIM cards. The SIMs aren't coupled to a fixed service provider but using the best available service provider in its area, a so-called All-Net SIM card. In addition to providing internet access to your module and in case of Wi-Fi connection (through bridging) also to your PC/Laptop, the SIM card provides VPN connection to get SSH remote access and for data streaming through mobile network.

**HINT:** Please contact the support team to get your customer-specific config-file and Token for the settings described below.

### 13.1. Setting up OpenVPN for Linux

- Install OpenVPN software (e.g. "apt-get install openvpn")
- Download client.conf (emnify-eu-west-1.conf) and store it on your server in /etc/openvpn
- Create a file **credentials.txt** in /etc/openvpn with following content to authenticate with your user credentials:

### 7133 YourApplicationToken

The corresponding Application-Token is given in the txt-file **Application\_Token\_XXX.txt** 

• Start openvpn service (e.g. "service openvpn start") and monitor connection in /var/log/syslog

### 13.2. Setting up the OpenVPN for Windows

- Install OpenVPN software from <u>https://openvpn.net/index.php/open-source/downloads.html</u>
- Download client.opvn (emnify-eu-west-1.ovpn) and store it on your server in C:\Program Files\OpenVPN\config
- Create a file **credentials.txt** in C:\Program Files\OpenVPN\config with following content to authenticate with your user credentials:

Issue: 2.14



Multi-Sensor RTK Module, RTK Reference Station and ISP 13. LTE-VPN connection to the ANavS Positioning Systems

### 7133 YourApplicationToken

The corresponding Application-Token is given in the txt-file *Application\_Token\_XXX.txt* 

 Start OpenVPN GUI application and monitor the connection in C:\Program Files\OpenVPN\log\client.txt

Alternatively, you can download OpenVPN clients for Windows, OSX, Android and iOS from <a href="https://openvpn.net">https://openvpn.net</a>



Multi-Sensor RTK Module, RTK Reference Station and ISP 13. LTE-VPN connection to the ANavS Positioning Systems

### APPENDIX-1: EXAMPLE CAN DBC-FILE FOR THE SENSOR DATA INPUT

If you are concerned about undisclosed information in your DBC-file, you can remove most traces of it from the MSRTK-System without impeding operation of the CAN functionality. Files that contain information on your CAN signals after the setup process:

Path	Description	CAN-related con- tent	Clean up notes
/home/pi/device/can_pro- file.dbc	Copy of your .dbc file	Your DBC	File may be deleted, not required for op- eration
/home/pi/device/settings	Database for MSRTK- device specific set- tings	Your signal map	Remove CAN related lines manually, not required for opera- tion
/home/pi/.generator/	Working directory of build process	Generated source code of decoder, binaries	Directory may be de- leted, not required for operation
/share/driver/dbcc/can_pro- file.dbc	Copy of your .dbc file	Your DBC	File may be deleted, not required for op- eration
/share/driver/dbcc/can_pro- file.c	Source code of gener- ated decoder	Extensive infor- mation on your signals	File may be deleted, not required for op- eration
/share/driver/dbcc/can_pro- file.h	Header of generated decoder	Some Information on your signals	File may be deleted, not required for op- eration
/home/pi/device/libdy- namic-decoder.so	Installed decoder bi- naries	Executable de- coder + names of signals	Required for opera- tion

Example golf.dbc file:

VERSION ""

NS\_:

NS\_DESC\_ CM\_ BA\_DEF\_ BA\_ VAL\_ CAT\_DEF\_



Multi-Sensor RTK Module, RTK Reference Station and ISP 13. LTE-VPN connection to the ANavS Positioning Systems

CAT\_ FILTER BA\_DEF\_DEF\_ EV\_DATA\_ ENVVAR\_DATA\_ SGTYPE\_ SGTYPE\_VAL\_ BA\_DEF\_SGTYPE\_ BA\_SGTYPE\_ SIG\_TYPE\_REF\_ VAL\_TABLE\_ SIG\_GROUP\_ SIG\_VALTYPE\_ SIGTYPE\_VALTYPE\_

BS\_:

BU\_:

- BO\_ 535 WheelSpeed: 8 Car
- SG\_ WheelSpeedRearLeft : 33|15@1+ (0.0033,0) [0|0] "" Car
- SG\_ WheelSpeedRearRight : 49|15@1+ (0.0033,0) [0|0] "" Car
- BO\_ 534 WheelDirection: 8 Car
- SG\_ WheelDirRearLeft : 33|1@1+ (1,0) [0|0] "" Car
- SG\_ WheelDirRearRight : 39|1@1+ (1,0) [0|0] "" Car



Multi-Sensor RTK Module, RTK Reference Station and ISP 13. LTE-VPN connection to the ANavS Positioning Systems

### APPENDIX-2: EXAMPLE CAN DBC-FILE FOR THE ANAVS SOLUTION OUTPUT

Example dbc file for all given output parameters according to the Table 1:

VERSION ""

NS\_ :

NS\_DESC\_ CM\_ BA\_DEF\_ BA\_ VAL\_ CAT\_DEF\_ CAT FILTER BA\_DEF\_DEF\_ EV\_DATA\_ ENVVAR\_DATA\_ SGTYPE\_ SGTYPE\_VAL\_ BA\_DEF\_SGTYPE\_ BA SGTYPE SIG\_TYPE\_REF\_ VAL\_TABLE\_ SIG\_GROUP\_ SIG\_VALTYPE\_ SIGTYPE\_VALTYPE\_ BO\_TX\_BU\_ BA\_DEF\_REL\_ BA\_REL\_ BA\_DEF\_DEF\_REL\_ BU\_SG\_REL\_ BU EV REL BU\_BO\_REL\_ SG\_MUL\_VAL\_

#### BS\_:

BU\_:

BO\_ 50 numSats: 8 Vector\_\_XXX SG\_ numSats : 0/8@1+ (1,0) [0/255] "" Vector\_\_XXX



Multi-Sensor RTK Module, RTK Reference Station and ISP 13. LTE-VPN connection to the ANavS Positioning Systems

- BO\_ 49 gnssReception: 8 Vector\_\_XXX SG\_ gnssReception : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "" Vector\_\_XXX
- BO\_ 42 timingInfo\_Odometry: 8 Vector\_\_XXX SG\_ timingInfo\_Odometry : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "s" Vector\_\_XXX
- BO\_ 41 timingInfo\_Baro: 8 Vector\_\_XXX SG\_ timingInfo\_Baro : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "s" Vector\_\_XXX
- BO\_ 40 timingInfo\_IMU: 8 Vector\_\_XXX SG\_ timingInfo\_IMU : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "s" Vector\_\_XXX
- BO\_ 39 timingInfo\_GNSS: 8 Vector\_\_XXX SG\_ timingInfo\_GNSS : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "s" Vector\_\_XXX
- BO\_ 36 attStdDev\_roll: 8 Vector\_\_XXX SG\_ attStdDev\_roll : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "deg" Vector\_\_XXX
- BO\_ 35 attStdDev\_pitch: 8 Vector\_\_XXX SG\_ attStdDev\_pitch : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "deg" Vector\_\_XXX
- BO\_ 34 attStdDev\_heading: 8 Vector\_\_XXX SG\_ attStdDev\_heading : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "deg" Vector\_\_XXX
- BO\_ 33 att\_roll: 8 Vector\_\_XXX SG\_ att\_roll : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "deg" Vector\_\_XXX
- BO\_ 32 att\_pitch: 8 Vector\_\_XXX SG\_ att\_pitch : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "deg" Vector\_\_XXX
- BO\_ 31 att\_heading: 8 Vector\_\_XXX SG\_ att\_heading : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "deg" Vector\_\_XXX
- BO\_ 30 accStdDev\_z: 8 Vector\_\_XXX SG\_ accStdDev\_z : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s^2" Vector\_\_XXX
- BO\_ 29 accStdDev\_y: 8 Vector\_\_XXX SG\_ accStdDev\_y : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s^2" Vector\_\_XXX
- BO\_ 28 accStdDev\_x: 8 Vector\_\_XXX SG\_ accStdDev\_x : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s^2" Vector\_\_XXX
- BO\_ 27 acc\_z: 8 Vector\_\_XXX SG\_ acc\_z : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s^2" Vector\_\_XXX



Multi-Sensor RTK Module, RTK Reference Station and ISP 13. LTE-VPN connection to the ANavS Positioning Systems

BO\_ 26 acc\_y: 8 Vector\_\_XXX SG\_ acc\_y : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s^2" Vector\_\_XXX

BO\_ 25 acc\_x: 8 Vector\_\_XXX SG\_ acc\_x : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s^2" Vector\_\_XXX

BO\_ 24 velStdDev\_D: 8 Vector\_\_XXX SG\_ velStdDev\_D : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s" Vector\_\_XXX

BO\_ 23 velStdDev\_E: 8 Vector\_\_XXX SG\_ velStdDev\_E : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s" Vector\_\_XXX

BO\_ 22 velStdDev\_N: 8 Vector\_\_XXX SG\_ velStdDev\_N : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s" Vector\_\_XXX

BO\_ 21 vel\_D: 8 Vector\_\_XXX SG\_ vel\_D : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s" Vector\_\_XXX

BO\_ 20 vel\_E: 8 Vector\_\_XXX SG\_ vel\_E : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s" Vector\_\_XXX

BO\_ 19 vel\_N: 8 Vector\_\_XXX SG\_ vel\_N : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m/s" Vector\_\_XXX

BO\_ 18 bStdDev\_D: 8 Vector\_\_XXX SG\_ bStdDev\_D : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m" Vector\_\_XXX

BO\_ 17 bStdDev\_E: 8 Vector\_\_XXX SG\_ bStdDev\_E : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m" Vector\_\_XXX

BO\_ 16 bStdDev\_N: 8 Vector\_\_XXX SG\_ bStdDev\_N : 0/64@1- (1,0) [-1.7E+308/1.7E+308] "m" Vector\_\_XXX

BO\_ 15 b\_D: 8 Vector\_\_XXX SG\_ b\_D : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m" Vector\_\_XXX

BO\_ 14 b\_E: 8 Vector\_\_XXX SG\_ b\_E : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m" Vector\_\_XXX

BO\_ 13 b\_N: 8 Vector\_\_XXX SG\_ b\_N : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m" Vector\_\_XXX

BO\_ 12 ECEF\_Z: 8 Vector\_\_XXX SG\_ ECEF\_Z: 0/64@1- (1,0) [-1.7E+308/1.7E+308] "m" Vector\_\_XXX



Multi-Sensor RTK Module, RTK Reference Station and ISP 13. LTE-VPN connection to the ANavS Positioning Systems

BO\_ 11 ECEF\_Y: 8 Vector\_\_XXX SG\_ ECEF\_Y : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m" Vector\_\_XXX

BO\_ 10 ECEF\_X: 8 Vector\_\_XXX SG\_ ECEF\_X : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m" Vector\_\_XXX

BO\_ 9 height: 8 Vector\_\_XXX SG\_ height : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "m" Vector\_\_XXX

BO\_ 8 lon: 8 Vector\_\_XXX SG\_ lon : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "deg" Vector\_\_XXX

BO\_ 7 lat: 8 Vector\_\_XXX SG\_ lat : 0/64@1- (1,0) [-1.7E+308/1.7E+308] "deg" Vector\_\_XXX

BO\_ 5 towInit: 8 Vector\_\_XXX SG\_ towInit : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "s" Vector\_\_XXX

BO\_ 4 weekInit: 8 Vector\_\_XXX SG\_ weekInit : 0|16@1+ (1,0) [0|65535] "" Vector\_\_XXX

BO\_ 3 tow: 8 Vector\_\_XXX SG\_ tow : 0|64@1- (1,0) [-1.7E+308|1.7E+308] "s" Vector\_\_XXX

BO\_ 2 week: 8 Vector\_\_XXX SG\_ week : 0|16@1+ (1,0) [0|65535] "" Vector\_\_XXX

BO\_ 1 resCode: 8 Vector\_\_XXX SG\_ resCode : 0|16@1+ (1,0) [0|65535] "" Vector\_\_XXX

CM\_ SG\_ 50 numSats "Number of satellites"; CM\_ SG\_ 49 gnssReception "Scalar, which indicates the GNSS signal reception";

CM\_ SG\_ 42 timingInfo\_Odometry "CPU-Load of used sensor. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor)";

CM\_ SG\_ 41 timingInfo\_Baro "CPU-Load of used sensor. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor)";

CM\_ SG\_ 40 timingInfo\_IMU "CPU-Load of used sensor. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor)";

CM\_ SG\_ 39 timingInfo\_GNSS "CPU-Load of used sensor. The sum (green line in the GUI) of elapsed time should not over 1 second (-> to slow processor)";

CM\_ SG\_ 36 attStdDev\_roll "Standard deviation of the attitude";

CM\_ SG\_ 35 attStdDev\_pitch "Standard deviation of the attitude";



Multi-Sensor RTK Module, RTK Reference Station and ISP

13. LTE-VPN connection to the ANavS Positioning Systems

- CM\_ SG\_ 34 attStdDev\_heading "Standard deviation of the attitude";
- CM\_ SG\_ 33 att\_roll "Attitude/Euler angles (heading, pitch, roll)";
- CM\_ SG\_ 32 att\_pitch "Attitude/Euler angles (heading, pitch, roll)";
- CM\_ SG\_ 31 att\_heading "Attitude/Euler angles (heading, pitch, roll)";
- CM\_ SG\_ 30 accStdDev\_z "Standard deviation of the acceleration";
- CM\_ SG\_ 29 accStdDev\_y "Standard deviation of the acceleration";
- CM\_ SG\_ 28 accStdDev\_x "Standard deviation of the acceleration";
- CM\_ SG\_ 27 acc\_z "Acceleration in body frame";
- CM\_ SG\_ 26 acc\_y "Acceleration in body frame";
- CM\_ SG\_ 25 acc\_x "Acceleration in body frame";
- CM\_ SG\_ 24 velStdDev\_D "Standard deviation of the velocity";
- CM\_ SG\_ 23 velStdDev\_E "Standard deviation of the velocity";
- CM\_SG\_22 velStdDev\_N "Standard deviation of the velocity";
- CM\_SG\_21 vel\_D "Velocity in NED frame";
- CM\_SG\_20 vel\_E "Velocity in NED frame";
- CM\_SG\_19 vel\_N "Velocity in NED frame";
- CM\_ SG\_ 18 bStdDev\_D "Standard deviation of the baseline";
- CM\_ SG\_ 17 bStdDev\_E "Standard deviation of the baseline";
- CM\_SG\_16 bStdDev\_N "Standard deviation of the baseline";
- CM\_ SG\_ 15 b\_D "Baseline in NED frame spanned by the position given by lat, lon and height, and by the position of the reference station";
- CM\_ SG\_ 14 b\_E "Baseline in NED frame spanned by the position given by lat, lon and height, and by the position of the reference station";

CM\_SG\_13 b\_N "Baseline in NED frame spanned by the position given by lat, lon and height, and by the position of the reference station";

- CM\_ SG\_ 12 ECEF\_Z "Z-position in ECEF-coordinate frame";
- CM\_ SG\_ 11 ECEF\_Y "Y-position in ECEF-coordinate frame";
- CM\_ SG\_ 10 ECEF\_X "X-position in ECEF-coordinate frame";
- CM\_ SG\_ 9 height "Height";
- CM\_ SG\_ 8 lon "Longitude";
- CM\_ SG\_ 7 lat "Latitude";
- CM\_ SG\_ 5 towInit "Time of Week of the epoch when the system was started";
- CM\_SG\_4 weekInit "Week number of the epoch when the system was started";
- CM\_SG\_3 tow "Time of Week of the current epoch";
- CM\_SG\_2 week "Week number of the current epoch";
- CM\_SG\_1 resCode "Result code bitfield, which keeps the system status and information";
- BA\_DEF\_ "BusType" STRING ;
- BA\_DEF\_DEF\_ "BusType" "CAN";
- SIG\_VALTYPE\_ 49 gnssReception : 2;
- SIG\_VALTYPE\_ 42 timingInfo\_Odometry : 2;
- SIG\_VALTYPE\_ 41 timingInfo\_Baro : 2;
- SIG\_VALTYPE\_ 40 timingInfo\_IMU : 2;
- SIG\_VALTYPE\_ 39 timingInfo\_GNSS : 2;
- SIG\_VALTYPE\_ 36 attStdDev\_roll : 2;
- SIG\_VALTYPE\_ 35 attStdDev\_pitch : 2;



Multi-Sensor RTK Module, RTK Reference Station and ISP

13. LTE-VPN connection to the ANavS Positioning Systems

SIG\_VALTYPE\_ 34 attStdDev\_heading : 2; SIG\_VALTYPE\_ 33 att\_roll : 2; SIG\_VALTYPE\_ 32 att\_pitch : 2; SIG\_VALTYPE\_ 31 att\_heading : 2; SIG\_VALTYPE\_ 30 accStdDev\_z : 2; SIG\_VALTYPE\_ 29 accStdDev\_y : 2; SIG\_VALTYPE\_ 28 accStdDev\_x : 2; SIG\_VALTYPE\_ 27 acc\_z : 2; SIG\_VALTYPE\_ 26 acc\_y : 2; SIG\_VALTYPE\_ 25 acc\_x : 2; SIG\_VALTYPE\_ 24 velStdDev\_D : 2; SIG\_VALTYPE\_ 23 velStdDev\_E : 2; SIG\_VALTYPE\_ 22 velStdDev\_N : 2; SIG\_VALTYPE\_ 21 vel\_D : 2; SIG\_VALTYPE\_ 20 vel\_E : 2; SIG\_VALTYPE\_ 19 vel\_N : 2; SIG\_VALTYPE\_ 18 bStdDev\_D : 2; SIG\_VALTYPE\_ 17 bStdDev\_E : 2; SIG\_VALTYPE\_ 16 bStdDev\_N : 2; SIG\_VALTYPE\_ 15 b\_D : 2; SIG\_VALTYPE\_ 14 b\_E : 2; SIG\_VALTYPE\_ 13 b\_N : 2; SIG\_VALTYPE\_ 12 ECEF\_Z : 2; SIG\_VALTYPE\_ 11 ECEF\_Y : 2; SIG\_VALTYPE\_ 10 ECEF\_X : 2; SIG\_VALTYPE\_ 9 height : 2; SIG\_VALTYPE\_ 8 lon : 2; SIG\_VALTYPE\_ 7 lat : 2; SIG VALTYPE 5 towInit : 2; SIG\_VALTYPE\_ 3 tow : 2;



**Multi-Sensor RTK Module, RTK Reference Station and ISP** 13. LTE-VPN connection to the ANavS Positioning Systems

### APPENDIX-3: DRAWING 3D-PRINTED CASING TYPE



Issue: 2.14

Date: 23.05.2023



Multi-Sensor RTK Module, RTK Reference Station and ISP

13. LTE-VPN connection to the ANavS Positioning Systems

### APPENDIX-4: DRAWING INDUSTRIAL CASING TYPE



Issue: 2.14

Date: 23.05.2023



Multi-Sensor RTK Module, RTK Reference Station and ISP 13. LTE-VPN connection to the ANavS Positioning Systems

### APPENDIX-5: DRAWING HIGH-CLASS GNSS-ANTENNA



Issue: 2.14

Date: 23.05.2023



Multi-Sensor RTK Module, RTK Reference Station and ISP 13. LTE-VPN connection to the ANavS Positioning Systems

### APPENDIX-6: DRAWING SURVEY-GRADE GNSS-ANTENNA



Issue: 2.14

Date: 23.05.2023